AD-A128 203 CORRECTIONS AND IMPROVEMENTS TO THE INTERACTIVE COMPUTER PROGRAM FOR THE..(U) NAVAL POSTGRADUATE SCHOOL MONTEREY CA R M HILL MAR 83 1/2

UNCLASSIFIED F/G 9/2 NL





NAVAL POSTGRADUATE SCHOOL
Monterey, California

THESIS

CORRECTIONS AND IMPROVEMENTS TO THE INTERACTIVE COMPUTER PROGRAM FOR THE SURVIVABILITY EVALUATION OF AIRCRAFT CONCEPTUAL DESIGNS (WISAP)

by

Ronald Maxwell Hill

March 1983

Thesis Advisor: R. E. Ball

Approved for public release, distribution unlimited.

DISCLAIMER NOTICE

THIS DOCUMENT IS BEST QUALITY PRACTICABLE. THE COPY FURNISHED TO DTIC CONTAINED A SIGNIFICANT NUMBER OF PAGES WHICH DO NOT REPRODUCE LEGIBLY.

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

REPORT DOCUMENTATION PAGE	READ INSTRUCTIONS BEFORE COMPLETING FORM
1. REPORT NUMBER	2. GOVT ACCESSION NO. A128203 — 3. RECIPIENT'S CATALOG NUMBER
4. TITLE (and Subtitle) Corrections and Improvements to the Interactive Computer Program for the Survivability Evaluation of Aircraft Conceptual Designs (VISAP)	5. TYPE OF REPORT & PERIOD COVERED Master's Thesis March 1983 — 6. PERFORMING ORG. REPORT NUMBER
7. AUTHOR(s) Ronald Maxwell Hill	8. CONTRACT OR GRANT NUMBER(s)
9. PERFORMING ORGANIZATION NAME AND ADDRESS Naval Postgraduate School Monterey, California 93940	10. PROGRAM ELEMENT, PROJECT, TASK AREA & WORK UNIT NUMBERS
11. CONTROLLING OFFICE NAME AND ADDRESS Naval Postgraduate School Monterey, California 93940	12. REPORT DATE March 1983 — 13. NUMBER OF PAGES 182
14. MONITORING AGENCY NAME & ADDRESS(if different from Controlling Office)	15. SECURITY CLASS. (of this report) — 15a. DECLASSIFICATION/DOWNGRADING SCHEDULE

16. DISTRIBUTION STATEMENT (of this Report)

Approved for public release, distribution unlimited.

17. DISTRIBUTION STATEMENT (of the abstract entered in Block 20, if different from Report)

18. SUPPLEMENTARY NOTES

19. KEY WORDS (Continue on reverse side if necessary and identify by block number)

Aircraft Non-nuclear Survivability

Computer Conceptual Design Evaluation

20. ABSTRACT (Continue on reverse side if necessary and identify by block number)

A computer program for assessing the survivability of fixed wing aircraft in the conceptual design phase was developed at the Naval Postgraduate School by Ball and Hesser in 1982. The program was called VISAP (Vought Interactive Survivability Assessment Program). This thesis presents corrections and improvements made to VISAP by the author. These corrections and improvements include improved efficiency and friendliness of the program from the user's viewpoint, enhanced output, and the incorporation of graphics to aid in the assessment and evaluation of aircraft conceptual design.

DD FORM 1 JAN 73 1473 EDITION OF 1 NOV 65 IS OBSOLETE S/N 0102-014-6601

UNCLASSIFIED

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

Approved for public release, distribution unlimited

Corrections and Improvements to the Interactive Computer Program for the Survivability Evaluation of Aircraft Conceptual Designs (VISAP)

by

Ronald Maxwell Hill
Lieutenant Commander, United States Navy
B.S., United States Naval Academy, 1970
M.S.B.A., University of Northern Colorado, 1978

Submitted in partial fulfillment of the requirements for the degree of

MASTER OF SCIENCE IN AERONAUTICAL ENGINEERING

from the

NAVAL POSTGRADUATE SCHOOL
March 1983

Author: R M Hill

Approved by: M E Bell
Thesis Advisor

Donald M Layton
Department of Aeronautics

J N Dyer
Dean of Science and Engineering

ABSTRACT

A computer program for assessing the survivability of fixed wing aircraft in the conceptual design phase was developed at the Naval Postgraduate School by Ball and Hesser in 1982. The program was called VISAP (Vought Interactive Survivability Assessment Program). This thesis presents corrections and improvements made to VISAP by the author. These corrections and improvements include improved efficiency and friendliness of the program from the user's viewpoint, enhanced output, and the incorporation of graphics to aid in the assessment and evaluation of aircraft conceptual design.

TABLE OF CONTENTS

I. INTRODUCTION ---------- 7

II. NATURE OF THE PROBLEM ---------- 11

III. SOLUTIONS ---------- 14

APPENDIX A. VARIABLES, SUBROUTINES AND DEFINITIONS ---------- 21

APPENDIX B. SAMPLE INSTRUCTION MANUAL AND ASSESSMENTS ---------- 35

APPENDIX C. FLOW CHARTS ---------- 55

APPENDIX D. VISAP AND DISVIS EXEC PROGRAM LISTINGS ---------- 57

APPENDIX E. ESCORT AND ESCPLT PROGRAM LISTINGS ---------- 58

APPENDIX F. STRIKE AND STRPLT PROGRAM LISTINGS ---------- 102

APPENDIX G. SUPPORT AND SUPPLT PROGRAM LISTINGS ---------- 140

LIST OF REFERENCES ---------- 180

INITIAL DISTRIBUTION LIST ---------- 181

LIST OF FIGURES

1. Example Plot ---------- 18
2. Sample Escort Plot ---------- 43
3. Sample Escort Baseline Output ---------- 44
4. Sample Escort 1st Design Output ---------- 45
5. Sample Escort 2nd Design Output ---------- 46
6. Sample Strike Plot ---------- 47
7. Sample Strike Baseline Output ---------- 48
8. Sample Strike 1st Design Output ---------- 49
9. Sample Strike 2nd Design Output ---------- 50
10. Sample Support Plot ---------- 51
11. Sample Support Baseline Output ---------- 52
12. Sample Support 1st Design Output ---------- 53
13. Sample Support 2nd Design Output ---------- 54
14. External Program Flow Chart ---------- 55
15. Internal Program Flow Chart ---------- 56

ACKNOWLEDGMENT

To Professor Robert E. Ball for his encouragement and direction which always kept the objective in sight.

To my bride of ten months, Mary Ann, for her love, devotion, and limitless patience. Her advice was timely, consistent, and unfailingly wise.

I. INTRODUCTION

A. SURVIVABILITY (P(s))

Aircraft combat survivability is defined as the capability of an aircraft to avoid and/or withstand a man-made hostile environment. This ability to avoid or withstand the hostile environment is a function of several factors both inherent in and external to the aircraft. Survivability is quantifiable using basic probability theory and can be expressed as unity minus the product of the aircraft's susceptibility and the aircraft's vulnerability.

$$P(s) = 1 - \text{Susceptibility} \times \text{Vulnerability} \qquad (1)$$

1. Susceptibility (P(h))

Susceptibility is the aircraft's inability to avoid the hostile environment. It can be expressed as the probability that the aircraft is hit (P(h)), it is influenced by a multitude of factors. Generally, these factors consist of the threat activity, the threat sensors, the threat tracking ability and the threat propagator. These factors can also be quantified. They can be expressed as the probability of activity (P(a)), the probability of detection (P(d)), the probability of conversion (P(c)), and the probability of damage (P(dam)).

$$P(h) = P(a) \times P(d) \times P(c) \times P(dam) \qquad (2)$$

Susceptibility can be reduced by one or more means. Prominent are threat suppression (reduction of the threat's activity or ability to act), signature reduction (minimizing the aircraft's visual, aural, and electromagnetic emissions or reflections), and overt countermeasures (interference with the threat's ability to track or engage the aircraft).

2. Vulnerability (P(k/h))

Once hit by a damage causing mechanism, such as a fragment or projectile, the reaction of the aircraft is dependent upon its vulnerability. The vulnerability levels may range from no effect through catastrophic destruction, with intermediate effects including but not limited to mission degradation, system or subsystem malfunctions, and component failures.

Vulnerability is often measured using the concept of vulnerable area. An aircraft presents a projected area (A(p)) depending on the aspect of the observer or tracking system. Each aircraft critical component has its own vulnerable area that contributes to the total aircraft vulnerable area (A(v)). The vulnerability of the aircraft can also be measured by the ratio of the aircraft vulnerable area to the aircraft presented area.

$$P(k/h) = A(v) / A(p) \qquad (3)$$

P(k/h) is the probability the aircraft is killed given a hit.

B. VISAP

"The Development of an Interactive Computer Program for the Evaluation of Aircraft Conceptual Designs" [Ref. 1] was the result of the compilation of numerous efforts to perform survivability assessments in the conceptual design phase utilizing deterministic models. The computer programs, collectively called the VISAP (Vought Interactive Survivability Assessment Program) program, eloquently allow the designer or analyst to investigate the effects on survivability of altering, singly or in groups, the aircraft's design features, its vulnerability and susceptibility reduction features, and/or the threat environment parameters. Results of a single sortie and

a campaign analysis and the incremental increases to the aircraft's take-off gross weight are used as measures of effectiveness.

VISAP is also the filename of the CMS control EXEC designed for use on the Naval Postgraduate School's IBM 3033 computer. When executed, it presents the user with the choice of one of three aircraft types to analyze. These types are Fighter Escort, Long Range Strike, and Close Air Support. Each type is assessed by independent programs with filenames of ESCORT, STRIKE, and SUPPORT respectively.

Each program solves the survivability equation using values calculated from the design parameters chosen by the user from "menus" incorporated into the programs and automatically displayed on the user's terminal at the appropriate time during program execution. Subsidiary routines and subroutines either correlate the inputs with tabulated data or do deterministic calculations to produce values for, ultimately, the probability of survival (P(s)) for a design of an aircraft type against predetermined threats. Three subroutines are utilized to determine the results of the single sortie of an aircraft, to conduct a campaign analysis consisting of several flights by many aircraft, and to show a comparison between the new and the original gross weights.

Parameter values are displayed on the terminal while the user is running the program. Changes made are immediately indicated, and the values calculated from the changes are also displayed when appropriate. In addition, upon completion of a design, a hard copy printout may be obtained if desired. This printout contains the susceptibility and vulnerability reduction features, values for P(s), P(d), P(h), and P(k/h),

results of the campaign analysis, the baseline takeoff gross weight, and the enhanced gross weight.

C. CONCLUSION

VISAP was an immense improvement over the previous requirements to correlate masses of emperical and analytic data. The elimination of time consuming, tedious, and, therefore, error prone hand calculations is, of course, the principle benefit of the programs.

II. NATURE OF THE PROBLEM

A. INTRODUCTION

VISAP was used at the Naval Postgraduate School in course AE-3251, Aircraft Combat Survivability during the Spring Quarter 1982. Students were assigned the task of analyzing survivability enhancements on the three available aircraft types. While the results of this project were generally favorable, several inadequacies were discovered in the programs. Furthermore, solicited comments from industry and government activities studying the program pointed out other errors and several suggestions for improvement. The gist of the significant errors, inadequacies, and recommendations are:

1. Erroneous output in some cases
2. Inaccuracies in the "HELP" menus
3. Excessive time to work through a design
4. Inability to save design changes from one run to the next
5. Necessity to reenter each point in the program to duplicate a design
6. Requirement to rerun an entire program to assess the effects of a change to a parameter
7. Limited data on printouts making comparisons between the design and effects difficult
8. Questionable validity of the results
9. No provisions for cost information provided
10. Lack of graphical presentation of results

B. SPECIFICS OF THE PROBLEM

Difficulties with VISAP in general are categorized as follows:

1. The data output and validity of results were suspect due to random and obviously erroneous results. Several minor corrections in the subroutine programming were identified. The corrections to this and other problems will be discussed in more detail in the next chapter. The methodology used to develop the algorithms for the programs' subroutines are not questioned.

2. Inaccuracies and garbled text in the "HELP" menus were identified. Proper interpretations were researched in "The Fundamentals of Aircraft Combat Survivability Analysis and Design" [Ref. 2]. Specifically, the help menu 6's equation for P(s) was incorrect, P(S) = P(D)*P(H)*P(K/H) instead of the correct, P(S) = 1 - (P(D)*P(H)*P(K/H)). Also, HELP menu 3 contained a nonsense line reading, "of study as the A/C type defined them."

3. Students universally complained about an excessive amount of time to complete an evaluation. The inability to save the results of a design effort by means other than reaccessing VISAP at the beginning and having to reenter all previously chosen data was also of concern. The need for a data saving and retrieval routine, in addition to the established capability to automatically reenter the program at the completion of a run, was established. Furthermore, once the user familiarizes himself/herself with program operation, stepping through each sequence becomes redundant. Therefore, a means to automatically assess individual design changes was required.

4. Accompanying item 3 above was the necessity to expand the output. To help identify a design analysis and to correlate which parameter affected which measure of effectiveness, the printouts required design and performance information in addition to the susceptibility and vulnerability reduction features already presented.

5. To enhance industry use, cost information was recommended for inclusion in VISAP. While costing was a major emphasis in the preliminary research, it was not incorporated in Reference 1 and is also considered beyond the scope of the current project.

6. A graphical presentation of an assessment seemed a logical application of VISAP. In fact, a bar chart depicting aircraft loss rate or P(k) versus the threat types was a requirement for the AE-3251 project. A means to utilize some of the graphics utilities available at the Naval Postgraduate School was, therefore, made a requirement.

C. CONCLUSION

Chapter three will delve into the details of the changes and corrections made to the version of VISAP described in Reference 1. The intention of continuing work on VISAP was to improve the efficiency of the program, extend its applicability, and broaden the range of useful information produced. The basic methodologies, approach to the solution, and programming techniques were all considered suitable and, therefore, the corrections and additions are principally enhancements to the basic programs.

III. SOLUTIONS

A. GENERAL

The solutions will be discussed in the same order as the problems to which they relate were delineated in Chapter II. Additionally, appendixes E-G, the program listings, have been annotated with a numbered comment card (c ## ----) preceding each section that has been altered from the original version of VISAP. The number (##) in the comment refers to the like numbered statements of the following paragraphs.

B. SOLUTION SPECIFICS

Corrective action for the problems were developed as follows:

1. Random, erroneous output values were the result of computational errors, programming errors, and the use of mixed mode arithmetic (i.e., integer instead of real data). These errors occurred in the SORT and CAMP subroutines of all three programs. Mixed mode was also discovered in SUPPORT in the Menu 41 section on Vulnerable Area/P(k) vs. AAA, in the SRPDSM, the SRVAAA, and the SRPHR subroutines, in the STRIKE subroutines SSRPDS and ESRWT, and the ESCORT ESRAVG and ESRWT subroutines. The affected sections and subroutines were analyzed, corrected, and now check against hand calculated values for sample cases.

2. Inaccuracies and garbled text in the "HELP" menus as mentioned in Chapter II were identified. The text with corrections has been retyped maintaining the existing format.

3. Incorporation of routines to save data and modifications of the program flow to expedite the time required to perform an evaluation have been made. Data is now retained in a disk file and is continually updated as particular parameters or values change during program execution. At program termination, or any time MENU 7, the assessment routine, is executed, current data is "dumped" to the data file. Separate files, named ESCORT DATA, STRIKE DATA, and SUPPORT DATA, are maintained for the respective aircraft types. When reentering a program, the user is given the option of using either his previously defined data or the default values specified in the declaration section of the program.

The programs are now written to cause an automatic assessment any time a variable is changed. This is accomplished with "GO TO" statements in the menus Main, 2, 3, 4, 5, and 6 which force the program to execute Menu 7, to evaluate gross weight changes (subroutines ESRWT or SSRWT), and to record all values in the data file.

Following the evaluation, when the user exits the program, the current assessment is displayed on the terminal. He/she may opt to have this information printed, then exit; reenter the program; or exit without a printout.

4. The printouts themselves include new sections. The full title of the aircraft type is spelled out. For example, "Long Range Strike Aircraft" replaces the abbreviated "Strike Aircraft" used previously. Performance features, mission parameters, and threat parameters are enumerated, in addition to the existing susceptibility and vulnerability reduction features. These additions facilitate the identification of

the cause and effect relationships between the independent design variables and the resulting changes in the survivability assessment.

The augmented printouts are produced by rewritten statements in the Exit routines' "WRITE" statements and their associated "FORMAT" statements. Furthermore, this output is identical to that displayed on the terminal screen which was discussed in objective 3. This is accomplished by incorporating repetitive "WRITE" statements with the unit codes changed to direct output to the terminal instead of the printer.

5. Graphics capability posed many possibilities and a multitude of alternatives. First, consideration had to be given to what information was to be presented. Since the Probability of Survival (P(s)) or the Probability of Kill (P(k)) provides a comprehensive, quantifiable evaluation of a design, the choices were immediately limited to one of these. Of the two, Probability of Kill, against each of the threat types, was arbitrarily picked since it was anticipated to show a decreasing trend for each successive design which seems more esthetically pleasing. Second, a decision concerning the format of the graph was needed. A bar chart was picked for its simplicity and to remain consistent with the AE-3251 project objectives. Third, several plotting devices are available that can be accessed either directly from VISAP or separately by the user. The dual screen IBM 3277/Tektronix 618 system at NPS was chosen due to its availability and its ability to produce both a CRT display and a hard copy printout. The user must decide upon which assessments to have plotted, and then, subsequent to exiting the program but at his/her convenience, he/she may obtain graphs of the chosen designs. Finally, the numbers of

assessments to be depicted had to be determined. In keeping with prior requirements, and in an effort to supply adequate information and yet prevent the charts from becoming cluttered, a total of three design alternatives are presented. These are indicated on the graphs by separate bars corresponding to a Baseline, a 1st Design, and a 2nd Design. Three bars corresponding to the three alternative designs are clustered vertically above the appropriate threat type. Figure 1 shows a typical plot.

VISAP MENU 8 was written to calculate the Probability of Kill against each threat type.

$$P(k) = 1. - P(s) \qquad (4)$$

Menu 8, additionally incorporates routines to query the user about his plotting intentions, to provide him/her with further plotting procedure information, and to file the data required for the plots. When Menu 8 is executed, the user is informed as to how many designs he has selected for plotting (i.e., 0 of 3, 1 of 3, or 2 of 3) and is given the opportunity to access a HELP MENU 8 which was written to provide further information concerning plot procedures. If the user decides to have the current design depicted, VISAP files the plotting data in disk files named ESCPLT DATA, STRPLT DATA, or SUPPLT DATA, respectively, from the ESCORT, STRIKE or SUPPORT programs. These plot data files are distinct from the aforementioned "save" data files.

The DISSPLA (a Proprietary Software Product of Integrated Software Systems Corporation) system was utilized to write separate Fortran IV programs for each aircraft type. Named ESCPLT, STRPLT, and SUPPLT, they peruse their respective data files, format the presentation, and direct

EXAMPLE AIRCRAFT

Loss Rate VS. Threat Type



Figure 1. EXAMPLE PLOT

the output to the Tektronix 618 display screen. The user simply presses the "HARD COPY" key below the screen to obtain a printed copy assuming, of course, the screen in use is attached to a printer.

ESCPLT, etc., are controlled by a CMS EXEC called DISVIS. The user operates DISVIS in a manner similar to VISAP. When seated before a dual screen terminal, and having accessed DISVIS, he/she enters the plot desired (ESCPLT, STRPLT, or SUPPLT) and the proper graph will automatically appear on the adjoining screen. One caution must be noted. The user must have made three design selections during one terminal session prior to attempting a plot request. If fewer than three data points are filed, DISSPLA will inform the viewer that "the end of data file" on the appropriate unit number (disk) has been reached. While some sort of graph may be presented, there will probably be depicted zero values, erroneous P(k)'s or other even more erratic or undesirable output.

C. CONCLUSION

VISAP as currently configured is an extensive, highly versatile, and efficient computer program or, more properly, an interdependent system of programs. While "user friendly," by design, it still produces voluminous amounts of information containing both the detail and the broad overview required to perform effective survivability assessments on aircraft conceptual designs. This version retains the original's modular form, allowing easier "debugging" and possible further modifications. Additionally, menus and subroutines can be changed or new ones added easily without affecting the other aspects of the program.

No project is complete without comment concerning recommendations for further possible improvements. VISAP could encompass other aircraft types, for instance, helicopters and their variety of applications. To enhance industrial usage, current cost of aircraft and the ramifications upon those costs of alternative survivability related components need to be integrated into VISAP.

APPENDIX A

VARIABLES, SUBROUTINES, AND DEFINITIONS

A.1. ESCORT

A.1.1. Menu 2 Design

A.1.1.1. Menu 21 Aircraft Performance Inputs

TW	thrust to weight ratio
WS	wing loading
WT	ordnance weight
B	wing span
XL	fuselage length
W	fuselage width
EC	engine face to quarter chord
ED	engine diameter
EL	engine length
DL	duct length

A.1.1.2. Menu 22 Susceptibility Features

JAM	jammer number
IRCS	RCS reduction level
IWARN	RWR installed/not installed value
ICHAFF	chaff dispenser installed/not installed value
IRJAM	IR jammer installed/not installed value
IRFLAR	IR flare dispenser installed/not installed value
IRSUP	IR suppression susceptibility value

A.1.1.3. Menu 23 Vulnerability Features

IFS	general fuel system vulnerability value
IFV	fuel/void interface vulnerability value
IFE	fuel/engine interface vulnerability value
IEA	engine arrangement vulnerability value
IEP	engine protection vulnerability value
ICS	control system vulnerability value
ICA	crew arrangement vulnerability value

A.1.2. Menu 3 Combat Scenario

A.1.2.1. Menu 31 Mission Description

XMDA	mission dash altitude
XMDM	mission dash distance
XMDD	mission dash Mach number

A.1.2.2. Menu 32 Threat Definition

AAH	air-to-air threat density
AAD	air-to-air threat diameter
AAL	air-to-air threat penetration distance
SAMH	low altitude SAM threat density
SAMD	low altitude SAM threat diameter
SAML	low altitude SAM threat penetration distance

A.1.3. Menu 4 Susceptibility Assessment

A.1.3.1. Menu 41 Probability of Detection

PDAAG	P(d) by air-to-air guns
PDAAM	P(d) by air-to-air IR missiles
PDSM	P(d) by low altitude SAM

A.1.3.2. Menu 42 Probability of Hit

PHG P(h) by air-to-air guns

PHM P(h) by air-to-air IR missile

PHSM P(h) by low altitude SAM

A.1.4. Menu 5 Vulnerability Assessment

A.1.4.1. Menu 51 Vulnerable Area and Probability of Kill Given a Hit

APAAG presented area to air-to-air guns

AVAAG vulnerable area to air-to-air guns

PKHAAG P(k/h) by air-to-air guns

AVAAM vulnerable area to air-to-air IR missile

PKHAAM P(k/h) by air-to-air IR missile

VASM vulnerable area to low altitude SAM

PKHSM P(k/h) by low altitude SAM

A.1.5. Menu 6 Survivability Assessment

A.1.5.1. Menu 61 Probability of Survival

PSAG P(s) vs. air-to-air guns

PSAM P(s) vs. air-to-air IR missile

PSSM P(s) vs. low altitude SAM

A.1.5.2. Menu 62 Sortie Analysis

ACR number of aircraft in single sortie

XNPASS number of targets attacked by aircraft per sortie

ACR2 number of aircraft ready for next sortie

TOTSR total sorties flown

TOTACK total targets attacked

TOTACL total aircraft lost

TOTACR total aircraft in repair at end

SORT subroutine to perform sortie analysis

A.1.5.3. Menu 63 Campaign Analysis

ACR1 number of aircraft in campaign

NSRT number of raids in the campaign

NS maximum number of sorties for repair

A.1.6. Menu 7 Reassessment

ESRPDS subroutine: P(d) by low altitude SAM

ESRPHG subroutine: P(h) by air-to-air guns

ESRPHM subroutine: P(h) by air-to-air IR missile

ESRPHS subroutine: P(h) by low altitude SAM

ESRAVG subroutine: A(v) and P(k/h) vs. air-to-air guns

ESRAVM subroutine: A(v) and P(k/h) vs. air-to-air IR missile

ESRAVS subroutine: A(v) and P(k/h) vs. low altitude SAM

CAMP subroutine to perform campaign assessment

A.1.7. Menu 8 Plotting Routine

N counter for maximum of three plot values

PKAG P(k) vs. air-to-air guns array

PKAM P(k) vs. air-to-air IR missile array

PKSM P(k) vs. low altitude SAM array

A.1.8. Other/Miscellaneous

I1 single digit integer input

I2 two digit integer input

V1 real number input

IJK integer to prevent auto-scroll

KK	general commands comparison array
K1	Main Menu comparison array
K2	Menu 2 comparison array
K3	Menu 3 comparison array
K4	Menu 4 comparison array
K5	Menu 5 comparison array
K6	Menu 6 comparison array
JJ	Menu 8 comparison array
K1Q-K9Q	branch command variables
SRFA	subroutine: alertion factor
SRFC	subroutine: chaff factor
ESRWT	subroutine: take off gross weight

A.2. ESCPLT

XO	X-axis points array
YO	lower Y-axis values
Y1	Baseline Design P(k)'s array
Y2	1st Design P(k)'s array
Y3	2nd Design P(k)'s array
IPKRAY	Legend text array

A.3. STRIKE

A.3.1. Menu 2 Design

A.3.1.1. Menu 21 Aircraft Performance Inputs

TW	thrust to weight ratio
WS	wing loading
WT	ordnance weight

B wing span

XL fuselage length

W fuselage width

EC engine face to quarter chord

ED engine diameter

EL engine length

A.3.1.2. Menu 22 Susceptibility Features

JAM jammer number

IRCS RCS reduction level

IWARN RWR installed/not installed value

ICHAFF chaff dispenser installed/not installed value

A.3.1.3. Menu 23 Vulnerability Features

IFS general fuel system vulnerability value

IFV fuel/void interface vulnerability value

A.3.2. Menu 3 Combat Scenario

A.3.2.1. Menu 31 Mission Description

XMA mission penetration altitude

XMD mission penetration distance

XMM mission penetration Mach number

A.3.2.2. Menu 32 Threat Definition

AAH air-to-air threat density

AAD air-to-air threat diameter

SAMH high altitude SAM threat density

SAMD high altitude SAM threat diameter

A.3.3. Menu 4 Susceptibility Assessment

A.3.3.1. Menu 41 Probability of Detection

PDSM P(d) by high altitude SAM

PDAR P(d) by air-to-air IR missile

A.1.3.2. Menu 42 Probability of Hit

PHSM P(h) by high altitude SAM

PHAR P(h) by air-to-air IR missile

A.3.4. Menu 5 Vulnerability Assessment

A.3.4.1. Menu 51 Vulnerable Area and Probability of Kill Given a Hit

AVAA vulnerable area to air-to-air IR missile

PKHAA P(k/h) by air-to-air IR missile

VASM vulnerable area to high altitude SAM

PKHSM P(k/h) by high altitude SAM

A.3.5. Menu 6 Survivability Assessment

A.3.5.1. Menu 61 Probability of Survival

PSSM P(s) vs. high altitude SAM

PSAR P(s) vs. air-to-air IR missile

A.3.5.2. Menu 62 Sortie Analysis

ACR number of aircraft in single sortie

X1NPASS number of targets attacked by aircraft per sortie

ACR2 number of aircraft ready for next sortie

TOTSR total sorties flown

TOTACK total targets attacked

TOTACL total aircraft lost

TOTACR total aircraft in repair at end

SORT subroutine to perform sortie analysis

A.1.5.3. Menu 63 Campaign Analysis

ACR1	number of aircraft in campaign
XNPASS	number of targets attacked by aircraft in campaign
NSRT	number of raids in the campaign
NS	maximum number of sorties for repair

A.3.6. Menu 7 Reassessment

SSRPDA	subroutine: P(d) by air-to-air IR missile
SSRPDS	subroutine: P(d) by high altitude SAM
SSRPHR	subroutine: P(h) by air-to-air IR missile
SSRPHS	subroutine: P(h) by high altitude SAM
SSRAVA	subroutine: A(v) and P(k/h) vs. air-to-air IR missile
SSRAVS	subroutine: A(v) and P(k/h) vs. high altitude SAM
CAMP	subroutine to perform campaign assessment

A.3.7. Menu 8 Plotting Routine

N	counter for maximum of three plot values
PKSM	P(k) vs. high altitude SAM array
PKAR	P(k) vs. air-to-air IR missile

A.3.8. Other/Miscellaneous

I1	single digit integer input
I2	two digit integer input
V1	real number input
IJK	integer to prevent auto-scroll
KK	general commands comparison array
K1	Main Menu comparison array
K2	Menu 2 comparison array

K3	Menu 3 comparison array
K4	Menu 4 comparison array
K5	Menu 5 comparison array
K6	Menu 6 comparison array
JJ	Menu 8 comparison array
K1Q-K9Q	branch command variables
SRFA	subroutine: alertion factor
SRFC	subroutine: chaff factor
ESRWT	subroutine: take off gross weight

A.4. STRPLT

XO	X-axis points array
YO	lower Y-axis values
Y1	Baseline Design P(k)'s array
Y2	1st Design P(k)'s array
Y3	2nd Design P(k)'s array
IPKRAY	Legend text array
LABEL	X-axis labels array

A.5. SUPPORT

A.5.1. Menu 2 Design

A.5.1.1. Menu 21 Aircraft Performance Inputs

TW	thrust to weight ratio
WS	wing loading
WT	ordnance weight
B	wing span
XL	fuselage length

W fuselage width

ES engine separation

EC engine face to quarter chord

ED engine diameter

EL engine length

A.5.1.2. Menu 22 Susceptibility Features

JAM jammer number

IRCS RCS reduction level

IWARN RWR installed/not installed value

ICHAFF chaff dispenser installed/not installed value

A.5.1.3. Menu 23 Vulnerability Features

IFS general fuel system vulnerability value

IFV fuel/void interface vulnerability value

IFE fuel/engine interface vulnerability value

IEA engine arrangement vulnerability value

IEP engine protection vulnerability value

ICS control system vulnerability value

ICA crew arrangement vulnerability value

A.5.2. Menu 3 Combat Scenario

A.5.2.1. Menu 31 Mission Description

XMA mission loiter altitude

XMR mission radius of action

XMT mission time on station

A.5.2.2. Menu 32 Threat Definition

AAAH AAA threat density

AAAD AAA threat diameter

SAMH low altitude SAM threat density

SAMD low altitude SAM threat diameter

A.5.3. Menu 4 Susceptibility Assessment

A.5.3.1. Menu 41 Probability of Detection

PDSM P(d) by low altitude SAM

PDAR P(d) by AAA radar

PDAO P(d) by AAA optical

A.5.3.2. Menu 42 Probability of Hit

PHSM P(h) by low altitude SAM

PHR P(h) by AAA radar

PHO P(h) by AAA optical

A.5.4. Menu 5 Vulnerability Assessment

A.5.4.1. Menu 51 Vulnerable Area and Probability of Kill Given a Hit

VAAAA vulnerable area to AAA

PKHAAA P(k/h) by AAA

VASM vulnerable area to low altitude SAM

PKHSM P(k/h) by low altitude SAM

A.5.5. Menu 6 Survivability Assessment

A.5.5.1. Menu 61 Probability of Survival

PSSM P(s) vs. low altitude SAM

PSAR P(s) vs. AAA radar

PSAO P(s) vs. AAA optical

A.5.5.2. Menu 62 Sortie Analysis

ACR	number of aircraft in single sortie
XINPASS	number of targets attacked by aircraft per sortie
ACR2	number of aircraft ready for next sortie
TOTSR	total sorties flown
TOTACK	total targets attacked
TOTACL	total aircraft lost
TOTACR	total aircraft in repair at end
SORT	subroutine to perform sortie analysis

A.5.5.3. Menu 63 Campaign Analysis

ACR1	number of aircraft in campaign
XNPASS	number of targets attacked by aircraft in campaign
NSRT	number of raids in the campaign
NS	maximum number of sorties for repair

A.5.6. Menu 7 Reassessment

SRPDSM	subroutine: P(d) by low altitude SAM
SRPHSM	subroutine: P(h) by low altitude SAM
SRVASM	subroutine: A(v) and P(k/h) vs. low altitude SAM
SRPHR	subroutine: P(h) by AAA radar
SRPHO	subroutine: P(h) by AAA optical
SRVAAA	subroutine: A(v) and P(k/h) vs. AAA
CAMP	subroutine to perform campaign assessment

A.5.7. Menu 8 Plotting Routine

N	counter for maximum of three plot values
PKSM	P(k) vs. low altitude SAM array

PKAR	P(k) vs. AAA radar
PKAO	P(k) vs. AAA optical

A.5.8. Other/Miscellaneous

I1	single digit integer input
I2	two digit integer input
V1	real number input
IJK	integer to prevent auto-scroll
KK	general commands comparison array
K1	Main Menu comparison array
K2	Menu 2 comparison array
K3	Menu 3 comparison array
K4	Menu 4 comparison array
K5	Menu 5 comparison array
K6	Menu 6 comparison array
JJ	Menu 8 comparison array
K1Q-K9Q	branch command variables
SRFA	subroutine: alertion factor
SRFC	subroutine: chaff factor
SSRWT	subroutine: take off gross weight

A.6. SUPPLT

XO	X-axis points array
YO	lower Y-axis values
Y1	Baseline Design P(k)'s array
Y2	1st Design P(k)'s array

Y3	2nd Design P(k)'s array
IPKRAY	Legend text array
LABEL	X-axis labels array

APPENDIX B

SAMPLE INSTRUCTION MANUAL AND ASSESSMENTS

AE 3251

AIRCRAFT COMBAT SURVIVABILITY

AIRCRAFT SURVIVABILITY DESIGN AND ASSESSMENT

USING THE

VOUGHT INTERACTIVE SURVIVABILITY ASSESSMENT PROGRAM

(VISAP)

NAVAL POSTGRADUATE SCHOOL

MONTEREY, CALIFORNIA

INTRODUCTION

The VISAP (Vought Interactive Survivability Assessment Program) was developed at NPS to introduce the student to the survivability decisions and design tradeoffs confronting the designer/analyst of conceptual aircraft. Three specific aircraft types are examined, a Fighter Escort, a Long Range Strike aircraft, and a Close Air Support aircraft. The student is presented with several aircraft performance and design features, potential threats, and vulnerability/susceptibility parameters from which to choose for each aircraft type. Having established a baseline design (either through the default values or by individual design), the student can easily assess the effects of changing one or more design or mission descriptive parameters.

Several measures of the aircraft design's survivability are presented. These include probability of detection (P(d)), probability of hit (P(h)), and the probability of survival (P(d)) against a particular threat for each of the three types of aircraft analyzed. Comparisons of the effectiveness of each design can be obtained through repeated use of the SORTIE and CAMPAIGN analysis models incorporated in the programs. Graphs, of three designs each, may also be obtained for comparison of results.

All required inputs for the analysis are made at a computer terminal. Real time results will appear at the terminal, and hard copy results of each analysis can be sent to the on line printer. Subsequently, plots of loss rate, P(k), versus the threat types for each aircraft can be processed at an IBM 3277/Tektronix 618 dual screen terminal. throughout the analysis, default values are used for all calculations unless corrected or updated by the user.

INSTRUCTIONS

You will need the following items to estimate the survivability and effectiveness of your designs for the three types of aircraft:

1. A computer user number.
2. The ability to LOG ON and operate the IBM 3033 VM system from a a terminal.
3. This set of instructions.

The completion of the following instructions causes the VISAP program to execute. VISAP is an interactive program and is self explanatory. Please read the instructions given on the screen carefully. Failure to do so may invalidate your results and terminate the program. Please be sure to enter all variables in the format requested. You are to complete a design evaluation for each type of aircraft. The "HELP" Menus will give you useful information about the program execution and the methodology. It is recommended that you design the Fighter Escort Aircraft (ESCORT) first. It contains the most detail.

In order to access VISAP you must complete the following steps:

1. Turn the terminal on using the red toggle or pull switch on the left hand side.
2. Depress alternately the "RESET" AND "ENTER" keys until the terminal screen is cleared and the message, "CP READ", appears.
3. Enter "L XXXXP", where XXXX refers to your user number (Do not omit the blank space).

4. Enter your password.
5. Enter "CP LINK ++++P 191 195 RR", where ++++ is the user's number on whose disk the programs reside (again do not omit blank spaces).
6. Enter the password "SAP".
7. Enter "ACC 199 B".
8. Enter "VISAP". This calls the exec.
9. Choose and enter one of the aircraft types: "ESCORT", "STRIKE", or "SUPPORT".
10. After you have completed your analysis of one aircraft type, you may design another type by exiting the program and then reentering "VISAP" and choosing another type. Requesting printed results of the assessment(s) for each type can be retrieved after you exit that type.

To obtain graphs, you must utilize an IBM 3277/Tektronix 618 dual screen terminal. Follow the VISAP accession procedures, listed above, for steps 1 - 7 as before, then:

8. Enter "DISVIS". This accesses the DISSPLA programs.
9. Choose and enter one of the following: "ESCPLT", "STRPLT", or "SUPPLT" for the Escort, Strike, or Support type aircraft respectively.
10. Push the "HARD COPY" key beneath the large screen for a printout.
11. After receiving a plot for one type of aircraft, you may obtain others by pressing the "ENTER" key and reentering "DISVIS".

TASKS

You are to complete the following tasks:

1. For each type of aircraft conduct a "BASELINE" (no survivability enhancement features) assessment using the default values.
2. For each type of aircraft, select the survivability features that you want. Then conduct an assessment of that design. What is the weight penalty and how many aircraft are saved in the campaign?
3. For one type of aircraft do a sensitivity study on any three features.

   Examples:

   (a) What is the effect of jammer power on the results?

   (b) What is the effect of wing loading on the results?

   (c) What is the effect of the fuel system vulnerability reduction on the results?

   Use the plotting procedure to present your results.
4. Comment on whether your studies agree with the theory that you learned in class. Why or why not?
5. Please note any errors or difficulties that you encounter.

ESCORT INITIAL INPUTS

The following mission, aircraft, and threat parameters are used to conduct the "ESCORT" assessment:

1. Aircraft performance indicators:
   - (a) Thrust to Weight 1.0
   - (b) Wing Loading ..... 70.0 lb/sq ft
   - (c) Ordnance Weight ..... 4000.0 lbs
2. Mission Description:
   - (a) Mission Dash Altitude ..... 10,000.00 ft
   - (b) Mission Dash Mach 0.8
   - (c) Mission Dash Distance ..... 75 miles
3. Threat Definition:
   - (a) Air-to-Air Threat Density ..... 0.01 wpns/sq mi
   - (b) Air-to-Air Threat Diameter ..... 2.0 miles
   - (c) Air-to-Air Penetration Distance ..... 150.0 miles
   - (d) Low Altitude SAM Threat Density ..... 0.0017 wpns/sq mi
   - (e) Low Altitude SAM Threat Diameter ..... 20.0 miles
   - (f) Low Altitude SAM Penetration Distance .. 75.0 miles
4. Sortie and Campaign Analysis:
   - (a) Initial Number of Aircraft 100
   - (b) Number of Raids in Campaign 20
   - (c) Number of Passes per Sortie 1
   - (d) Number of Sorties for Repair 4

STRIKE INITIAL INPUTS

The following Mission, Aircraft, and Threat parameters are used to conduct the "STRIKE" assessment:

1. Aircraft Performance Indicators:
   - (a) Thrust to Weight 1.0
   - (b) Wing Loading ..... 105.0 lb/sq ft
   - (c) Ordnance Weight ..... 4000.0 lbs
2. Missions Description:
   - (a) Mission Penetration Distance ..... 200.0 miles
   - (b) Mission Penetration Altitude ..... 40000.0 ft
   - (c) Mission Penetration Mach 1.8
3. Threat Definition:
   - (a) Air-to-Air Threat Density ..... 0.01 wpns/sq mi
   - (b) Air-to-Air Threat Diameter ..... 4.0 miles
   - (c) High Altitude SAM Threat Density ..... 0.0017 wpns/sq mi
   - (d) High Altitude SAM Threat Diameter ..... 20.0 miles
4. Sortie and Campaign Analysis:
   - (a) Initial Number of Aircraft 100
   - (b) Number of Raids in Campaign 20
   - (c) Number of Passes per Sortie 1
   - (d) Number of Sorties for Repair 4

SUPPORT INITIAL INPUTS

The following Mission, Aircraft, and Threat Parameters are used to conduct the "SUPPORT" assessment:

1. Aircraft Performance Indicators:
   - (a) Thrust to Weight 0.55
   - (b) Wing Loading ..... 90.0 lb/sq ft
   - (c) Ordnance Weight ..... 8000.0 lbs
2. Mission Description:
   - (a) Mission Radius of Action ..... 150.0 miles
   - (b) Mission Loiter Altitude ..... 10000.0 ft
   - (c) Mission Time on Station ..... 60.0 min
3. Threat Definition:
   - (a) AAA Threat Density ..... 0.01 wpns/sq mi
   - (b) AAA Threat Diameter ..... 3.0 miles
   - (c) Low Altitude SAM Threat Density ..... 0.0017 wpns/sq mi
   - (d) Low Altitude SAM Threat Diameter ..... 20.0 miles
4. Sortie and Campaign Analysis:
   - (a) Initial Number of Aircraft 100
   - (b) Number of Raids in Campaign 20
   - (c) Number of Passes per Sortie 1
   - (d) Number of Sorties for Repair 4

FIGHTER ESCORT AIRCRAFT

Loss Rate VS. Threat Type



Figure 2. Sample Escort Plot

** FIGHTER ESCORT AIRCRAFT **

* PERFORMANCE FEATURES

THRUST TO WEIGHT	1.00	WING LOADING	70.00
ORDNANCE WEIGHT	4000.00		

* MISSION PARAMETERS

DASH ALTITUDE	10000.00
DASH MACH NBR.	0.80
DASH DISTANCE	75.00

* THREAT PARAMETERS

A/A DENSITY	0.01
A/A DIAMETER	2.00
A/A PENETRATION DIST	150.00
SAM DENSITY	0.00
SAM DIAMETER	20.00
SAM PENETRATION DIST	75.00

* SUSCEPTIBILITY REDUCTION FEATURES

JAMMER NUMBER	0
RCS REDUCTION LEVEL	0
RADAR WARNING RECEIVER	0
CHAFF DISPENSER	0
IR JAMMER	0
IR FLARE DISPENSER	0
IR SUPPRESSION TECHNIQUE	0

* VULNERABILITY REDUCTION FEATURES

FUEL SYSTEM GENERAL	1
FUEL/VOID INTERFACE	1
FUEL/ENGINE INTERFACE	1
ENGINE ARRANGEMENT	1
ENGINE PROTECTION	1
CONTROL SYSTEM	1
CREW ARRANGMENT	1

* SURVIVABILITY ASSESSMENT:

	P(S)	P(D)	P(H)	P(K/H)
VS A/A GUNS	0.86	1.00	0.86	0.17
VS A/A MISS	0.73	1.00	0.41	0.68
VS SAM	0.80	1.00	0.20	0.99

* CAMPAIGN ANALYSIS:

INITIAL A/C	100.	NUMBER OF RAIDS	20
PASSES/SORTIE	1.	SORTIES FOR REPAIR	4
A/C READY	43.	TOTAL SORTIES	1294.
TOTAL TARGETS	1233.	TOTAL A/C LOST	49.
IN REPAIR	8.		

BASELINE TOGW 47932.01 ENHANCED TOGW 47932.01

Figure 3. Sample Escort Baseline Output



** FIGHTER ESCORT AIRCRAFT **

* PERFORMANCE FEATURES

THRUST TO WEIGHT	1.20	WING LOADING	70.00
ORDNANCE WEIGHT	4000.00		

* MISSION PARAMETERS

DASH ALTITUDE	15000.00
DASH MACH NBR.	0.80
DASH DISTANCE	75.00

* THREAT PARAMETERS

A/A DENSITY	0.02
A/A DIAMETER	2.00
A/A PENETRATION DIST	150.00
SAM DENSITY	0.00
SAM DIAMETER	20.00
SAM PENETRATION DIST	75.00

* SUSCEPTIBILITY REDUCTION FEATURES

JAMMER NUMBER	5
RCS REDUCTION LEVEL	0
RADAR WARNING RECEIVER	0
CHAFF DISPENSER	0
IR JAMMER	0
IR FLARE DISPENSER	0
IR SUPPRESSION TECHNIQUE	0

* VULNERABILITY REDUCTION FEATURES

FUEL SYSTEM GENERAL	8
FUEL/VOID INTERFACE	1
FUEL/ENGINE INTERFACE	1
ENGINE ARRANGEMENT	1
ENGINE PROTECTION	1
CONTROL SYSTEM	1
CREW ARRANGMENT	1

* SURVIVABILITY ASSESSMENT:

	P(S)	P(D)	P(H)	P(K/H)
VS A/A GUNS	0.87	1.00	0.86	0.15
VS A/A MISS	0.73	1.00	0.40	0.67
VS SAM	0.92	0.95	0.09	0.93

* CAMPAIGN ANALYSIS:

INITIAL A/C	100.	NUMBER OF RAIDS	20
PASSES/SORTIE	1.	SORTIES FOR REPAIR	4
A/C READY	31.	TOTAL SORTIES	1065.
TOTAL TARGETS	976.	TOTAL A/C LOST	57.
IN REPAIR	12.		

BASELINE TOGW 51861.88 ENHANCED TOGW 56990.67

Figure 4. Sample Escort 1st Design Output

** FIGHTER ESCORT AIRCRAFT **

* PERFORMANCE FEATURES

THRUST TO WEIGHT	1.20	WING LOADING	80.00
ORDNANCE WEIGHT	10000.00		

* MISSION PARAMETERS

DASH ALTITUDE	15000.00
DASH MACH NBR.	1.20
DASH DISTANCE	100.00

* THREAT PARAMETERS

A/A DENSITY	0.02
A/A DIAMETER	5.00
A/A PENETRATION DIST	100.00
SAM DENSITY	0.00
SAM DIAMETER	25.00
SAM PENETRATION DIST	100.00

* SUSCEPTIBILITY REDUCTION FEATURES

JAMMER NUMBER	5
RCS REDUCTION LEVEL	6
RADAR WARNING RECEIVER	1
CHAFF DISPENSER	1
IR JAMMER	1
IR FLARE DISPENSER	1
IR SUPPRESSION TECHNIQUE	2

* VULNERABILITY REDUCTION FEATURE

FUEL SYSTEM GENERAL	8
FUEL/VOID INTERFACE	6
FUEL/ENGINE INTERFACE	8
ENGINE ARRANGEMENT	2
ENGINE PROTECTION	2
CONTROL SYSTEM	5
CREW ARRANGMENT	6

* SURVIVABILITY ASSESSMENT:

	P(S)	P(D)	P(H)	P(K/H)
VS A/A GUNS	0.97	1.00	0.92	0.03
VS A/A MISS	0.93	1.00	0.17	0.42
VS SAM	1.00	0.10	0.00	0.29

* CAMPAIGN ANALYSIS:

INITIAL A/C	100.	NUMBER OF RAIDS	20
PASSES/SORTIE	1.	SORTIES FOR REPAIR	4
A/C READY	49.	TOTAL SORTIES	1202.
TOTAL TARGETS	1070.	TOTAL A/C LOST	22.
IN REPAIR	29.		

BASELINE TOGW 57463.81 ENHANCED TOGW 84619.50

Figure 5. Sample Escort 2nd Design Output

LONG RANGE STRIKE AIRCRAFT

Loss Rate VS. Threat Type



Figure 6. Sample Strike Plot



** LONG RANGE STRIKE AIRCRAFT **

* PERFORMANCE FEATURES

THRUST TO WEIGHT	1.00	WING LOADING	105.00
ORDNANCE WEIGHT	4000.00		

* MISSION PARAMETERS

PENETRATION DISTANCE	200.00
PENETRATION ALTITUDE	40000.00
PENETRATION MACH NBR.	1.80

* THREAT PARAMETERS

A/A DENSITY	0.01
A/A DIAMETER	4.00
SAM DENSITY	0.00
SAM DIAMETER	20.00

* SUSCEPTIBILITY REDUCTION FEATURES

JAMMER NUMBER	0
RCS REDUCTION LEVEL	0
RADAR WARNING RECEIVER	0
CHAFF DISPENSER	0

* VULNERABILITY REDUCTION FEATURES

FUEL SYSTEM GENERAL	1
FUEL/VOID INTERFACE	1

* SURVIVABILITY ASSESSESSMENT:

	P(S)	P(D)	P(H)	P(K/H)
VS A/A MISSILE	0.01	0.99	1.00	1.00
VS HIGH ALT SAM	0.10	0.99	0.91	1.00

* CAMPAIGN ANALYSIS:

INITIAL A/C	100.	NUMBER OF RAIDS	20
PASSES/SORTIE	1.	SORTIES FOR REPAIR	4
A/C READY	0.	TOTAL SORTIES	155.
TOTAL TARGETS	92.	TOTAL A/C LOST	100.
IN REPAIR	0.		

BASELINE TOGW 64071.66 ENHANCED TOGW 64071.66

Figure 7. Sample Strike Baseline Output

** LONG RANGE STRIKE AIRCRAFT **

* PERFORMANCE FEATURES

THRUST TO WEIGHT	1.20	WING LOADING	105.00
ORDNANCE WEIGHT	4000.00		

* MISSION PARAMETERS

PENETRATION DISTANCE	1000.00
PENETRATION ALTITUDE	40000.00
PENETRATION MACH NBR.	1.80

* THREAT PARAMETERS

A/A DENSITY	0.02
A/A DIAMETER	4.00
SAM DENSITY	0.00
SAM DIAMETER	20.00

* SUSCEPTIBILITY REDUCTION FEATURES

JAMMER NUMBER	5
RCS REDUCTION LEVEL	0
RADAR WARNING RECEIVER	0
CHAFF DISPENSER	0

* VULNERABILITY REDUCTION FEATURES

FUEL SYSTEM GENERAL	4
FUEL/VOID INTERFACE	1

* SURVIVABILITY ASSESSESSMENT:

	P(S)	P(D)	P(H)	P(K/H)
VS A/A MISSILE	0.25	0.76	1.00	0.98
VS HIGH ALT SAM	0.91	0.10	0.91	0.99

* CAMPAIGN ANALYSIS:

INITIAL A/C	100.	NUMBER OF RAIDS	20
PASSES/SORTIE	1.	SORTIES FOR REPAIR	4
A/C READY	0.	TOTAL SORTIES	113.
TOTAL TARGETS	35.	TOTAL A/C LOST	100.
IN REPAIR	0.		

BASELINE TOGW 146325.19 ENHANCED TOGW 159213.56

Figure 8. Sample Strike 1st Design Output

** LONG RANGE STRIKE AIRCRAFT **

* PERFORMANCE FEATURES

THRUST TO WEIGHT	1.20	WING LOADING	120.00
ORDNANCE WEIGHT	14000.00		

* MISSION PARAMETERS

PENETRATION DISTANCE	1000.00
PENETRATION ALTITUDE	60000.00
PENETRATION MACH NBR.	2.20

* THREAT PARAMETERS

A/A DENSITY	0.02
A/A DIAMETER	5.00
SAM DENSITY	0.00
SAM DIAMETER	25.00

* SUSCEPTIBILITY REDUCTION FEATURES

JAMMER NUMBER	5
RCS REDUCTION LEVEL	8
RADAR WARNING RECEIVER	1
CHAFF DISPENSER	1

* VULNERABILITY REDUCTION FEATURES

FUEL SYSTEM GENERAL	4
FUEL/VOID INTERFACE	6

* SURVIVABILITY ASSESSESSMENT:

	P(S)	P(D)	P(H)	P(K/H)
VS A/A MISSILE	0.74	0.76	0.40	0.88
VS HIGH ALT SAM	0.99	0.10	0.19	0.47

* CAMPAIGN ANALYSIS:

INITIAL A/C	100.	NUMBER OF RAIDS	20
PASSES/SORTIE	1.	SORTIES FOR REPAIR	4
A/C READY	0.	TOTAL SORTIES	221.
TOTAL TARGETS	153.	TOTAL A/C LOST	100.
IN REPAIR	0.		

BASELINE TOGW 200446.50 ENHANCED TOGW 224027.69

Figure 9. Sample Strike 2nd Design Output

CLOSE AIR SUPPORT AIRCRAFT

Loss Rate VS. Threat Type



Figure 10. Sample Support Plot



** CLOSE AIR SUPPORT AIRCRAFT **

* PERFORMANCE FEATURES

THRUST TO WEIGHT	0.55	WING LOADING	90.00
ORDNANCE WEIGHT	8000.00		

* MISSION PARAMETERS

RADIUS OF ACTION	150.00
LOITER ALTITUDE	10000.00
TIME ON STATION	60.00

* THREAT PARAMETERS

AAA DENSITY	0.01
AAA DIAMETER	3.00
SAM DENSITY	0.00
SAM DIAMETER	20.00

* SUSCEPTIBILITY REDUCTION FEATURES

JAMMER NUMBER	0
RCS REDUCTION LEVEL	0
RADAR WARNING RECEIVER	0
CHAFF DISPENSER	0

* VULNERABILITY REDUCTION FEATURES

FUEL SYSTEM GENERAL	1
FUEL/VOID INTERFACE	1
FUEL/ENGINE INTERFACE	1
ENGINE ARRANGEMENT	1
ENGINE PROTECTION	1
CONTROL SYSTEM	1
CREW ARRANGMENT	1

* SURVIVABILITY ASSESSMENT:

	P(S)	P(D)	P(H)	P(K/H)
VS AAA OPTICAL	0.94	1.00	0.14	0.45
VS AAA RADAR	0.59	1.00	0.90	0.45
VS SAM	0.38	1.00	0.13	1.00

* CAMPAIGN ANALYSIS:

INITIAL A/C	100.	NUMBER OF RAIDS	20
PASSES/SORTIE	1.	SORTIES FOR REPAIR	4
A/C READY	30.	TOTAL SORTIES	1103.
TOTAL TARGETS	1039.	TOTAL A/C LOST	65.
IN REPAIR	6.		

BASELINE TOGW 28945.09 ENHANCED TOGW 28945.09

Figure 11. Sample Support Baseline Output

** CLOSE AIR SUPPCRT AIRCRAFT **

* PERFORMANCE FEATURES

THRUST TO WEIGHT	0.65	WING LOADING	90.00
ORDNANCE WEIGHT	8000.00		

* MISSION PARAMETERS

RADIUS OF ACTION	300.00
LOITER ALTITUDE	10000.00
TIME ON STATION	60.00

* THREAT PARAMETERS

AAA DENSITY	0.02
AAA DIAMETER	3.00
SAM DENSITY	0.00
SAM DIAMETER	20.00

* SUSCEPTIBILITY REDUCTION FEATURES

JAMMER NUMBER	5
RCS REDUCTION LEVEL	0
RADAR WARNING RECEIVER	0
CHAFF DISPENSER	0

* VULNERABILITY REDUCTION FEATURES

FUEL SYSTEM GENERAL	8
FUEL/VOID INTERFACE	1
FUEL/ENGINE INTERFACE	1
ENGINE ARRANGEMENT	1
ENGINE PROTECTION	1
CONTROL SYSTEM	1
CREW ARRANGMENT	1

* SURVIVABILITY ASSESSMENT:

	P(S)	P(D)	P(H)	P(K/H)
VS AAA OPTICAL	0.94	1.00	0.14	0.44
VS AAA RADAR	0.61	1.00	0.89	0.44
VS SAM	0.99	0.97	0.01	0.98

* CAMPAIGN ANALYSIS:

INITIAL A/C	100.	NUMBER OF RAIDS	20
PASSES/SORTIE	1.	SORTIES FOR REPAIR	4
A/C READY	97.	TOTAL SORTIES	1975.
TOTAL TARGETS	1974.	TOTAL A/C LOST	3.
IN REPAIR	0.		

BASELINE TOGW 32200.62 ENHANCED TOGW 34886.78

Figure 12. Sample Support 1st Design Output



** CLOSE AIR SUPPCRT AIRCRAFT **

* PERFORMANCE FEATURES

THRUST TO WEIGHT	0.65	WING LOADING	100.00
ORONANCE WEIGHT	10000.00		

* MISSION PARAMETERS

RADIUS OF ACTION	300.00
LCITER ALTITUCE	9000.00
TIME ON STATICN	120.00

* THREAT PARAMETERS

AAA DENSITY	0.02
AAA DIAMETER	5.00
SAM DENSITY	0.00
SAM DIAMETER	25.00

* SUSCEPTIBILITY REDUCTICN FEATURES

JAMMER NUMBER	5
RCS REDUCTION LEVEL	3
RADAR WARNING RECEIVER	1
CHAFF DISPENSER	1

* VULNERABILITY REDUCTION FEATURES

FUEL SYSTEM GENERAL	8
FUEL/VCID INTERFACE	6
FUEL/ENGINE INTERFACE	8
ENGINE ARRANGEMENT	2
ENGINE PROTECTION	2
CONTROL SYSTEM	5
CREW ARRANGMENT	6

* SURVIVABILITY ASSESSMENT:

	P(S)	P(D)	P(H)	P(K/H)
VS AAA OPTICAL	C.98	1.00	0.14	C.11
VS AAA RADAR	C.90	1.00	0.90	0.11
VS SAM	C.96	0.94	0.21	0.18

* CAMPAIGN ANALYSIS:

INITIAL A/C	10C.	NUMBER OF RAIDS	20
PASSES/SORTIE	1.	SORTIES FOR REPAIR	4
A/C READY	72.	TOTAL SORTIES	1632.
TOTAL TARGETS	1583.	TOTAL A/C LCST	18.
IN REPAIR	11.		

BASELINE TCGW 40858.48 ENHANCED TCGW 46643.16

Figure 13. Sample Support 2nd Design Output

APPENDIX C

FLOW CHARTS



Figure 14. External Program Flow Chart



Figure 15. Internal Program Flow Chart

```
C*************************************************************************
C**                                                                     **
C**      CMS EXEC TO CONTROL VISAP OPERATION                            **
C**                                                                     **
C*************************************************************************
GLOBAL TXTLIB CMSLIB FORTMOD2 MOD2EEH NONIMSL IMSLSP
FILEDEF 01 DISK ESCORT DATA
FILEDEF 02 DISK STRIKE DATA
FILEDEF 03 DISK SUPPORT DATA
FILEDEF 04 TERMINAL
FILEDEF 06 PRINTER
FILEDEF 07 DISK ESCPLT DATA
FILEDEF 08 DISK STRPLT DATA
FILEDEF 09 DISK SUPPLT DATA
&TYPE ENTER STRIKE, ESCORT, OR SUPPORT
&READ VARS &1
LOAD &1 (START
&END
```

```
C*************************************************************************
C**                                                                     **
C**      CMS EXEC TO CONTROL PLOTTING REQUESTS                          **
C**                                                                     **
C*************************************************************************
GLOBAL TXTLIB CMSLIB FORTMOD2 MOD2EEH NONIMSL IMSLSP
FILEDEF 07 DISK ESCPLT DATA
FILEDEF 08 DISK STRPLT DATA
FILEDEF 09 DISK SUPPLT DATA
&TYPE ENTER STRPLT, ESCPLT, OR SUPPLT
&READ VARS &1
EXEC DISSPLA &1 (START
&END
```

```
C*****************************************************************************
C**                                                                         **
C**      ESCORT                                                             **
C**      PROGRAM TO ASSESS FIGHTER ESCORT AIRCRAFT SURVIVABILITY**          **
C**                                                                         **
C*****************************************************************************
C
C           FIGHTER ESCORT
C
C  THESE LINE NUMBERS ARE FOR EASY REFERENCE
C           MAIN MENU                          1, 100, 100%
C           AIRCRAFT DESIGN SELECTION           2, 110, 1110
C               A/C PERFORMANCE INDICATORS     21, 210, 1210
C               SUSCEPTIBILITY FEATURES        22, 220, 1220
C                    JAMMERS 221  RCS 222  RWR 223
C                    CHAFF 224 IRJAM 225 IRFLAR 226 IRSUP 227
C               VULNERABILITY FEATURES         23, 230, 1230
C           COMBAT SCENARIO SELECTION           3, 120, 1120
C               MISSION PROFILE                31, 310, 1310
C               THREAT SELECTION               32, 320, 1320
C           SUSCEPTIBILITY ASSESMENT            4, 130, 1130
C               PROBABILITY OF DETECTION       41, 410, 1410
C               PROBABILITY OF HIT             42, 420, 1420
C                    VS A/A GUN                   421
C                    VS A/A IR MISSILE            422
C                    VS LOW ALT SAM               423
C           VULNERABILITY ASSESMENT          5, 140, 1140
C                    VS A/A GUN                   510
C                    VS A/A IR MISSILE            520
C                    VS SAM                       530
C           SURVIVABILITY ASSESMENT             6, 150, 1150
C               P(S) 1:1 A/A GUN                 610, 618
C               P(S) 1:1 A/A IR MISSILE          620, 628
C               P(S) 1:1 LOW ALT SAM             630, 638
C               SINGLE SORTIE                    640, 1640
C               CAMPAIGN EVALUATION              650, 1650
C           HELP                                 997X
C           TRANFER                              998
C           EXIT                                 999
C
      IMPLICIT REAL*4(A-H,O-Z),INTEGER*4(I-N)
C
      DIMENSION KK(4),K1(6),K2(3),K3(2),K4(2),K5(3),K6(5),
C- #5 ------------------------------------------------------------------
     *          JJ(2),PKAG(3),PKAM(3),PKSM(3)
C
      DATA K1/'DE','MS','SA','VA','SV','MM'/
      DATA K2/'AP','SF','VF'/
```

```
      DATA K3/'MP','TH'/
      DATA K4/'PD','PH'/
      DATA K5/'KG','KM','KD'/
      DATA K6/'AG','AM','LS','SS','CE'/
      DATA KK/'HP','TN','EX','RT'/
C- #5 ------------------------------------------------------------------
      DATA JJ/'Y','N'/
C- #3 ------------------------------------------------------------------
C************ TO SAVE DATA ***************************************
      CALL FRTCMS('CLRSCRN ')
      WRITE(4,1010)
1010  FORMAT(' ','DATA MODE SELECTION, ENTER A CODE AS FOLLOWS:'//
     *T6,'IF THIS IS YOUR FIRST TIME THRCUGH ESCORT OR IF YOU WISH'/
     *T6,'TO USE THE DEFAULT VALUES/PARAMETERS ENTER...0 '//
     *T6,'TO USE DATA SAVED FROM YOUR LAST RUN ENTER...1 '///
     *T20,'WARNING'//
     *T6,'--DO NOT ENTER 1 IF THIS IS YOUR FIRST RUN OR IF YOU HAVE'/
     *T6,'ERASED YOUR ESCORT DATA FILE FROM YOUR DISK--'/)
      READ(4,1011)I1
1011  FORMAT(I1)
      IF(I1.EQ.0)GO TO 1021
      IF(I1.EQ.1)GO TO 1022
1022  CONTINUE
      REWIND 1
      READ(1,1012)TW,WS,WT,B,XL,W,EC,ED,EL,DL,JAM,IRCS,IWARN,ICHAFF,
     *       IRJAM,IRFLAR,IRSUP,IFS,
     *       IFV,IFE,IEA,IEP,ICS,ICA,XMDA,XMDM,XMDD,AAH,AAD,AAL,SAMH,
     *       SAMD,SAML,PDAAG,PDAAM,PDSM,PHG,PHM,PHSM,APAAG,AVAAG,
     *       PKHAAG,AVAAM,PKHAAM,VASM,PKHSM,
     *       PSAG,PSAM,PSSM,ACR,ACRI,NSRT,
     *       XNPASS,NS,ACR2,TOTSR,TOTACK,TOTACL,TOTACR,BLTOGW,TOGW
1012  FORMAT(' ',5G12.4)
      GO TO 1
C*****************************************************************
1021  CONTINUE
      DATA TW/1./,WS/70./,WT/4000./,B/26./,XL/36./,W/5.5/,EC/5.5/,ED/2.0
     &/, EL/11./,DL/8./
      DATA JAM/0/,IRCS/0/,IWARN/0/,ICHAFF/0/,IRJAM/0/,IRFLAR/0/,IRSUP/0/
      DATA IFS/1/,IFV/1/,IFE/1/,IEA/1/,IEP/1/,ICS/1/,ICA/1/
      DATA XMDA/1CCOC./,XMDM/.8/,XMDD/75./
      DATA AAH/.01/,AAD/2./,AAL/150./,SAMH/.0017/,SAMD/20./,SAML/75./
      DATA PDAAG/1./,PDAAM/1./,PDSM/.9988/
      DATA PHG/.8625/,PHM/.4052/,PHSM/.2/
      DATA APAAG/604./,AVAAG/100./,PKHAAG/.1657/,AVAAM/408./,
     &PKHAAM/.675/,VASM/600./,PKHSM/.9934/
      DATA PSAG/.8571/,PSAM/.7265/,PSSM/.8316/
      DATA ACR/100./
C- #3 ------------------------------------------------------------------
```

```
      DATA ACR1/100./,NSRT/20/,XNPASS/1./,NS/4/
      DATA ACR2/43.25/,TOTSR/1293.62/,TOTACK/1232.79/,TOTACL/48.71/
      DATA TOTACR/8.04/,BLTOGW/47932.01/,TOGW/47932.01/
C- #5 ------------------------------------------------------------------
      DATA N/0/
C*****************************************************************
C     MAIN MENU DISPLAY
C*****************************************************************
100       CONTINUE
1         CONTINUE
          CALL FRTCMS('CLRSCRN ')
      WRITE(4,1001)
1001  FORMAT(' ',' ESCORT MENU (1) SELECT A CODE AS FOLLOWS:'//
     +T6,'FOR AN EXPLANATION              ',T41,'HP'/
     +T6,'AIRCRAFT DESIGN SELECTION       ',T41,'DE'/
     +T6,'COMBAT SCENARIO SELECTION       ',T41,'MS'/
     +T6,'SUSCEPTIBILITY ASSESSMENT       ',T41,'SA'/
     +T6,'VULNERABILITY ASSESSMENT        ',T41,'VA'/
     +T6,'SURVIVABILITY ASSESSMENT        ',T41,'SV'/
     +T6,'TO TRANSFER TO OTHER MENUS      ',T41,'TN'/
     +T6,'TO EXIT OR PRINT RESULTS        ',T41,'EX'/)
      READ(5,2000) K1C
2000  FORMAT(A4)
      IF(K1C.EQ.K1(1)) GO TO 110
      IF(K1C.EQ.K1(2)) GO TO 120
      IF(K1C.EQ.K1(3)) GO TO 130
      IF(K1C.EQ.K1(4)) GO TO 140
      IF(K1C.EQ.K1(5)) GO TO 150
      IF(K1C.EQ.KK(1)) GO TO 9971
      IF(K1C.EQ.KK(2)) GO TO 998
C- #3 ------------------------------------------------------------------
      IF(K1C.EQ.KK(3)) GO TO 1061
      WRITE(4,1200)
1200  FORMAT(' ',' INPUT ERROR. REPEAT INPUT')
      GO TO 1
C*****************************************************************
C     MENU 2  DESIGN
C*****************************************************************
110       CALL FRTCMS('CLRSCRN ')
2         CONTINUE
      WRITE(4,1110)
1110  FORMAT(' ',' MENU (2) DESIGN,  ENTER  A CODE AS FOLLOWS:'//
     +T6,'FOR AN EXPLANATION              ',T51,'HP'/
     +T6,'A/C PERFORMANCE INDICATORS      ',T51,'AP'/
     +T6,'SUSCEPTIBILITY FEATURES         ',T51,'SF'/
     +T6,'VULNERABILITY FEATURES          ',T51,'VF'/
     +T6,'TO RETURN TO MENU (1)           ',T51,'RT'/
     +T6,'TO TRANSFER TO OTHER MENUS      ',T51,'TN'/)
```

```
      READ(5,2000) K2Q
      IF(K2C.EQ.K2(1)) GO TO 210
      IF(K2C.EQ.K2(2)) GO TO 220
      IF(K2Q.EQ.K2(3)) GO TO 230
      IF(K2Q.EQ.KK(1)) GO TO 9972
      IF(K2C.EQ.KK(2)) GO TO 998
C- #3 ------------------------------------------------------------------
      IF(K2Q.EQ.KK(4)) GO TO 7
      WRITE(4,120C)
      GO TO 2
C*************************************************************************
C     MENU 3  COMBAT SCENARIO
C*************************************************************************
120       CALL FRTCMS('CLRSCRN ')
3          CONTINUE
      WRITE(4,112C)
1120  FORMAT(' ',' MENU (3) COMBAT SCENARIO, ENTER  A CODE AS FOLLOWS:'//
     +T6,'FOR AN EXPLANATION            ',T51,'HP'/
     +T6,'MISSION PROFILE               ',T51,'MP'/
     +T6,'THREAT SELECTION              ',T51,'TH'/
     +T6,'TO RETURN TO MENU (1)         ',T51,'RT'/
     +T6,'TO TRANSFER TO OTHER MENUS    ',T51,'TN'/)
      READ(5,2000) K3Q
      IF(K3C.EC.K3(1)) GO TO 310
      IF(K3Q.EQ.K3(2)) GO TO 320
      IF(K3Q.EQ.KK(1)) GO TO 9973
      IF(K3Q.EQ.KK(2)) GO TO 998
C- #3 ------------------------------------------------------------------
      IF(K3Q.EQ.KK(4)) GO TO 7
      WRITE(4,120C)
      GO TO 3
C*************************************************************************
C MENU 4  SUSCEPTIBILITY ASSESSMENT
C*************************************************************************
130       CALL FRTCMS('CLRSCRN ')
4          CONTINUE
      WRITE(4,1130)
1130  FORMAT(' ',' MENU (4) SUSCEPTIBILITY ASSESSMENT'//
     *T6,'ENTER A CODE AS FOLLOWS:'//
     +T6,'FOR AN EXPLANATION            ',T41,'HP'/
     +T6,'PROBABILITY OF DETECTION      ',T41,'PD'/
     +T6,'PROBABILITY OF HIT            ',T41,'PH'/
     +T6,'TO RETURN TO MENU (1)         ',T41,'RT'/
     +T6,'TO TRANSFER TO OTHER MENUS    ',T41,'TN'/)
      READ(5,2000) K4Q
      IF(K4Q.EQ.K4(1)) GO TO 410
      IF(K4C.EQ.K4(2)) GO TO 420
      IF(K4Q.EQ.KK(1)) GO TO 9974
```

```
      IF(K4Q.EQ.KK(2)) GC TC 998
C- #3 ---------------------------------------------------------------
      IF(K4C.EQ.KK(4)) GC TC 7
      WRITE(4,120C)
      GO TO 4
C*****************************************************************
C  MENU 5  VULNERABILITY ASSESSMENT
C*****************************************************************
140       CALL FRTCMS('CLRSCRN ')
5         CONTINUE
      WRITE(4,114C)
1140  FORMAT(' ','MENU (5)  VULNERABILITY ASSESSMENT'//
     *T6,'ENTER A CODE AS FCLLOWS:'//
     +T6,'FOR AN EXPLANATION                ',T41,'HP'/
     +T6,'VULN AREA & P(K/H) VS A/A GUN     ',T41,'KG'/
     +T6,'VULN AREA & P(K/C) VS A/A MISSILE ',T41,'KM'/
     +T6,'VULN AREA & P(K/D) VS SAM         ',T41,'KD'/
     +T6,'TC RETURN TO MENU (1)             ',T41,'RT'/
     +T6,'TC TRANSFER TO OTHER MENUS        ',T41,'TN'//)
      READ(5,2000,ERR=1061) K5Q
      IF(K5C.EQ.K5(1)) GC TC 510
      IF(K5Q.EQ.K5(2)) GC TC 520
      IF(K5C.EQ.K5(3)) GC TO 530
      IF(K5Q.EQ.KK(1)) GC TC 9975
      IF(K5C.EQ.KK(2)) GO TO 998
C- #3 ---------------------------------------------------------------
      IF(K5C.EQ.KK(4)) GO TO 7
      WRITE(4,120C)
      GO TO 5
C*****************************************************************
C  MENU 6  SURVIVABILITY ASSESSMENT
C*****************************************************************
150       CALL FRTCMS('CLRSCRN ')
6         CONTINUE
      WRITE(4,1150)
1150  FORMAT(' ','MENU (6)  SURVIVABILITY ASSESSMENT'//
     *T6,'ENTER A CODE AS FCLLOWS:'//
     +T6,'FOR AN EXPLANATION                ',T41,'HP'/
     +T6,'P(S) 1:1 A/A (GUNS)               ',T41,'AG'/
     +T6,'P(S) 1:1 A/A (IR MISSILE)         ',T41,'AM'/
     +T6,'P(S) 1:1 LOW ALT SAM              ',T41,'LS'/
     +T6,'SINGLE SORTIE                     ',T41,'SS'/
     +T6,'CAMPAIGN EVALUATION               ',T41,'CE'/
     +T6,'TO RETURN TO MENU (1)             ',T41,'RT'/
     +T6,'TC TRANSFER TO OTHER MENUS        ',T41,'TN'//)
      READ(5,2000,ERR=1061) K6Q
      IF(K6C.EQ.K6(1)) GO TC 610
      IF(K6C.EQ.K6(2)) GO TO 620
```

```
      IF(K6Q.EQ.KK(3)) GO TO 630
      IF(K6Q.EQ.KK(4)) GO TO 640
      IF(K6Q.EQ.KK(5)) GO TO 650
      IF(K6Q.EQ.KK(1)) GO TO 9978
      IF(K6Q.EQ.KK(2)) GO TO 998
C- #3 ---------------------------------------------------------------------
      IF(K6C.EQ.KK(4)) GO TO 7
      WRITE(4,120C)
      GO TO 6
C
C- #3 ---------------------------------------------------------------------
C*************************************************************************
C**    MENU 7   REASSESSMENT                                            **
C*************************************************************************
    7 CONTINUE
      CALL ESRPDS(JAM,IRCS,PDSM)
      CALL ESRPHG(TW,WS,PHG)
      CALL ESRPHM(TW,WS,IRJAM,IRFLAR,IRSUP,PHM)
      CALL ESRPHS(IWARN,ICHAFF,XMDM,WS,PHSM)
      CALL ESRAVG(IFS,IFV,IFE,IEA,IEP,ICS,ICA,TW,WS,XMDA,XMDM,XMDD,WT,
     *            AVAAG,APAAG,PKHAAG)
      CALL ESRAVM(IFS,IFV,APAAG,AVAAM,PKHAAM)
      CALL ESRAVS(IFS,IFV,APAAG,VASM,PKHSM)
C
C
      PSAG = 1. - PDAAG * PHG * PKHAAG
      PSAM = 1. - PDAAM * PHM * PKHAAM
      PSSM = 1. - PDSM * PHSM * PKHSM
C
      CALL CAMP(AAL,AAH,AAD,PKHAAG,PSAG,AAL,AAH,AAD,PKHAAM,PSAM,
     *          SAML,SAMH,SAMD,PKHSM,PSSM,ACR1,NSRT,XNPASS,NS,
     *          ACR2,TCTSR,TCTACK,TOTACL,TCTACR)
C
      GO TO 1
C
C
C- #5 ---------------------------------------------------------------------
C*************************************************************************
C**    MENU (8)    ROUTINE TO GENERATE P(K) VALUES FOR PLOTTING          **
C*************************************************************************
    8 CONTINUE
      IF(N.GE.3) GO TO 999
      CALL FRTCMS('CLRSCRN ')
      WRITE(4,801)N
  801 FORMAT('1',' MENU(8) GRAPH CHOICES'//
     *       T6,'DO YOU WISH TO SAVE P(K) FOR THIS DESIGN?'/
     *       T6,'NOTE:  YOU HAVE ALREADY CHOSEN ',I1,' OF THE',
     *          ' 3 POSSIBLE DESIGNS'/T6,'FOR THIS PLOT.'//
```

```
     *       T6,'ENTER A CODE AS FOLLOWS:'/
     *       T6,'    TO SAVE P(K)',T51,'Y'/
     *       T6,'    DO NOT SAVE',T51,'N'/
     *       T6,'    FOR FURTHER EXPLANATION',T51,'HP')
C
      READ(4,2000)K8Q
         IF(K8Q.EQ.JJ(1)) GO TO 81
         IF(K8Q.EQ.JJ(2)) GO TO 999
         IF(K8Q.EQ.KK(1)) GO TO 8888
C
      WRITE(4,120C)
      GO TO 8
   81 CONTINUE
         N = N + 1
         PKAG(N) = 1. - PSAG
         PKAM(N) = 1. - PSAM
         PKSM(N) = 1. - PSSM
C
      IF(N.NE.3) GO TO 999
C
      WRITE(7,802)(PKAG(I),PKAM(I),PKSM(I),I=1,3)
  802 FORMAT(F4.2)
      GO TO 999
C*****************************************************************
C MENU 21   A/C PERFORMANCE INPUTS
C*****************************************************************
210      CALL FRTCMS('CLRSCRN ')
21        CONTINUE
      WRITE(4,121C)TW,WS,WT,B,XL,W,EC,ED,EL,DL
1210  FORMAT(' ',/      MENU (21) ENTER  A CODE AS FOLLOWS:'//
     +T16,'      A/C PERFORMANCE INDICATORS  '/
     +T6,'1    THRUST TO WEIGHT            ',T41,F6.4/
     +T6,'2    WING LOADING                ',T41,F6.2,' PSF'/
     +T6,'3    ORDNANCE WEIGHT             ',T41,F6.0,' LBS'/
     +T6,'     WING SPAN                   ',T41,F6.2,' FT'/
     +T6,'     FUSELAGE LENGTH             ',T41,F6.2,' FT'/
     +T6,'     FUSELAGE WIDTH              ',T41,F6.2,' FT'/
     +T6,'     ENGINE FACE TO QUARTER CORD',T41,F6.2,' FT'/
     +T6,'     ENGINE DIAMETER             ',T41,F6.2,' FT'/
     +T6,'     ENGINE LENGTH               ',T41,F6.2,' FT'/
     +T6,'     DUCT LENGTH                 ',T41,F6.2,' FT'//
     +T6,'VALUES 1,2, &3 ARE VARIABLE; TO CHANGE THEM ENTER ITS NUMBER I
     +N'/T6,'I1 FORMAT. ENTER 0 FOR NO CHANGE REQUIRED')
      READ(5,1211)I1
1211  FORMAT(I1)
      IF(I1.EQ.0) GO TO 110
      GO TO (211,212,213),I1
1212  WRITE(4,120C)
```

```
      GO TO 210
211       CONTINUE
          WRITE(4,1201)
1201      FORMAT(' ',' TW RANGE ALLOWED IS .80 TO 1.2'/
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
          READ(5,1202)V1
1202      FORMAT(F8.4)
          TW=V1
          GO TO 210
212       CONTINUE
          WRITE(4,1203)
1203      FORMAT(' ',' WS RANGE ALLOWED IS 60. TO 80.'/
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
          READ(5,1202)V1
          WS=V1
          GO TO 210
213       CONTINUE
          WRITE(4,1204)
1204      FORMAT(' ',' WT RANGE ALLOWED IS 5000. TO 10000.'/
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
          READ(5,1202)V1
          WT=V1
          GO TO 210
C*****************************************************************
C MENU 22  SUSCEPTIBILITY FEATURES
C*****************************************************************
220       CALL FRTCMS('CLRSCRN ')
22        CONTINUE
       WRITE (4,1220)JAM,IRCS,IWARN,ICHAFF,IRJAM,IRFLAR,IRSUP
1220   FORMAT(' ',' MENU (22) ENTER  A CODE AS FOLLOWS:'//
     +T16,'  SUSCEPTIBILITY REDUCTION FEATURES     '//
     +T6,'1   JAMMER NUMBER              ',T41,I1/
     +T6,'2   RCS REDUCTION LEVEL        ',T41,I1/
     +T6,'3   RADAR WARNING RECEIVER     ',T41,I1/
     +T6,'4   CHAFF DISPENSER            ',T41,I1/
     +T6,'5   IR JAMMER                  ',T41,I1/
     +T6,'6   IR FLARE DISPENSER         ',T41,I1/
     +T6,'7   IR SUPPRESSION TECHNIQUE',T41,I1//
     +T6,'"0" INDICATES NOT INSTALLED "1" INDICATES INSTALLED'//
     +T6,'TO CHANGE A VALUE ENTER ITS NUMBER IN I1 FORMAT'/
     +T6,'ENTER 0 FOR NO CHANGE REQUIRED')
       READ(5,1211)I1
       IF(I1.EQ.0) GO TO 110
       GO TO (221,222,223,224,225,226,227),I1
1229   WRITE(4,1200)
       GO TO 220
221       CONTINUE
          CALL FRTCMS('CLRSCRN ')
```

```
      WRITE(4,1221)
1221  FORMAT(' ',                JAMMERS AVAILABLE          '//
     +T6,'0                          00 ',/
     +T6,'1                          50 WATTS',/
     +T6,'2                         100 WATTS',/
     +T6,'3                         200 WATTS',/
     +T6,'4                         500 WATTS',/
     +T6,'5                        1000 WATTS',//
     +T6,'ENTER THE JAMMER NUMBER IN I1 FORMAT')
      READ(5,1211)I1
      JAM=I1
      GO TO 220
222   CONTINUE
      CALL FRTCMS('CLRSCRN ')
      WRITE(4,1222)
1222  FORMAT(' ',                RCS REDUCTION LEVELS       '//
     +T6,'0                        NO REDUCTION  ',/
     +T6,'1                        PROCEDURE 1',/
     +T6,'2                        PROCEDURE 1 & 2',/
     +T6,'3                        PROCEDURE 1 & 3',/
     +T6,'4                        PROCEDURE 1,3, & 5',/
     +T6,'5                        PROCEDURE 1,3,5, & 6',/
     +T6,'6                        PROCEDURE 1,4,5,6,7, & 8',//
     +T6,'ENTER THE DESIRED RCS LEVEL IN I1 FORMAT')
      READ(5,1211)I1
      IRCS=I1
      GO TO 220
223   CONTINUE
      WRITE(4,1223)
1223  FORMAT(' ',                RADAR WARNING RECEIVER     '//
     +T6,'"0" INDICATES NOT INSTALLED, "1" INDICATES INSTALLED'/
     +T6,'ENTER "0" OR "1" IN I1 FORMAT')
      READ(5,1211)I1
      IWARN=I1
      GO TO 220
224   CONTINUE
      WRITE(4,1224)
1224  FORMAT(' ',                CHAFF DISPENSER            '//
     +T6,'"0" INDICATES NOT INSTALLED, "1" INDICATES INSTALLED'/
     +T6,'ENTER "0" OR "1" IN I1 FORMAT')
      READ(5,1211)I1
      ICHAFF=I1
      GO TO 220
225   CONTINUE
      WRITE(4,1225)
1225  FORMAT(' ',                IR JAMMER                  '//
     +T6,'"0" INDICATES NOT INSTALLED, "1" INDICATES INSTALLED'/
     +T6,'ENTER "0" OR "1" IN I1 FORMAT')
```

```
            READ(5,1211)I1
            IRJAM=I1
            GO TO 220
  226       CONTINUE
            WRITE(4,1226)
 1226       FORMAT(' ','      IR FLARE DISPENSER                    '//
     +T6,'"0" INDICATES NOT INSTALLED, "1" INDICATES INSTALLED'/
     +T6,'ENTER "0" OR "1" IN I1 FORMAT')
            READ(5,1211)I1
            IRFLAR=I1
            GO TO 220
  227       CONTINUE
           CALL FRTCMS('CLRSCRN ')
            WRITE(4,1227)
 1227  FORMAT(' ','      SUPPRESSION TECHNIQUES AVAILABLE'//
     +T6,'0            NONE  ',/
     +T6,'1            AEROSOL DISPENSER',/
     +T6,'2            COLD PLUG',//
     +T6,'ENTER THE TECHNIQUE NUMBER IN I1 FORMAT')
            READ(5,1211)I1
            IRSUP=I1
            GO TO 220
C*************************************************************************
C MENU 23  VULNERABILITY FEATURES
C*************************************************************************
  230       CALL FRTCMS('CLRSCRN ')
  23        CONTINUE
       WRITE(4,1230)IFS,IFV,IFE,IEA,IEP,ICS,ICA
 1230  FORMAT(' ','      MENU (23) ENTER  A CODE AS FOLLOWS:'//
     +T16,'      VULNERABILITY  REDUCTION FEATURES  '//
     +T6,'1    FUEL SYSTEM GENERAL      ',T41,I1/
     +T6,'2    FUEL/VOID INTERFACE      ',T41,I1/
     +T6,'3    FUEL/ENGINE INTERFACE    ',T41,I1/
     +T6,'4    ENGINE ARRANGEMENT       ',T41,I1/
     +T6,'5    ENGINE PROTECTION        ',T41,I1/
     +T6,'6    CONTROL SYSTEM           ',T41,I1/
     +T6,'7    CREW ARRANGMENT          ',T41,I1//
     +T6,'"1" MINIMUM PROTECTION '/
     +T6,'TO CHANGE A VALUE ENTER ITS NUMBER IN I1 FORMAT'//
     +T6,'ENTER 0 FOR NO CHANGE REQUIRED')
       READ(5,1211)I1
       IF(I1.EQ.0) GO TO 110
       GO TO (231,232,233,234,235,236,237),I1
 1239  WRITE(4,1200)
       GO TO 230
  231       CONTINUE
           CALL FRTCMS('CLRSCRN ')
            WRITE(4,1231)
```

```
1231  FORMAT(' ',T6,'1     SINGLE SUMP TANK, NO SELF-SEALING  ',/
     +T6,'2     SINGLE SUMP TANK, WITH SELF-SEALING',/
     +T6,'3     DUAL SUMP TANKS , NO SELF-SEALING    ,   NO SEPARATION',/
     +T6,'4     DUAL SUMP TANKS , WITH SELF-SEALING  ,   NO SEPARATION',/
     +T6,'5     DUAL SUMP TANKS , EXTRA SELF-SEALING,    NO SEPARATION',/
     +T6,'6     DUAL SUMP TANKS , NO SELF-SEALING    , WITH SEPARATION',/
     +T6,'7     DUAL SUMP TANKS , WITH SELF-SEALING  , WITH SEPARATION',/
     +T6,'8     DUAL SUMP TANKS , EXTRA SELF-SEALING, WITH SEPARATION',//
     +T6,'ENTER THE PROTECTION NUMBER IN I1 FORMAT')
      READ(5,1211)I1
      IFS=I1
      GO TO 230
232   CONTINUE
     CALL FRTCMS('CLRSCRN ')
      WRITE(4,1232)
1232  FORMAT(' ',T6,'1     TANKS ADJACENT TO DRY BAYS, HIGH SURFACE TEMP',/
     +T6,'2     TANKS ADJACENT TO DRY BAYS WITH ELECTRICAL EQUIPMENT',/
     +T6,'3     TANKS ADJACENT TO DRY BAYS WITH INERTING EQUIPMENT   ',/
     +T6,'4     INTERNAL FOAM OR INERTING FOR TANK ULLAGES           ',/
     +T6,'5     EXTERNAL FOAM OR FIRE EXTINGUISHING FOR VOIDS        ',/
     +T6,'6     BOTH INTERNAL AND EXTERNAL PROTECTION 2 OR 4 & 3 OR 5',//
     +T6,'ENTER THE DESIRED PROTECTION LEVEL IN I1 FORMAT')
      READ(5,1211)I1
      IFV=I1
      GO TO 230
233   CONTINUE
     CALL FRTCMS('CLRSCRN ')
      WRITE(4,1233)
1233  FORMAT(' ',T6,'1     FUEL AROUND ENGINE                   ',/
     +T6,'2     FUEL AROUND ENGINE WITH PROTECTION   ',/
     +T6,'3     FUEL AROUND DUCTS                    ',/
     +T6,'4     FUEL AROUND DUCTS WITH PROTECTION    ',/
     +T6,'5     DUCTS AROUND FUEL                    ',/
     +T6,'6     DUCTS AROUND FUEL WITH PROTECTION    ',/
     +T6,'7     FUEL FORWARD OF ENGINE               ',/
     +T6,'8     POSITIVE FUEL/ENGINE SEPARATION      ',//
     +T6,'ENTER THE PROTECTION NUMBER IN I1 FORMAT')
      READ(5,1211)I1
      IFE=I1
      GO TO 230
234   CONTINUE
     CALL FRTCMS('CLRSCRN ')
      WRITE(4,1234)
1234  FORMAT(' ',T6,'1   ONE ENGINE, OR TWO ENGINES SEPARATED BY LESS THAN 2 FT',/
```

```
     +T6,'2    TWO ENGINES SEPARATED OVER 2 FT                ',//
     +T6,'ENTER THE DESCRIPTION NUMBER IN I1 FORMAT')
           READ(5,1211)I1
           IEA=I1
           GO TO 230
235        CONTINUE
          CALL FRTCMS('CLRSCRN ')
           WRITE(4,1235)
1235  FORMAT(' ',T          ENGINE PROTECTION          '//
     +T6,'1    NONE                                          ',/
     +T6,'2    WITH PROTECTION AND/OR OVER 6 FT OF SEPARATION',//
     +T6,'ENTER THE DESCRIPTION NUMBER IN I1 FORMAT')
           READ(5,1211)I1
           IEP=I1
           GO TO 230
236        CONTINUE
          CALL FRTCMS('CLRSCRN ')
           WRITE(4,1236)
1236  FORMAT(' ',T          CONTROL SYSTEM             '//
     +T6,'1    NO BACKUP - OVER 5 SINGLE POINT FAILURE (SPF) SITES',/
     +T6,'2    NO BACKUP - UNDER 5 SPF SITES',/
     +T6,'3    WITH BACKUP - OVER 5 SPF SITES    ',/
     +T6,'4    WITH BACKUP - UNDER 5 SPF SITES   ',/
     +T6,'5    NO SINGLE POINT FAILURE SITES ',/
     +T6,'ENTER THE DESCRIPTION NUMBER IN I1 FORMAT')
           READ(5,1211)I1
           ICS=I1
           GO TO 230
237        CONTINUE
          CALL FRTCMS('CLRSCRN ')
           WRITE(4,1237)
1237  FORMAT(' ',T          CREW ARRANGEMENT           '//
     +T6,'1    NO BOTTOM SHIELD FOR PILOT BY ARMOR OR EQUIPMENT',/
     +T6,'2    NO SIDE SHIELD FOR PILOT BY ARMOR OR EQUIPMENT',/
     +T6,'3    PARTIAL ARMOR PROTECTION WITH STANDOFF(FRONT AND/OR BOTTO
     &M)',/
     +T6,'4    PARTIAL ARMOR PROTECTION WITH NO STANDOFF(FRONT AND/OR BO
     &TTOM)',/
     +T6,'5    FULL ARMOR PROTECTION WITH STANDOFF (FRONT,BOTTOM, AND SI
     &DES)',/
     +T6,'6    FULL ARMOR PROTECTION WITH NO STANDOFF (FRONT,BOTTOM AND
     &SIDES)',//
     +T6,'ENTER THE DESCRIPTION NUMBER IN I1 FORMAT')
           READ(5,1211)I1
           ICA=I1
           GO TO 230
C*****************************************************************
C  MENU 31   MISSION DESCRIPTION
```

```
C*****************************************************************
310       CALL FRTCMS('CLRSCRN ')
31        CONTINUE
      WRITE(4,1310)XMDA,XMDM,XMDD
1310  FORMAT(' ','      MENU (31)                              '//
     +T6,'       MISSION DESCRIPTION          '//
     +T6,'1    MISSION DASH ALTITUDE    ',T41,F6.0,' FT.'/
     +T6,'2    MISSION DASH MACH        ',T41,F6.4,' MACH'/
     +T6,'3    MISSION DASH DISTANCE    ',T41,F6.0,' MILES'//
     +T6,'TO CHANGE THEM ENTER ITS NUMBER IN I1 FORMAT.'//
     +T6,' ENTER C FOR NO CHANGE REQUIRED')
      READ(5,1211)I1
      IF(I1.EQ.0) GO TO 120
      GO TO (311,312,313),I1
1319  WRITE(4,120C)
      GO TO 310
311       CONTINUE
          WRITE(4,1311)
1311      FORMAT(' ','      MISSION DASH ALT RANGE                  FT'//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
          READ(5,1202)V1
          XMDA=V1
          GO TO 310
312       CONTINUE
          WRITE(4,1312)
1312      FORMAT(' ','      MISSION DASH MACH RANGE 0.8 TO 1.2 MACH'//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
          READ(5,1202)V1
          XMDM=V1
          GO TO 310
313       CONTINUE
          WRITE(4,1313)
1313      FORMAT(' ','      MISSION DASH DISTANCE                   NM'//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
          READ(5,1202)V1
          XMDD=V1
          GO TO 310
C*****************************************************************
C MENU 32  THREAT DEFINITION
C*****************************************************************
320       CALL FRTCMS('CLRSCRN ')
32        CONTINUE
      WRITE (4,1320)AAH,AAD,AAL,SAMH,SAMD,SAML
1320  FORMAT(' ','      MENU (32)                              '//
     +T6,'       THREAT DEFINITION            '//
     +T6,'1    A/A THREAT DENSITY       ',T41,F6.4,' WP/SQ.MI.'/
     +T6,'2    A/A THREAT DIAMETER      ',T41,F6.2,' MI.'/
     +T6,'3    A/A PENETRATION DIST     ',T41,F6.2,' MI'/
```

```
     +T6,'4    SAM THREAT DENSITY       ',T41,F6.4,' WP/SQ.MI.'/
     +T6,'5    SAM THREAT DIAMETER      ',T41,F6.2,' MI'/
     +T6,'6    SAM PENETRATION DIST     ',T41,F6.2,' MI'//
     +T6,'TO CHANGE A VALUE ENTER ITS NUMBER IN I1 FORMAT.'//
     +T6,' ENTER 0 FOR NO CHANGE REQUIRED')
      READ(5,1211)I1
      IF(I1.EQ.0) GO TO 120
      GO TO (321,322,323,324,325,326),I1
1329  WRITE(4,1200)
      GO TO 320
321        CONTINUE
           WRITE(4,1321)
1321       FORMAT(' ',' A/A THREAT DENSITY RANGE 0.0 TO .02    '//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
           READ(5,1202)V1
           AAH=V1
           GO TO 320
322        CONTINUE
           WRITE(4,1322)
1322       FORMAT(' ',' A/A THREAT DIAMETER RANGE 0.0 TO 5.  '//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
           READ(5,1202)V1
           AAD=V1
           GO TO 320
323        CONTINUE
           WRITE(4,1323)XMDD
1323       FORMAT(' ',' A/A PENETRATION DIST RANGE 0.0 TO ',F6.0,
     +' MILES'//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
           READ(5,1202)V1
           AAL=V1
           GO TO 320
324        CONTINUE
           WRITE(4,1324)
1324       FORMAT(' ',' SAM THREAT DENSITY RANGE 0.0 TO .002  '//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
           READ(5,1202)V1
           SAMH=V1
           GO TO 320
325        CONTINUE
           WRITE(4,1325)
1325       FORMAT(' ',' SAM THREAT DIAMETER RANGE 0.0 TO 25.  '//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
           READ(5,1202)V1
           SAMD=V1
           GO TO 320
326        CONTINUE
           WRITE(4,1326)XMDD
```

```
1326      FORMAT(' ','      SAM PENETRATION DIST. RANGE 0.0 TO ',F6.0,
     +' MILES'//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
          READ(5,1202)V1
          SAML=V1
          GO TO 320
C*****************************************************************
C MENU 41  PROB OF DETECTION
C*****************************************************************
410       CALL FRTCMS('CLRSCRN ')
41         CONTINUE
       WRITE(4,1410)
1410   FORMAT(' ',' MENU (41) SELECT A CODE AS FOLLOWS:'//
     +T6,'FOR AN EXPLANATION              ',T41,'HP'/
     +T6,'P(D) VS A/A (GUNS)              ',T41,'AG'/
     +T6,'P(D) VS A/A (IR MISSILE)        ',T41,'AM'/
     +T6,'P(D) VS LOW ALTITUDE SAM        ',T41,'LS'/
     +T6,'TO RETURN TO MENU (4)           ',T41,'RT'/
     +T6,'TO TRANSFER TO OTHER MENUS      ',T41,'TN'/)
       READ(5,2000) K70
       IF(K70.EQ.K6(1)) GO TO 411
       IF(K70.EQ.K6(2)) GO TO 412
       IF(K70.EQ.K6(3)) GO TO 413
       IF(K70.EQ.KK(1)) GO TO 9976
       IF(K70.EQ.KK(2)) GO TO 998
       IF(K70.EQ.KK(4)) GO TO 130
       WRITE(4,1200)
       GO TO 41
C*****************************************************************
C      PD A/A GUNS
C*****************************************************************
411       CALL FRTCMS('CLRSCRN ')
       WRITE(4,1411)PDAAG
1411   FORMAT(' ',T6,'THE PROBABILITY OF DETECTION BY A/A (GUNS) IS '
     +,F6.4//T6,'TO CHANGE THIS VALUE ENTER 1'/
     +T6,' ENTER 0 FOR NO CHANGE REQUIRED')
       READ(5,1211)I1
       IF(I1.EQ.0) GO TO 410
       IF(I1.EQ.1) GO TO 1413
1419   WRITE(4,1200)
       GO TO 411
1413       CONTINUE
           WRITE(4,1417)
1417       FORMAT(' ','      PD  RANGE   0.0 TO 1.0     '//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
           READ(5,1202)V1
           PDAAG=V1
           GO TO 411
```

```
C*************************************************************************
C      PD A/A IR MISSILE
C*************************************************************************
412       CALL FRTCMS('CLRSCRN ')
      WRITE(4,1415)PDAAM
1415  FORMAT(' ',T6,'THE PROBABILITY OF DETECTION BY A/A (MISSILE) IS '
     +,F6.4//T6,'TO CHANGE THIS VALUE ENTER 1'/
     +T6,' ENTER 0 FOR NO CHANGE REQUIRED')
      READ(5,1211)I1
      IF(I1.EQ.0) GO TO 410
      IF(I1.EQ.1) GO TO 1416
1418  WRITE(4,1200)
      GO TO 412
1416       CONTINUE
           WRITE(4,1417)
           READ(5,1202)V1
           PDAAM=V1
           GO TO 412
C*************************************************************************
C      PD VS SAM
C*************************************************************************
413        CONTINUE
         CALL ESRPDS (JAM,IRCS,PDSM)
         CALL FRTCMS('CLRSCRN ')
1490  WRITE(4,1491)PDSM
1491  FORMAT(' ',T6,'THE COMPUTED PROBABILITY OF DETECTION BY LOW ALT SA
     +M (RADAR) IS ',F6.4//T6,'TO CHANGE THIS VALUE ENTER 1'/
     +T6,' ENTER 0 FOR NO CHANGE REQUIRED')
      READ(5,1211)I1
      IF(I1.EQ.0) GO TO 410
      IF(I1.EQ.1) GO TO 1492
1493  WRITE(4,1200)
      GO TO 1490
1492       CONTINUE
           WRITE(4,1417)
           READ(5,1202)V1
           PDSM=V1
           GO TO 1490
C*************************************************************************
C MENU 42   PROB OF HIT
C*************************************************************************
420       CALL FRTCMS('CLRSCRN ')
42         CONTINUE
      WRITE(4,1420)
1420  FORMAT(' ','MENU (42) SELECT A CODE AS FOLLOWS:'//
     +T6,'FOR AN EXPLANATION           ',T41,'HP'/
     +T6,'P(H) VS A/A (GUNS)           ',T41,'AG'/
     +T6,'P(H) VS A/A (IR MISSILE)     ',T41,'AM'/
```

```
     +T6,'P(H) VS LOW ALTITUDE SAM     ',T41,'LS'/
     +T6,'TO RETURN TO MENU (4)        ',T41,'RT'/
     +T6,'TO TRANSFER TO OTHER MENUS   ',T41,'TN'/)
      READ(5,2000) K8Q
      IF(K8Q.EQ.K6(1)) GO TO 421
      IF(K8Q.EQ.K6(2)) GO TO 422
      IF(K8Q.EQ.K6(3)) GO TO 423
      IF(K8Q.EQ.KK(1)) GO TO 9977
      IF(K8Q.EQ.KK(2)) GO TO 998
      IF(K8Q.EQ.KK(4)) GO TO 130
      WRITE(4,1200)
      GO TO 42
C*****************************************************************
C     PROB OF HIT A/A GUNS
C*****************************************************************
421   CONTINUE
        CALL ESRPHG(TW,WS,PHG)
1421    CALL FRTCMS('CLRSCRN ')
        WRITE (4,14911)PHG
14911 FORMAT(' ',T6,'THE COMPUTED PROBABILITY OF HIT BY A/A(GUNS) IS '
     +,F6.4//T6,'TO CHANGE THIS VALUE ENTER 1'/
     +T6,' ENTER 0 FOR NO CHANGE REQUIRED')
      READ(5,1211)I1
      IF(I1.EQ.0) GO TO 420
      IF(I1.EQ.1) GO TO 14212
14913 WRITE(4,1200)
      GO TO 1421
14212   CONTINUE
        WRITE(4,1497)
1497    FORMAT(' ',' PH  RANGE  0.0 TO 1.0  '//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
        READ(5,1202)V1
        PHG=V1
        GO TO 1421
C*****************************************************************
C     PROB OF HIT A/A MISSILE
C*****************************************************************
422   CONTINUE
        CALL ESRPHM(TW,WS,IRJAM,IRFLAR,IPSUP,PHM)
1422    CALL FRTCMS('CLRSCRN ')
        WRITE(4,14921)PHM
14921 FORMAT(' ',T6,'THE COMPUTED PROBABILITY OF HIT BY A/A (IR MISSILE
     +) IS ',F6.4//T6,'TO CHANGE THIS VALUE ENTER 1'/
     +T6,' ENTER 0 FOR NO CHANGE REQUIRED')
      READ(5,1211)I1
      IF(I1.EQ.0) GO TO 420
      IF(I1.EQ.1) GO TO 14222
14929 WRITE(4,1200)
```

```
      GO TO 1422
14222     CONTINUE
          WRITE(4,1497)
          READ(5,1202)V1
          PHM=V1
          GO TO 1422
C*************************************************************************
C     PROB OF HIT LOW ALT SAM
C*************************************************************************
423   CONTINUE
        CALL ESRFFS(IWARN,ICHAFF,XMDM,WS,PHSM)
1423    CALL FRTCMS('CLRSCRN ')
        WRITE (4,14923)PHSM
14923 FORMAT(' ',T6,'THE COMPUTED PROBABILITY OF HIT BY LOW ALTITUDE SA
     +M IS ',F6.4//T6,'TO CHANGE THIS VALUE ENTER 1'/
     +T6,' ENTER 0 FOR NO CHANGE REQUIRED')
        READ(5,1211)I1
        IF(I1.EQ.0) GO TO 420
        IF(I1.EQ.1) GO TO 14232
14933 WRITE(4,1200)
      GO TO 1423
14232     CONTINUE
          WRITE(4,1497)
          READ(5,1202)V1
          PHSM=V1
          GO TO 1423
C*************************************************************************
C MENU 51  VULN. AREA / P(K/H) VS A/A GUNS
C*************************************************************************
510   CONTINUE
        CALL ESRAVG(IFS,IFV,IFE,IEA,IEP,ICS,ICA,TW,WS,XMDA,XMDM,XMDD,WT,
     &AVAAG,APAAG,PKHAAG)
1511      CALL FRTCMS('CLRSCRN ')
          WRITE (4,1512)AVAAG,PKHAAG
1512  FORMAT(' ',T6,'VERSUS THE AIA-TO-AIR GUNS'/
     +T6,'THE COMPUTED VULNERABLE AREA VS IS ',T51,F6.0,' SQ.FT.'/
     +T6,'THE P(K/H) IS ',T51,F6.4,//
     +T6,'TO CHANGE THESE VALUES ENTER 1'/
     +T6,' ENTER 0 FOR NO CHANGE REQUIRED')
        READ(5,1211)I1
        IF(I1.EQ.0) GO TO 140
        IF(I1.EQ.1) GO TO 1513
1514  WRITE(4,1200)
      GO TO 1511
1513      CONTINUE
          WRITE(4,1515)
1515      FORMAT(' ',' VULNERABLE AREA RANGE  "0.0 TO 600."  '//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
```

```
            READ(5,1202)V1
            AVAAG=V1
            PKHAAG = AVAAG/APAAG
            GO TO 1511
C*****************************************************************
C     VULN. AREA / P(K/H) VS A/A MISSILE IR
C*****************************************************************
520         CONTINUE
         CALL ESRAVM(IFS,IFV,APAAG,AVAAM,PKHAAM)
1521       CALL FRTCMS('CLRSCRN ')
           WRITE (4,1522)AVAAM,PKHAAM
1522    FORMAT(' ',T6,'VERSUS THE AIA-TO-AIR IR MISSILE'/
     +T6,'THE COMPUTED VULNERABLE AREA VS IS ',T51,F6.0,' SQ.FT.'/
     +T6,'THE P(K/H) IS ',T51,F6.4,//
     +T6,'TO CHANGE THESE VALUES ENTER 1
     +'/T6,' ENTER 0 FOR NO CHANGE REQUIRED')
           READ(5,1211)I1
           IF(I1.EQ.0) GO TO 140
           IF(I1.EQ.1) GO TO 1523
1524       WRITE(4,1200)
           GO TO 1521
1523       CONTINUE
           WRITE(4,1525)
1525       FORMAT(' ',' VULN. AREA RANGE 0 TO 600 '//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
           READ(5,1202)V1
           AVAAM=V1
           PKHAAM = AVAAM/APAAG
           GO TO 1521
C*****************************************************************
C     VULN. AREA / P(K/H) VS LOW ALT SAM
C*****************************************************************
530         CONTINUE
         CALL ESRAVS(IFS,IFV,APAAG,VASM,PKHSM)
1531       CALL FRTCMS('CLRSCRN ')
           WRITE (4,1532)VASM,PKHSM
1532    FORMAT(' ',T6,'VERSUS THE LOW ALTITUDE SAM'/
     +T6,'THE COMPUTED VULNERABLE AREA VS IS ',T51,F6.0,' SQ.FT.'/
     +T6,'THE P(K/H) IS ',T51,F6.4,//
     +T6,' TO CHANGE THESE VALUES ENTER 1'/
     +T6,' ENTER 0 FOR NO CHANGE REQUIRED')
           READ(5,1211)I1
           IF(I1.EQ.0) GO TO 140
           IF(I1.EQ.1) GO TO 1533
1534       WRITE(4,1200)
           GO TO 1531
1533       CONTINUE
           WRITE(4,1535)
```

```
1535      FORMAT(' ',' VULNERABLE AREA RANGE   0.0 TO 600.0  '//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
          READ(5,1202)V1
          VASM=V1
          PKHSM = VASM/APAAG
          GO TO 1531
C*************************************************************************
C MENU 61  P(S) A/A GUN
C*************************************************************************
610       PSAG = 1.- PDAAG * PHG * PKHAAG
618       CALL FRTCMS('CLRSCRN ')
      WRITE (4,2220)JAM,IFS,IRCS,IFV,IWARN,IFE,ICHAFF,IEA,IRJAM,IEP,
     +IRFLAR,ICS,IRSUP,ICA
2220  FORMAT('0',' SUSCEPTIBILITY REDUCTION FEATURES ',
     +T40,' * VULNERABILITY  REDUCTION FEATURES  '//
     +,'      JAMMER NUMBER              ',T35,I1,
     +T42,'   FUEL SYSTEM GENERAL         ',T69,I1/
     +,'      RCS REDUCTION LEVEL        ',T35,I1,
     +T42,'   FUEL/VOID INTERFACE         ',T69,I1/
     +,'      RADAR WARNING RECEIVER     ',T35,I1,
     +T42,'   FUEL/ENGINE INTERFACE       ',T69,I1/
     +,'      CHAFF DISPENSER            ',T35,I1,
     +T42,'   ENGINE ARRANGEMENT          ',T69,I1/
     +,'      IR JAMMER                  ',T35,I1,
     +T42,'   ENGINE PROTECTION           ',T69,I1/
     +,'      IR FLARE DISPENSER         ',T35,I1,
     +T42,'   CONTROL SYSTEM              ',T69,I1/
     +,'      IR SUPPRESSION TECHNIQUE',T35,I1,
     +T42,'   CREW ARRANGMENT             ',T69,I1//)
      WRITE(4,1610)PSAG,PDAAG,PHG,PKHAAG
1610  FORMAT(' ',T6,' THE PROB OF SURVIVAL VS A/A(GUNS)'//
     +T6,'   PS   =  1  -   PD   *   PH   *   PK/H '/
     +T9,F6.4,7X,F6.4,3X,F6.4,3X,F6.4//
     +T6,'TO CHANGE THIS VALUE ENTER 1 IN I1 FORMAT'/
     +T6,'ENTER 0 FOR NO CHANGE REQUIRED')
      READ(5,1659)I1
      IF(I1.EQ.0) GO TO 150
      GO TO (611,1619),I1
1619  WRITE(4,1200)
          GO TO 618
611       CONTINUE
          WRITE(4,1611)
1611  FORMAT(' ',T6,'ENTER PROBABILITY OF P(D), P(H), AND P(K/H) IN REAL
     +NUMBER FORMAT'/
     +T6,'                    (RANGE 0.001 TO 1.00)')
          READ(5,1657)PDAAG,PHG,PKHAAG
          PSAG=1.- PDAAG * PHG * PKHAAG
          GO TO 618
```

```
C*************************************************************************
C     P(S) A/A IR MISSILE
C*************************************************************************
620       PSAM = 1.- PDAAM * PHM * PKHAAM
628       CALL FRTCMS('CLRSCRN ')
      WRITE (4,2220)JAM,IFS,IRCS,IFV,IWARN,IFE,ICHAFF,IEA,IRJAM,IEP,
     +IRFLAR,ICS,IRSUP,ICA
          WRITE(4,1620)PSAM,PDAAM,PHM,PKHAAM
1620      FORMAT(' ',T6,' THE PROB OF SURVIVAL VS A/A (IR MISSILE)'//
     +T6,'    PS    =  1   -    PD    *    PH    *    PK/H '/
     +T9,F6.4,7X,F6.4,3X,F6.4,3X,F6.4//
     +T6,'TO CHANGE THIS VALUE ENTER 1 IN I1 FORMAT.'/
     +T6,'ENTER 0 FOR NO CHANGE REQUIRED')
          READ(5,1659)I1
          IF(I1.EQ.0) GO TO 150
          GO TO (621,1629),I1
1629      WRITE(4,1200)
          GO TO 628
621       CONTINUE
          WRITE(4,1611)
          READ(5,1657)PDAAM,PHM,PKHAAM
          PSAM=1.- PDAAM * PHM * PKHAAM
          GO TO 628
C*************************************************************************
C     P(S) LOW ALT SAM
C*************************************************************************
630       PSSM = 1.- PDSM * PHSM * PKHSM
638       CALL FRTCMS('CLRSCRN ')
      WRITE (4,2220)JAM,IFS,IRCS,IFV,IWARN,IFE,ICHAFF,IEA,IRJAM,IEP,
     +IRFLAR,ICS,IRSUP,ICA
          WRITE(4,1630)PSSM,PDSM,PHSM,PKHSM
1630      FORMAT(' ',T6,' THE PROB OF SURVIVAL VS SAM  '//
     +T6,'    PS    =  1   -    PD    *    PH    *    PK/H '/
     +T9,F6.4,7X,F6.4,3X,F6.4,3X,F6.4//
     +T6,'TO CHANGE THIS VALUE ENTER 1 IN I1 FORMAT.'/
     +T6,'ENTER 0 FOR NO CHANGE REQUIRED')
          READ(5,1659)I1
          IF(I1.EQ.0) GO TO 150
          GO TO (631,1639),I1
1639      WRITE(4,1200)
          GO TO 638
631       CONTINUE
          WRITE(4,1611)
          READ(5,1657)PDSM,PHSM,PKHSM
          PSSM=1.- PDSM * PHSM * PKHSM
          GO TO 638
C*************************************************************************
C MENU 62      SORTIE ANALYSIS
```

```
C*************************************************************************
640       CONTINUE
649       CALL FRTCMS('CLRSCRN ')
       WRITE (4,164C)ACR,XNPASS,PSAG,PSAM,PSSM
1640   FORMAT(' ',' MENU (62)  SORTIE ANALYSIS '//
      +T6,'1    AIRCRAFT IN SCRTIE                ',T46,F6.0/
      +T6,'2    NUMBER CF PASSES PER SCRTIE       ',T44,F6.0/
      +T6,'3    P(S) VS A/A(GUNS)                 ',T48,F6.4/
      +T6,'4    P(S) VS A/A(IR MISSILE)           ',T48,F6.4/
      +T6,'5    P(S) VS LOW ALT SAM               ',T48,F6.4//
      +T6,'TC CHANGE A VALUE ENTER ITS NUMBER IN I1 FORMAT.'/
      +T6,'ENTER 0 FOR NO CHANGE REQUIRED')
       READ(5,1659)I1
       IF(I1.EQ.0) GO TC 689
       GO TO (641,642,618,628,638),I1
1648   WRITE(4,120C)
            GC TO 64C
641         CCNTINUE
            WRITE(4,1651)
            READ(5,1657)V1
            ACR=V1
            GC TO 649
642         CCNTINUE
            WRITE(4,1653)
            READ(5,1202)V1
            XNPASS=V1
            GO TO 649
689    CALL  SCRT( AAL,AAH,AAC,PKHAAG,PSAG,
     &             AAL,AAH,AAD,PKHAAM,PSAM,   SAML,SAMH,SAMD,PKHSM,PSSM,
     & ACR,NSRT,XNPASS,NS,                ACR2,TCTSR,TOTACK,TOTACL,TOTACR)
          CALL FRTCMS('CLRSCRN ')
       WRITE (4,1689)ACR2,TCTSR,TOTACK,TOTACL,TOTACR
1689   FORMAT(' ',' RESULTS FROM SINGLE SORTIE AGAINST THE THREATS'//
      +T6,'    UNDAMAGED AIRCRAFT          ',T41,F6.2/
      +T6,'    SCRTIES FLOWN               ',T41,F6.2/
      +T6,'    TARGETS ATTACKED            ',T41,F6.2/
      +T6,'    AIRCRAFT LCST               ',T41,F6.2/
      +T6,'    AIRCRAFT DAMAGED            ',T41,F6.2//
      +T6,'TC RERUN A SCRTIE ANALYSIS ENTER 1 '/
      +T6,'TC RETURN TC MENU (6) ENTER 0')
       READ(5,1211)I1
        IF(I1.EQ.1) GO TO 64C
        GO TC 150
C*************************************************************************
C MENU 63  CAMPAIGN ANALYSIS
C*************************************************************************
650       CONTINUF
659        CCNTINUE
```

```
      CALL FRTCMS('CLRSCRN ')
      WRITE (4,1650)ACR1,NSRT,XNPASS,NS,PSAG,PSAM,PSSM
1650  FORMAT(' ',' MENU (63)  CAMPAIGN ANALYSIS '//
     +T6,'1    AIRCRAFT IN CAMPAIGN              ',T46,F6.0/
     +T6,'2    NUMBER OF RAIDS IN CAMPAIGN       ',T43,I6/
     +T6,'3    NUMBER OF PASSES PER SORTIE       ',T44,F6.0/
     +T6,'4    NUMBER OF SORTIES FOR REPAIR      ',T43,I6//
     +T6,'5    P(S) VS A/A(GUNS)                 ',T48,F6.4/
     +T6,'6    P(S) VS A/A(IR MISSILE)           ',T48,F6.4/
     +T6,'7    P(S) VS LOW ALT SAM               ',T48,F6.4//
     +T6,'TO CHANGE A VALUE ENTER ITS NUMBER IN I1 FORMAT.'/
     +T6,'ENTER 0 FOR NO CHANGE REQUIRED')
      READ(5,1659)I1
1659  FORMAT(I1)
      IF(I1.EQ.0) GO TO 699
      GO TO (651,652,653,654,618,628,638),I1
1658  WRITE(4,1200)
      GO TO 65C
651   CONTINUE
      WRITE(4,1651)
1651  FORMAT(' ',T6,'ENTER NUMBER OF A/C IN REAL NUMBER FORMAT.')
      READ(5,1657)V1
1657  FORMAT(F8.4)
      ACR1=V1
      GO TO 659
652   CONTINUE
      WRITE(4,1652)
1652  FORMAT(' ',T6,'ENTER NUMBER OF RAIDS IN I2 FORMAT.')
      READ(5,1697)I2
1697  FORMAT(I2)
      NSRT=I2
      GO TO 659
653   CONTINUE
      WRITE(4,1653)
1653  FORMAT(' ',T6,'ENTER PASSES PER SORTIE IN REAL NUMBER FORMAT.')
      READ(5,1202)V1
      XNPASS=V1
      GO TO 659
654   CONTINUE
      WRITE(4,1654)
1654  FORMAT(' ',T6,'ENTER THE MAX NUMBER OF SORTIES FOR REPAIR IN I
     +2 FORMAT.')
      READ(5,1697)I2
      NS=I2
      GO TO 659
699   CALL FRTCMS('CLRSCRN ')
      CALL CAMP( AAL,AAH,AAC,PKHAAG,PSAG,
     &           AAL,AAH,AAC,PKHAAM,PSAM,  SAML,SAMH,SAMD,PKHSM,PSSM,
```

```
     & ACR1,NSRT,XNPASS,NS,          ACR2,TOTSR,TOTACK,TOTACL,TOTACR)
      WRITE (4,1699)ACR2,TOTSR,TOTACK,TOTACL,TOTACR
1699  FORMAT(' ',/,'      RESULTS FROM CAMPAIGN AGAINST THE THREATS'//
     +T6,'     A/C READY FOR NEXT SORTIE',T41,F6.0/
     +T6,'     SORTIES FLOWN             ',T41,F8.0/
     +T6,'     TARGETS ATTACKED          ',T41,F8.0/
     +T6,'     AIRCRAFT LOST             ',T41,F6.0/
     +T6,'     AIRCRAFT IN REPAIR        ',T41,F6.0//
     +T6,'TO RETURN TO CAMPAIGN ANALYSIS ENTER 1 '/
     +T6,'TO RETURN TO MENU (6) ENTER 0')
      READ(5,1211)I1
       IF(I1.EQ.1) GO TO 650
       GO TO 150
C*****************************************************************
C     HELP
C*****************************************************************
9971     CALL FRTCMS('CLRSCRN ')
      WRITE(4,7971)
7971  FORMAT(' ',/,'                    HELP FOR MENU 1                '/
     +T6,' THE VISAP DESIGN EVALUATOR IS DIVIDED INTO FIVE SECTIONS. '/
     +T6,'     THE AIRCRAFT DESIGN SECTION IS WHERE A DESCRIPTION OF'/
     +T6,' THE AIRCRAFT IS ENTERED. THIS INCLUDES GENERAL PARAMETRIC'/
     +T6,' SIZING VALUES AS WELL AS DESCRIPTIONS OF THE S/V FEATURES'/
     +T6,' CONTAINED IN THE DESIGN. VALUES SHOWN INITIALLY ARE DEFAULT'/
     +T6,' VALUES WHICH MAY BE CHANGED.'/
     +T6,'     THE MISSION SECTION IS WHERE THE MISSION PARAMETERS AND'/
     +T6,' THREAT INTENSITY VALUES ARE ENTERED. NOTE THAT THE TYPE'/
     +T6,' OF THREATS CANNOT BE CHANGED BECAUSE THE SELECTION OF THE'/
     +T6,' AIRCRAFT DETERMINES THE THREATS.                         '/
     +T6,'     THE LAST THREE SECTIONS ARE FOR EVALUATION OF THE'/
     +T6,' DESIGN. IF THE DESIGN AND THREAT SECTIONS ARE NOT ENTERED'/
     +T6,' DEFAULT VALUES (BASELINE) WILL BE USED FOR ALL CALCULATIONS.'
     +,//T6,'          ENTER ANY INTEGER TO RETURN TO MENU 1       ')
      READ(5,*)IJK
      GO TO 100
9972     CALL FRTCMS('CLRSCRN ')
      WRITE(4,7972)
7972  FORMAT(' ',/,'                    HELP FOR MENU 2                '/
     +T6,' THE DESIGN SECTION IS DIVIDED INTO THREE SUBSECTIONS.'/
     +T6,'     THE AIRCRAFT PERFORMANCE INDICATORS AFFECT THE '/
     +T6,' ABILITY OF THE AIRCRAFT TO MANEUVER AND AVOID THE THEAT.'/
     +T6,' SOME OF THE VALUES MAY REMOVE THE AIRCRAFT FROM THE'/
     +T6,' THREAT ENVELOPE COMPLETELY. A FURTHER DISCUSSION OF THE '/
     +T6,' IMPACT OF THESE VALUES MAY BE FOUND IN THE P(H) SECTION'/
     +T6,' OF SUSCEPTIBILITY EVALUATION.                            '/
     +T6,'     SUSCEPTIBILITY REDUCTION FEATURES OF THE DESIGN ARE'/
     +T6,' ENTERED IN THIS SECTION. THESE INCLUDE JAMMER SIZE, RCS '/
     +T6,' REDUCTION LEVELS, CHAFF DISPENSER AND RADAR WARNING RE- '/
```

```
     +T6,' CEIVER. THE DEFAULT VALUES (BASELINE) ARE ZERO, INDICATING'/
     +T6,' NONE OF THESE FEATURES ARE INCLUDED.                        '/
     +T6,'      VULNERABILITY REDUCTION FEATURES VARY WITH THE THREE'/
     +T6,' TYPES OF AIRCRAFT. SELECT THOSE FEATURES THAT BEST'/
     +T6,' DESCRIBE YOUR DESIGN. MINIMUM VALUES OF 1 (BASELINE)'/
     +T6,' INDICATE NO IMPROVEMENTS.                                  '//
     +T6,'          ENTER ANY INTEGER TO RETURN TO MENU 2             ')
      READ(5,*)IJK
      GO TO 110
9973     CALL FRTCMS('CLRSCRN ')
      WRITE(4,7973)
7973  FORMAT(' ',T6,'                          HELP FOR MENU 3                    '/
     +T6,' THE COMBAT SCENERIO SECTION IS DIVIDED INTO TWO SUBSECTIONS.
     +'/,T6,'      IN MISSION PROFILE, VALUES ARE ENTERED TO SPECIFICALLY
     +',T6,' DEFINE THE DESIRED MISSION. THE MISSION PARAMETERS ARE DEFI
     +NED'/,T6,' BY THE SELECTION OF AIRCRAFT TYPE. THESE INCLUDE ITEMS'
     +/,T6,' THAT MIGHT BE CONSIDED AS TACTICS.                        '/
     +T6,'      IN THREAT SELECTION, THREAT DENSITIES AND THREAT'/
     +T6,' DIAMETERS ARE ENTERED.  THE THREATS FOR THE FIGHTER ESCORT'/
     +T6,' MISSION ARE; AIR-TO-AIR GUNS, AIR-TO-AIR IR MISSILES, AND'/
C- #2 ------------------------------------------------------------------
     +T6,' LOW ALTITUDE SAM''S.'//
     +T6,'          ENTER ANY INTEGER TO RETURN TO MENU 3             ')
      READ(5,*)IJK
      GO TO 120
9974     CALL FRTCMS('CLRSCRN ')
      WRITE(4,7974)
7974  FORMAT(' ',T6,'                          HELP FOR MENU 4                    '/
     +T6,' THE SUSCEPTIBILITY ASSESSMENT SECTION HAS TWO SUBSECTIONS.'/
     +T6,'      THE PROBABILITY OF DETECTION IS AFFECTED BY THE'/
     +T6,' PCS OF THE AIRCRAFT, THE POWER OF THE NOISE JAMMER, '/
     +T6,' AND THE SLANT RANGE FROM THE THREAT TO THE A/C AT CPA.'/
     +T6,' NOTE THAT ALL AIRCRAFT ARE CONSIDERED TO PASS OVER A POINT'/
     +T6,' THAT IS THE SAME HORIZONTAL DISTANCE FROM THE THREAT '/
     +T6,' AS THE ALTITUDE OF THE AIRCRAFT. THIS MEANS THAT THE'/
     +T6,' CPA SLANT RANGE IS 1.414 TIMES THE ALTITUDE.'/
     +T6,'      THE PROBABILITY OF HIT IS DEFINED SEPARATELY FOR EACH'/
     +T6,' AIRCRAFT AND THREAT. HOWEVER, THE FORM IS CONSISTENT, WHERE'/
     +T6,' P(H) REFERS TO THE PROBABILITY THAT A NON-MANEUVERING A/C'/
     +T6,' WOULD BE HIT BY THE THREAT, F(M) IS THE MANEUVER FACTOR.'/
     +T6,' AND F(C) IS THE COUNTERMEASURE (CHAFF OR FLARE) FACTOR.'//
     +T6,'             P(H)'' = P(H) * F(M) * F(C)                    '//
     +T6,'          ENTER ANY INTEGER TO RETURN TO MENU 4             ')
      READ(5,*)IJK
      GO TO 130
9975     CALL FRTCMS('CLRSCRN ')
      WRITE(4,7975)
7975  FORMAT(' ',T6,'                          HELP FOR MENU 5                    '/
```

```
     +T6,'       THE VULNERABILITY ASSESSMENT SECTION CALCULATES  '/
     +T6,' EITHER THE P(K/H) OR THE AVERAGE VULNERABLE AREA FOR THE '/
     +T6,' AIRCRAFT VERSUS A THREAT. FOR THE ESCORT AIRCRAFT;    '//
     +T6,' VS A/A GUNS                                           '/
     +T6,'    AV  = REGRESSION FORMULA THAT IS A FUNCTION    '/
     +T6,'          OF VULNERABILITY FEATURE INPUTS          '/
     +T6,'    AP = REGRESSION FORMULA THAT IS A FUNCTION       '/
     +T6,'         OF MISSION AND A/C PERFORMANCE INPUT DATA.  '/
     +T6,'    P(K/H) = AV/AP                                   '/
     +T6,' VS A/A IR MISSILE                                   '/
     +T6,'    P(K/H) = FROM A TABLE BASED UPON                 '/
     +T6,'      AP = ASSUMED SAME AS AP VS A/A GUNS (604 SQFT DEFAULT)'/
     +T6,'      AV  = P(K/H)*AP                                '//
     +T6,' VS LOW ALTITUDE SAM                                 '/
     +T6,'    P(K/H) = FROM A TABLE BASED UPON                 '/
     +T6,'      AP = ASSUMED SAME AS AP VS A/A GUNS (604 SQFT DEFAULT)'/
     +T6,'      AV  = P(K/H)*AP                                '//
     +T6,'         ENTER ANY INTEGER TO RETURN TO MENU 5          ')
      READ(5,*)IJK
      GO TO 140
9976    CALL FRTCMS('CLRSCRN ')
      WRITE(4,7976)
7976  FORMAT(' ','                                HELP FOR MENU 41      '/
     +T6,'       THE FOLLOWING METHODS ARE USED FOR THE ESCORT P(D)'//
     +T6,'    VS A/A GUNS/MISSILE                                '/
     +T6,'       P(D) = 1.                                       '/
     +T6,'    VS SAM                                             '/
     +T6,'       P(D) = TWO TIMES THE INTEGRAL OF THE GAUSSIAN   '/
     +T6,'            PROBABILITY FUNCTION FROM INFINITY TO CPA'//
     +T6,'         ENTER ANY INTEGER TO RETURN TO MENU 41         ')
      READ(5,*)IJK
      GO TO 410
9977    CALL FRTCMS('CLRSCRN ')
      WRITE(4,7977)
7977  FORMAT(' ','                                HELP FOR MENU 42      '/
     +T6,'       THE FOLLOWING METHODS ARE USED FOR THE ESCORT P(H)'/
     +T6,'PH = PROBABILITY THAT A NON-MANEUVERING A/C IS HIT      '/
     +T6,'PA = PROBABILITY THAT THE CREW IS ALLERTED AND TAKE EVASIVE AC
     +TION.'/
     +T6,'PJ = IR JAMMER FACTOR        PS = IR SUPPRESSION FACTOR'/
     +T6,'PM = MANEUVER FACTOR         PF = IR FLARE FACTOR'/
     +T6,'WS = WING LOADING/100.       TW = THRUST TO WEIGH'//
     +T6,'    VS A/A GUNS                                        '/
     +T6,'       PH= .46168                    PA= 1.'/
     +T6,'       PM= 1+ 1.24038 * WS - 1.604 * TW'/
     +T6,'       PH'' = PH * (1. -(1.-PM)*PA)                    ')
      WRITE(4,79771)
79771 FORMAT(' ',T6,'    VS A/A IR MISSILE                  '/
```

```
     +T6,'        PF= .46168              FJ = .87 FF'/
     +T6,'        FA= 1.                  FS = .011 * 2**(TW/.2 -1.)'/
     +T6,'        FM=-.06056+2.54829*WS+.06043*Tw**2-1.48652*WS**2'/
     +T6,'           -.25379*TW*WS'/
     +T6,'        PH'' = PH * FF * FJ * FS * (1. -(1.-FM)*FA)'//
     +T6,'    VS SAM                                                  '/
     +T6,'        PH = .33070      FC = .6                            '/
     +T6,'        FM = 1.-1.7  66 * Tw**2 + 2.9794 * WS**2            '/
     +T6,'             -3.816 * WS**2 * Tw**2                         '/
     +T6,'        PH'' = PH * FC * ( 1. - (1.- FM) * FA)              '//
     +T6,'          ENTER ANY INTEGER TO RETURN TO MENU 42             ')
      READ(5,*)IJK
      GO TO 420
9978     CALL FRTCMS('CLRSCRN ')
      WRITE(4,7978)
7978  FORMAT(' ','                              HELP FOR MENU 6        '//
     +T6,'THE P(S) VS INDIVIDUAL WEAPONS                              '/
     +T6,'          P(S) = 1 -  P(D) * P(H) * P(K/H)                  '//
     +T6,'THE P(S) FOR A SINGLE SORTIE                                '/
     +T6,'     W = WEIGHTING FACTOR          XL = PENETRATION DISTANCE'/
     +T6,'     XH = THREAT DENSITY            DL = THREAT DIAMETER    '/
     +T6,'     AH = A/C HIT      XK = A/C KILLED   AD = A/C DAMAGED    '/
     +T6,'     ACOVER = A/C OVER TARGET        ATAC = TARGETS ATTACKED '/
     +T6,'     PSM = PROB. OF MISS. SURVIVAL   ACR1 = A/C IN FORMATION'//
     +T6,'     W = XL * XH * D / 100.        PSM = PS ** W           '/
     +T6,'     PH = (1. - PSM)/PKH            H1 = ACR1 * PH         '/
     +T6,'     XK1 = H * PKH                  A1 = H1 - XK1          '/
     +T6,'     ACOVER = ACR1-H1-H2-H3         ATAC = ACOVER * XNPAS  '/
     +T6,'     H4 = ACOVER * PH               XK4 = H4 * PKH         '/
     +T6,'     A3 = H4 - XK4                  ACNHT = ACR1-H1-H4     '/
     +T6,'     ACDAM = A1 + A4                ACKIL = XK1 + XK4      '//
     +T6,'          ENTER ANY INTEGER TO RETURN TO MENU 6             ')
      READ(5,*)IJK
C-  #3 ------------------------------------------------------------------
      GO TO 150
C-  #5 ------------------------------------------------------------------
C ******************** PLOTTING INFORMATION ****************************
 8888 CALL FRTCMS('CLRSCRN ')
      WRITE(4,8889)
 8889 FORMAT(' ','          HELP FOR MENU (8)      '//
     *T6,'MENU (8) INCORPORATES A DATA GENERATING ROUTINE TO SAVE'/
     *T6,'THE PROBABILITIES OF A KILL ( P(K) = 1 - P(S) ) FOR'/
     *T6,'LATER PLOTTING.  THIS PLOT MAY BE OBTAINED FROM A'/
     *T6,'TEKTRONIX DUAL SCREEN (TEK618) SYSTEM.  THE P(K)'/
     *T6,'AGAINST THE APPROPRIATE THREAT TYPES ARE PRESENTED.'//
     *T6,'     THREE DESIGNS CAN BE PLOTTED AT A TIME, FOR EXAMPLE'/
     *T6,'YOUR BASELINE DESIGN, YOUR FIRST DESIGN, AND ONE OTHER'/
     *T6,'MODIFICATION.  YOU MUST HAVE DONE AND CHOSEN TO SAVE'/
```

```
     *T6,'PLOTTING DATA FROM THREE RUNS.'//
     *T6,'     TO OBTAIN THE PLOT, FOLLOW THE SAME LOGON AND LINK'/
     *T6,'PROCEDURES YOU UTILIZED TO ACCESS VISAP, HOWEVER, ENTER'/
     *T6,'DISVIS INSTEAD OF VISAP. THEN ENTER ESCPLT.'//
     *T6,'          ENTER ANY INTEGER TO RETURN TO MENU (8)')
      READ (5,*)IJK
      GO TO 8
C*****************************************************************
C          TRANSFER
C*****************************************************************
998       CALL FRTCMS('CLRSCRN ')
      WRITE(4,1998)
1998  FORMAT(' ','TRANSFER MENU, SELECT A CODE AS FOLLOWS:'/
     +T6,'MAIN MENU                    ',T41,'MM'/
     +T6,'  AIRCRAFT DESIGN SELECTION  ',T41,'DE'/
     +T6,'    A/C PERFORMANCE INDICATORS ',T41,'AP'/
     +T6,'    SUSCEPTIBILITY FEATURES    ',T41,'SF'/
     +T6,'    VULNERABILITY FEATURES     ',T41,'VF'/
     +T6,'  COMBAT SCENARIO SELECTION  ',T41,'MS'/
     +T6,'    MISSION PROFILE            ',T41,'MP'/
     +T6,'    THREAT SELECTION           ',T41,'TH'/
     +T6,'  SUSCEPTIBILITY ASSESSMENT  ',T41,'SA'/
     +T6,'    PROBABILITY OF DETECTION   ',T41,'PD'/
     +T6,'    PROBABILITY OF HIT         ',T41,'PH'/
     +T6,'  VULNERABILITY ASSESSMENT   ',T41,'VA')
      WRITE(4,19981)
19981 FORMAT(' ',
     +T6,'    P(K/H) VS A/A GUNS         ',T41,'KG'/
     +T6,'    P(K/D) VS A/A MISSILE      ',T41,'KM'/
     +T6,'    P(K/D)                     ',T41,'KD'/
     +T6,'  SURVIVABILITY ASSESSMENT   ',T41,'SV'/
     +T6,'    P(S) 1:1 A/A (GUNS)        ',T41,'AG'/
     +T6,'    P(S) 1:1 A/A (IR MISSILE)  ',T41,'AM'/
     +T6,'    P(S) 1:1 LOW ALT SAM       ',T41,'LS'/
     +T6,'    SINGLE SORTIE              ',T41,'SS'/
     +T6,'    CAMPAIGN EVALUATION        ',T41,'CE'/
     +T6,'TO EXIT OR PRINT RESULTS             ',T41,'EX'/)
      READ(5,2000) K90
      IF(K90.EQ.K1(1)) GO TO 110
      IF(K90.EQ.K1(2)) GO TO 120
      IF(K90.EQ.K1(3)) GO TO 130
      IF(K90.EQ.K1(4)) GO TO 140
      IF(K90.EQ.K1(5)) GO TO 150
      IF(K90.EQ.K2(1)) GO TO 210
      IF(K90.EQ.K2(2)) GO TO 220
      IF(K90.EQ.K2(3)) GO TO 230
      IF(K90.EQ.K3(1)) GO TO 310
      IF(K90.EQ.K3(2)) GO TO 320
```

```
      IF(K9Q.EQ.K4(1)) GO TO 410
      IF(K9Q.EQ.K4(2)) GO TO 420
      IF(K9Q.EQ.K5(1)) GO TO 510
      IF(K9Q.EQ.K5(2)) GO TO 520
      IF(K9Q.EQ.K5(3)) GO TO 530
      IF(K9Q.EQ.K6(1)) GO TO 610
      IF(K9Q.EQ.K6(2)) GO TO 620
      IF(K9Q.EQ.K6(3)) GO TO 630
      IF(K9Q.EQ.K6(4)) GO TO 640
      IF(K9Q.EQ.K6(5)) GO TO 650
      IF(K9Q.EQ.KK(3)) GO TO 999
      IF(K9Q.EQ.K1(6)) GO TO 100
      WRITE(4,1200)
      GO TO 998
C*************************************************************************
C           OUTPUTS AND EXIT
C*************************************************************************
C- #3 ------------------------------------------------------------------
1061      CONTINUE
C*************************************************************************
C           FIND TOGW OF AIRCRAFT
C*************************************************************************
          CALL ESRHT(B,W,DL,EC,ED,EL,TW,WS,WT,XL,ICA,ICS,IEA,
     @    IEP,IFE,IFS,IFV,JAM,IRCS,XMDA,XMDM,XMDD,IRJAM,IRSUP,IWARN,
     @    ICHAFF,IRFLAR,BLTOGW,TOGW)
C- #3 ------------------------------------------------------------------
C********** TO SAVE DATA ************************
      REWIND 1
      WRITE(1,1012)TW,WS,WT,B,XL,W,EC,ED,EL,DL,JAM,IRCS,IWARN,ICHAFF,
     *      IRJAM,IRFLAR,IRSUP,IFS,
     *      IFV,IFE,IEA,IEP,ICS,ICA,XMDA,XMDM,XMDD,AAH,AAD,AAL,SAMH,
     *      SAMD,SAML,PDAAG,PDAAM,PDSM,PHG,PHM,PHSM,APAAG,AVAAG,
     *      PKHAAG,AVAAM,PKHAAM,VASM,PKHSM,
     *      PSAG,PSAM,PSSM,ACR,ACR1,NSRT,
     *      XNPASS,NS,ACR2,TOTSR,TOTACK,TOTACL,TOTACR,BLTOGW,TOGW
C
C- #3 ------------------------------------------------------------------
      CALL FRTCMS('CLRSCRN ')
      WRITE (4,9200)TW,WS,WT,XMDA,AAH,XMDM,AAD,XMDD,AAL,SAMH,SAMD,SAML
      WRITE(4,2220)JAM,IFS,IRCS,IFV,IWARN,IFE,ICHAFF,IEA,IRJAM,IEP,
     +IRFLAR,ICS,IRSUP,ICA
      WRITE(4,9201)
      WRITE(4,9202)PSAG,PDAAG,PHG,PKHAAG
      WRITE(4,9203)PSAM,PDAAM,PHM,PKHAAM
      WRITE(4,9204)PSSM,PDSM,PHSM,PKHSM
      WRITE(4,9205)
      WRITE(4,9206)ACR1,NSRT,XNPASS,NS,ACR2,TOTSR,TOTACK,TOTACL,TOTACR
      WRITE(4,9207)BLTOGW,TOGW
```

```
      WRITE(4,9208)
      WRITE(4,922C)
      WRITE(4,922C)
      WRITE(4,922C)
      GO TO 8
C*****************************************************************************
999       CCNTINUE
      CALL FRTCMS('CLRSCRN ')
      WRITE(4,9999)
9999  FORMAT(' ',' TO PRINT YOUR RESULTS AND EXIT ENTER  "0"'/
     +,' TO PRINT YOUR RESULTS AND REENTER PROGRAM ENTER "1"'/
     +,' TO EXIT WITHOUT A PRINT ENTER "2"')
      READ(5,*)IJK
      IF(IJK.EC.2) GC TO 99999
C- #4 ---------------------------------------------------------------------
      WRITE (6,9200)TW,WS,WT,XMDA,AAH,XMDM,AAC,XMDD,AAL,SAMH,SAMD,SAML
      WRITE(6,2220)JAM,IFS,IRCS,IFV,IWARN,IFE,ICHAFF,IEA,IRJAM,IEP,
     +IRFLAR,ICS,IRSUP,ICA
      WRITE(6,9201)
      WRITE(6,9202)PSAG,PDAAG,PHG,PKHAAG
      WRITE(6,9203)PSAM,PDAAM,PHM,PKHAAM
      WRITE(6,9204)PSSM,PDSM,PHSM,PKHSM
      WRITE(6,922C)
      WRITE(6,9205)
      WRITE(6,9206)ACR1,NSRT,XNPASS,NS,ACR2,TCTSR,TOTACK,TOTACL,TOTACR
      WRITE(6,9207)BLTCGW,TCGW
C
      IF(IJK.EQ.1) GO TO 1022
9220  FORMAT(' ')
C- #3,#4 ------------------------------------------------------------------
9200  FORMAT('1',T25,'** FIGHTER ESCORT AIRCRAFT **'///
     *       T30,'* PERFORMANCE FEATURES'//
     *       ,'     THRUST TC WEIGHT',T30,F8.2,
     *       T42,'   WING LOADING',T65,F8.2/
     *       ,'     ORDNANCE WEIGHT',T30,F8.2///
     *       ,' * MISSION PARAMETERS',T40,' * THREAT PARAMETERS'//
     *       ,'     DASH ALTITUDE',T30,F8.2,
     *       T42,'   A/A DENSITY',T65,F8.2/
     *       ,'     DASH MACH NBR.',T30,F8.2,
     *       T42,'   A/A DIAMETER',T65,F8.2/
     *       ,'     DASH DISTANCE',T30,F8.2,
     *       T42,'   A/A PENETRATION DIST.',T65,F8.2/
     *       T42,'   SAM DENSITY',T65,F8.2/
     *       T42,'   SAM DIAMETER',T65,F8.2/
     *       T42,'   SAM PENETRATION DIST.',T65,F8.2///)
C- #3,#4 ------------------------------------------------------------------
9201  FORMAT('0','        * SURVIVABILITY ASSESSMENT:'//
     *       T18,'P(S)     P(C)     P(H)     P(K/H)')
```

```
9202  FORMAT(' ',' VS A/A GUNS     ',4(F4.2,5X))
9203  FORMAT(' ',' VS A/A MISS     ',4(F4.2,5X))
9204  FORMAT(' ',' VS SAM          ',4(F4.2,5X))
9205  FORMAT('0',' * CAMPAIGN ANALYSIS: */)
9206  FORMAT('0',' INITIAL A/C    ',F8.0,'     NUMBER OF RAIDS     ',I7,/
     +       ' PASSES/SORTIE     ',F8.0,'     SORTIES FOR REPAIR  ',I5,/
     +       ' A/C READY         ',F8.0,'     TOTAL SORTIES       ',F8.0,/
     +       ' TOTAL TARGETS     ',F8.0,'     TOTAL A/C LOST      ',F8.0,/
     +       ' IN REPAIR         ',F8.0)
9207  FORMAT('0',' BASELINE TOGW ',F10.2,T36,'ENHANCED TOGW ',F10.2)
9208  FORMAT('0',2('**********',/))
99999 STOP
      END
      SUBROUTINE ESRPDS(JAMS,IRCSS,PDF)
C*************************************************************
C***** PROBABILITY OF DETECTION BY LOW ALTITUDE SAM *********
C*************************************************************
      DIMENSION H(2,7,6),F(101),PDT(101),XX(101)
      DATA H/
     @31.4,9.3,30.0,9.0,25.8,7.8,24.9,7.6,21.2,7.2,18.4,5.3,12.2,3.5,
     @15.0,4.2,13.8,4.0,10.2,3.1, 8.9,2.6, 7.1,2.1, 5.1,1.4, 2.4,.75,
     @10.6,3.1, 9.7,3.0, 7.2,2.1, 6.4,1.8, 4.9,1.4, 3.7,1.1, 1.5,.33,
     @ 7.5,2.2, 6.9,2.1, 5.2,1.4, 4.6,1.3, 3.4,.96, 2.6,.71, 0.1,0.0,
     @ 4.8,1.4, 4.3,1.3, 3.2,.96, 2.5,.71, 2.1,.63, 1.7,.54, 0.1,0.0,
     @ 3.6,1.1, 3.2,.96, 2.5,.71, 2.1,.63, 1.9,.59, 1.3,.38, 0.1,0.0/
      PDF = 0.
C********** FOR ALL ALT .LT. 10,000 FT**********************
      DSR=1.5
C********** CANT USE ZERO AS AN INDEXIES**********************
      I=IRCSS+1
      J=JAMS+1
C********** SELECTS PROPER MEAN AND DEVIATIONS****************
      X=H(1,I,J)
      S=H(2,I,J)
      IF(S.LT..01)S=.01
C********** CONSTANTS FOR EASE OF WRITING*********************
      CON1=1./(S*SQRT(2.*3.14159))
      CON2=-.5/S**2
C**********INTEGRATION START AT MEAN + 4 DEVIATIONS********
      XI=X+4.*S
C**********100 STEPS IN ITEGRATION************************
      STEP=-S/12.5
C********** INITIAL VALUES TO START INTEGRATION***********
      F(1)=0.0
      XX(1)=XI
      PDF=0.
      PD=0.
C**********INTEGRATION LOOP*************************************
```

```
      DO 10 JJ=1,100
            F(JJ+1)= CON1*EXP(CON2*(XI-X)**2)
            XI=XI+STEP
            AREA=-.5*STEP*(F(JJ+1)+F(JJ))
            PDT(JJ+1)=PD
               IF(XI.LT.CSR)GO TO 5
                  PDF=PD
5              CONTINUE
            XX(JJ+1)=XI
            PD=PD+AREA
10    CONTINUE
C**********SETS UP A MINIMUM PDF OF .1**********
      IF(PDF.GT.0.1) GO TO 20
      PDF=.100
20      CONTINUE
      RETURN
      END
        SUBROUTINE ESRPHG(TWS,WS,PDAM)
C*************************************************************
C************** P(H) FOR A/A GUNS ****************************
C*************************************************************
            PDAM = 0.
                WSS = WS/100.
                PH= .46168
                FA= 1.
                FM= 1.+ 1.24038 * WSS - 1.604 * TW
            XMF = 1. -(1.-FM)*FA
            PDAM = PH*XMF
            IF(PDAM.LT..01)PDAM=.01
            RETURN
            END
            SUBROUTINE ESRPHM(TWS,WS,IRJAM,IRFLAR,IRSUP,PDAM)
C*************************************************************
C************** PH FOR A/A IR MISSILE ************************
C*************************************************************
            PDAM = 0.
                WSS = WS/100.
                PH= .46168
C************** IR JAMMER FACTOR *****************************
      IF(IRJAM.EQ.1) PH = PH * .87
C************** IR SUPPRESSION FACTOR ************************
      IF(IRSUP.EQ.1) PH = PH * .011 * 2**(TW/.2 -1.)
C************** IR FLAIR FACTOR ******************************
      IF(IRFLAR.EQ.1) PH = PH * .5
C************** ALERTION FACTOR ******************************
                FA= 1.
C************** MANUEVER FACTOR ******************************
      FM=-.06056+2.54829*WSS+.06043*TWS**2-1.4865?*WSS**2-.25379*TWS*WSS
```

```
            XMF = 1. -(1.-FM)*FA
            PDAM = PH*XMF
            RETURN
            END
            SUBROUTINE ESRPHS(IWARN,ICHAFF,XMA,WS,PDAM)
C*************************************************************************
C***** PH FOR LOW ALTITUDE SAM ******************************************
C*************************************************************************
            PDAM = 0.
             WSS = WS/100.
             XXMR = 3.29
               PH = .33070
            CALL SRFC (ICHAFF,FC)
C*************  MODIFIED FOR CHAFF ***********************************
               PH1 = PH * FC
            CALL SRFA (XXMR,IWARN,FA)
C*************  MODIFIED FOR MANUVERING ******************************
          FM = 1.-1.7  66*XMA**2+2.9794*WSS**2-3.816*WSS**2*XMA**2
C*************  SETS MINIMUM FM AT .01* ******************************
          IF(FM.LT.0.01)FM = 0.01
               XMF = 1. - (1.- FM) * FA
            PDAM = PH1 * XMF
            RETURN
            END
           SUBROUTINE SRFC(ICHAFF,FC)
C*************************************************************************
C****** CHAFF FACTOR *****************************************************
C*************************************************************************
           REAL PBTSM(17)
           DATA PBTSM/.00,.19,.35,.49,.6,.68,.74,.8,.83,.86,.9,.92,.935,
     A              .95,.96,.97,.98/
            FC = 0.
           PBTS=0.
           IF(ICHAFF.EQ.0) GO TO 10
C********NUMBER OF BUNDLES DEFAULTED TO FOUR **************************
           NBUNDS = 4
           PBTS=PBTSM(NBUNDS+1)
10         FC = 1. - PBTS
           RETURN
           END
         SUBROUTINE SRFA(XXMRS,IWARN,FAS)
C*************************************************************************
C******* ALERTION FACTOR **************************************************
C*************************************************************************
         REAL MRM(28),FVM(28),FESM(12),MRSM(12)
           DATA FESM/1.,.99999,.97,.91,.82,.69,.53,.35,.22,.137,.065,0./
           DATA MRSM/0.,36.,40.,50.,60.,70.,80.,90.,100.,110.,120.,140./
         DATA MRM/0.,1.,1.94,2.,2.54,3.,3.08,3.48,3.78,4.,4.05,4.23
```

```
     &4.35,4.45,4.55,4.68,4.8,4.9,5.05,5.35,5.8,6.,6.39,7.,7.36
     &8.,9.,10./
      DATA FVM/1.,.995,.95,.943,.9,.868,.85,.8,.75,.712,.7,.65,.6
     &,.55,.5,.45,.4,.357,.35,.3,.25,.216,.2,.165,.15,.13,.114,.101/
      FES=0.
      FVS=0.
      FAS = 0.
      IF(IWARN.EQ.1)GO TO 15
      KEY=1
5     CONTINUE
         KEY=KEY+1
      IF(MRM(KEY).LT.XXMRS) GO TO 5
      DELTAX=MRM(KEY)-MRM(KEY-1)
      DELTAY=FVM(KEY)-FVM(KEY-1)
      FVS=((XXMRS-MRM(KEY-1))/DELTAX)*DELTAY+FVM(KEY-1)
      FAS = FVS
      GO TO 20
15    CONTINUE
         J=1
10       CONTINUE
         J=J+1
         IF(XXMRS.GE.MRSM(J)) GO TO 10
         DX= MRSM(J-1)-MRSM(J)
         DY= FESM(J-1)-FESM(J)
         FES=((XXMRS-MRSM(J-1))/DX)*DY+FESM(J-1)
         FAS = FES
20     CONTINUE
         RETURN
         END
      SUBROUTINE ESRAVG(IFSS,IFVS,IFES,IEAS,IEPS,ICSS,ICAS,A,B,C,D,E,F,
     &AV,AP,PKH)
C*********************************************************************
C****** VULNERABLE AREA AND P(K/H) VS A/A GUNS **********************
C*********************************************************************
       DIMENSION XFE(8),XEA(2)
       DATA XFE/2.,3.,4.,6.,8.,12.,16.,32./
       DATA XEA/2.,1./
      AV = 0.
      AP = 0.
      PKH = 0.
      AF= 51.8325 - .00066C995*A*C + 80.0219*A*D +.000026905*B*C
     &          -1.43074*B*D + .000000105459*C*C - .00228477*C*D
     &          -.C000C651251*C*E + .636887*D*E + .0181204*D*F
     &          -.C0143276*E*E -.0000026265*F*E
      AS= 1019.17 - .01405*C -1693.35*D -2.74121*A*B +462.21*A*D
     &          +.000171723*B*C +1.77235*B*D -.0314528*B*E
     &          +.C000CC038CC12*C*C -.000246121*C*E + 404.036*D*D
     &          +4.69676*D*E +.100098*D*F -.00352892*E*E
```

```
      AB= 1836.72 -25.1442*B +305.998*A*C +5.49718*A*E +.0679002*B*B
     &          +.CCCCOC134505*C*C -.0227707*C*D -.0000872573*C*E
     &          +.2092535*D*F -.00127764*E*F
      AP = ( AF + AS + AB ) / 3.
      WES = 16652. + 23272.2*A*D +.0C0482062*C*C -171.969*B*D
     &          -.27622*C*D +.0295446*E*F
      FRS = 67207.8 -163392.*D +7.17334*F -73.9527*A*B +10009.5*A*D
     &          +144.856*A*E +.0060909*B*C -.051024*B*F +.0000587143*C*C
C- #1 ---------------------------------------------------------------
     &          -.858783*C*D -.0023968*C*F +105140.*D*D -.0262439*E*F
           FT = .6 * FRS
C************ SET UP VALUES ***************************************
           FS = FLCAT(IFSS)
           FV = FLCAT(IFVS)
           FE = XFE(IFES) * FT * .001
           EA = XEA(IEAS) * WES * .001
           EP = FLCAT(IEPS)
           CS = FLCAT(ICSS)
           CA = FLCAT(ICAS)
C************ CALCULATE VULNERABLE AREA ***************************
      AV     = 41.56 - 2.244*ALOG(FE) - 4.373*ALOG(FV) - 4.732*ALOG(FS)
     &           - 5.009*ALOG(CS) + 5.946*ALOG(EA) - 2.491*ALOG(CA)
     &           + 16.44*ALOG(FT*.001) - 47.503 * ALOG(EP)
C************ CALCULATE P(K/H) ************************************
           PKH    = AV/AP
       RETURN
       END
      SUBROUTINE ESRAVM(IFSS,IFVS,AP,AVMS,PKHSMS)
C*******************************************************************
C********VULNERABLE AREA AND P(K/H) VS AA IR MISSILE ***************
C*******************************************************************
C************ SET UP VALUES ***************************************
           F1= 0.
           F2= 0.
           F3= 0.
           F4= 0.
           IF(IFSS.GE.3)                                    F1 = 1.
           IF((IFSS.NE.1).ANC.(IFSS.NE.3).AND.(IFSS.NE.6)) F2 = 1.
           IF((IFVS.EQ.3).OR.(IFVS.EQ.4).OR.(IFVS.EQ.6)) F3 = 1.
           IF((IFVS.EQ.5).OR.(IFVS.EQ.6))                   F4 = 1.
C************ CALCULATE PK/H VS SAM ********************************
             ITF = INT(F1+F2+F3+F4)
             GO TC (1C,2C,30,40),ITF
1              PKHSMS = .675
             GC TC 50
10             PKHSMS = F1*.671 + F2*.673 + F3*.648 + F4*.560
             GO TO 50
20             PKHSMS = F1*F2*.670 + F1*F3*.640 + F1*F4*.610 +
```

```
     &                    F2*F3*.644 + F2*F4*.616 + F3*F4*.485
               GO TO 50
30               PKHSMS = F1*F2*F3*.637 + F1*F2*F4*.606 +
     &                    F1*F3*F4*.448 + F2*F3*F4*.460
               GO TO 50
40               PKHSMS = .423
50             CONTINUE
C************* CALCULATE VULN AREA VS SAM ***************************
               AVMS = PKHSMS*AP
          RETURN
          END
          SUBROUTINE ESRAVS(IFSS,IFVS,AP,AV,PKHSAM)
C*****************************************************************
C*************  VULNERABLE AREA VS LOW ALTITUDE SAM ***************
C*****************************************************************
C************* SET UP VALUES ************************************
            F1 = 0.
            F2 = 0.
            F3 = 0.
            F4 = 0.
             IF(IFSS.GE.3)                                    F1 = 1.
             IF((IFSS.NE.1).AND.(IFSS.NE.3).AND.(IFSS.NE.6)) F2 = 1.
             IF((IFVS.EQ.3).OR.(IFVS.EQ.4).OR.(IFVS.EQ.6)) F3 = 1.
             IF((IFVS.EQ.5).OR.(IFVS.EQ.6))                   F4 = 1.
C************* CALCULATE PK/H VS SAM ********************************
               ITF = INT(F1+F2+F3+F4)
               GO TO (10,20,30,40),ITF
1                PKHSAM = .9934
               GO TO 50
10               PKHSAM = F1*.940 + F2*.964 + F3*.898 + F4*.789
               GO TO 50
20               PKHSAM = F1*F2*.928 + F1*F3*.711 + F1*F4*.880 +
     &                    F2*F3*.783 + F2*F4*.904 + F3*F4*.747
               GO TO 50
30               PKHSAM = F1*F2*F3*.633 + F1*F2*F4*.861 +
     &                    F1*F3*F4*.518 + F2*F3*F4*.494
               GO TO 50
40               PKHSAM = .292
50             CONTINUE
C************* CALCULATE VULN AREA VS SAM ***************************
               AV = PKHSAM * AP
          RETURN
          END
          SUBROUTINE SORT(
C*****************************************************************
C******* SORTIE ANALYSIS *****************************************
C*****************************************************************
     &XL1,XH1,D1,PKH1,PS1,  XL2,XH2,D2,PKH2,PS2, XL3,XH3,D3,PKH3,PS3,
```

```
     &ACR1,NSRT,XNPAS,NS,          ACR2,TOTSR,TOTACK,TOTACL,TOTACR)
          ACR2 = 0.
          TOTSR = 0.
          TOTACK = 0.
          TOTACL = 0.
          TOTACR = 0.
          ACCAM=0.
          W1 = XL1 * XH1 * D1 / 100.
          W2 = XL2 * XH2 * D2 / 100.
          W3 = XL3 * XH3 * D3 / 100.
C
          PSM1 = PS1 ** W1
          PSM2 = PS2 ** W2
          PSM3 = PS3 ** W3
C
          PH1 = (1. - PSM1)/PKH1
          PH2 = (1. - PSM2)/PKH2
          PH3 = (1. - PSM3)/PKH3
C*****************INGRESS*****************************************
C**************THREAT 1**************
               H1 = ACR1 * PH1
               XK1 = H1 * PKH1
               A1 = H1 - XK1
C**************THREAT 2**************
                  H2 = (ACR1-H1) * PH2
                  XK2 = H2 * PKH2
                  A2 = H2 - XK2
C**************THREAT 3**************
                     H3 = (ACR1-H1-H2) * PH3
                     XK3 = H3 * PKH3
                     A3 = H3 - XK3
C***************OVER TARGET*************
               ACOVER = ACR1-H1-H2-H3
               ATAC = ACOVER * XNPAS
C***************EGRESS*****************
C**************THREAT 1**************
               H4 = ACOVER * PH1
               XK4 = H4 * PKH1
               A4 = H4 - XK4
C**************THREAT 2**************
                  H5 = (ACOVER-H4) * PH2
                  XK5 = H5 * PKH2
                  A5 = H5 - XK5
C**************THREAT 3**************
C - #1 ----------------------------------------------------------------
                     H6 = (ACOVER-H4-H5) * PH3
                     XK6 = H6 * PKH3
                     A6 = H6 - XK6
```

AD-A128 203 CORRECTIONS AND IMPROVEMENTS TO THE INTERACTIVE COMPUTER PROGRAM FOR THE..(U) NAVAL POSTGRADUATE SCHOOL MONTEREY CA R M HILL MAR 83 2/2

UNCLASSIFIED F/G 9/2 NL





```
C***************TOTALS FOR SORTIE********
                ACNHT = ACR1-H1-H2-H3-H4-H5-H6
                ACDAM = A1 + A2 + A3 + A4 + A5 + A6
                ACKIL = XK1 + XK2 + XK3 + XK4 + XK5 + XK6
C**************FOR NEXT SORTIE***********
                      ACR2 = ACNHT
                      TOTSR = ACR1
                      TOTACK = ATAC
                      TOTACL = ACKIL
                      TOTACR = ACDAM
        RETURN
          END
        SUBROUTINE CAMP(
     &XL1,XH1,D1,PKH1,PS1,   XL2,XH2,D2,PKH2,PS2,  XL3,XH3,D3,PKH3,PS3,
     &ACR1,NSRT,XNPAS,NS,                ACR2,TOTSR,TOTACK,TOTACL,TOTACR)
C*************************************************************************
C       XL-PENDIS      H-THREAT DENSITY     D- THREAT DIAMETER
C
C*************************************************************************
          INTEGER NSRT,NS
        DIMENSION ACR(200)
          TOTSR  = 0.
          TOTACK = 0.
          TOTACL = 0.
          TOTACR = 0.
          ACDAM=0.
C
        W1 = XL1 * XH1 * D1 / 100.
        W2 = XL2 * XH2 * D2 / 100.
        W3 = XL3 * XH3 * D3 / 100.
C
        PSM1 = PS1 ** W1
        PSM2 = PS2 ** W2
        PSM3 = PS3 ** W3
C
        PH1 = (1. - PSM1)/PKH1
        PH2 = (1. - PSM2)/PKH2
        PH3 = (1. - PSM3)/PKH3
C
       ACR(1)= ACR1
       DO 10 I = 1,NSRT
C**************INGRESS****************
            H1 = ACR(I) * PH1
            XK1 = H1 * PKH1
            A1 = H1 - XK1
               H2 = (ACR(I)-H1) * PH2
               XK2 = H2 * PKH2
               A2 = H2 - XK2
```

```
                    H3 = (ACR(I)-H1-H2) * PH3
                    XK3 = H3 * PKH3
                    A3 = H3 - XK3
C***************OVER TARGET**************
                  ACOVER = ACR(I)-H1-H2-H3
                  ATAC = ACOVER * XNPAS
C***************EGRESS*****************
                H4 = ACOVER * PH1
                XK4 = H4 * PKH1
                A4 = H4 - XK4
                   H5 = (ACOVER-H4) * PH2
                   XK5 = H5 * PKH2
                   A5 = H5 - XK5
C- #1 ------------------------------------------------------------------
                    H6 = (ACOVER-H4-H5) * PH3
                    XK6 = H6 * PKH3
                    A6 = H6 - XK6
C***************TOTALS FOR SORTIE********
                ACNHT = ACR(I)-H1-H2-H3-H4-H5-H6
                ACDAM = A1 + A2 + A3 + A4 + A5 + A6
                ACKIL = XK1 + XK2 + XK3 + XK4 + XK5 + XK6
C***************FOR NEXT SORTIE**********
                    TOTACR = TOTACR+ACDAM
                    ACROUT = TOTACR/FLOAT(NS)
                    TOTACR = TOTACR-ACROUT
                    ACR(I+1) = ACNHT + ACROUT
                    ACR2 = ACR(I+1)
                    TOTSR = TOTSR + ACR(I)
                    TOTACK = TOTACK + ATAC
                    TOTACL = TOTACL + ACKIL
10          CONTINUE
          RETURN
            END
            SUBROUTINE ESRWT(SPAN,W,DL,EC,ED,EL,TW,WS,WT,XL,ICA,ICS,IEA,
C*****************************************************************************
C********* TOGW CALCULATION SUBROUTINE ***************************************
C*****************************************************************************
      a     IEP,IFE,IFS,IFV,JAM,IRCS,XMDA,XMDM,XMDD,IRJAM,IRSUP,IWARN,
      a     ICHAFF,IRFLAR,BLTOGW,TOGW)
            REAL A,B,C,D,E,F,G,H,I,J
            A = TW
            B = WS
            C = XMDA
            D = XMDM
            E = XMDC
            F = WT
            G = 0.
            H = 0.
```

```
            I = 0.
            J = 0.
C*****************************************************************************
      BLTOGW    = .223614E+05 - .324752E+01*H -.949382E+05*J -.25362*A*C
     a+.241287E+05*A*D +.214144E+03*A*E +.36411E+01*A*H +.51498E+05*A*I
     a+.130783E-01*B*C-.46815E+03*B*E -.237024E+05*B*G +.691265E-05*C*C
     a-.118548E+01*C*D -.483582E-02*C*E -.296972E+02*C*G+.147131E+05*D*D
     a+.108228E+02*D*F +.612094E+07*D*G +.366191E+01*D*H-.550071E+05*D*I
     a+.148915E+06*D*J -.238375E-01*E*F+.152377E+05*E*G +.907909E-02*E*H
     a-.378503E+03*E*I +.359190E+03*E*J-.917125E-03*F*F -.205186E+04*F*G
     a+.165260E+08*G*G +.111890E+03*G*H-.265987E+07*G*I +.592438E+07*G*J
     a-.637399E-04*H*H +.620790E+01*H*J

C*****************************************************************************
C          A/C TOGW OF DESIGN WITH SURVIVABILITY ENHANCEMENT
C*****************************************************************************
C          THE FOLLOWING ASSUMPTION MADE;
C              ALL SELF-SEALING DONE FOR 23 MM
C              TWO WING TANKS, FOUR FUSELAGE TANKS, PLUS SUMP TANK(S)
C              DUAL SUMP TANKS HAVE EQUAL VOLUMN OF SINGLE SUMP TANK
C              EACH TANK HOLDS 1/7 OF TOTAL VOLUMN
C              INTERNAL FOAM USE VICE ULLAGE INERTING
C              FIRE EXTINGUSHING VICE EXTERNAL FOAM
C*****************************************************************************
              IF(JAM.EQ.0) GO TO 40
                 G = .8675 * WS / BLTOGW
40            CONTINUE
C?????????????????????????????????????????????????????????????????????????*
C***      TEMP FIX ON G ****************************************************
                 G=0.
              IF(IRSUP.NE.2) GO TO 50
                 I = .05
                 J = .05
50            CONTINUE
C*****************************************************************************
C        WEIGHT INCREASE CALCULATIONS
C*****************************************************************************
C******  FR = FUEL REQUIRED FOR MISSION ******************************
      FR =.672078E+05 -.163392E+06*D +.717334E+01*F-.782443E+05*I
     a-.739527E+02*A*B +.100095E+05*A*D +.144856E+03*A*E+.159256E+01*A*H
     a+.476609E+05*A*I -.431972E+05*A*J +.609094E-02*B*C-.510240E-01*B*F
     a-.238850E+05*B*G +.587143E-05*C*C -.858783E+00*C*D-.239668E-02*C*E
     a-.273454E+02*C*G -.153966E-04*C*H +.951930E+00*C*I+.105140E+06*D*D
     a+.265033E+07*D*G +.698039E+05*D*J -.262439E-01*E*F+.646932E+04*E*G
     a+.265667E+03*E*J +.170282E+08*G*G +.426677E+02*G*H-.232114E+07*G*I
     a+.281936E+07*G*J -.184747E-04*H*H +.214433E+01*H*J
C******* WEIGHT INCREASE DUE TO SELF-SEALING **********************
              XNT = 2.
```

```
          IF((IFS.EQ.1).OR.(IFS.EQ.3).OR.(IFS.EQ.6)) XNT = 0.
          IF(IFS.EQ.2) XNT = 1.
      WSSP = 1.49*(2.2*8./7.-1.)*(1./7.)**.75*(FR/6.6)**.64*XNT**.11
C****** WEIGHT INCREASE DUE TO INTERNAL FOAM **********************
      WF = 0.
          IF((IFV.EQ.4).OR.(IFV.EQ.6)) WF = .0186 * FR/6.6
C****** WEIGHT INCREASE DUE TO FIRE EXTINGUISHING ******************
      WFE = 0.
          XV = 4./3. * ( ED + 1.) * EC * EL
          IF((IFV.EQ.5).OR.(IFV.EQ.6)) WFE = 10.5 * XV**.26
C****** WEIGHT INCREASE DUE TO DUCT PROTECTION *********************
      XND = 1.
      WBB= 0.
      IF(IFE.EQ.2) XND = 2.
      XS = CL * EC * XND * .5
      IF((IFE.EQ.2).OR.(IFE.EQ.4).OR.(IFE.EQ.6)) WBB = 7.6 * XS
C****** WEIGHT INCREASE DUE TO ARMOR ******************************
      AD = 0.
          IF(ICA.EQ.2) AD = 10.
          IF((ICA.EQ.3).OR.(ICA.EQ.4)) AD = 18.
          IF((ICA.EQ.5).OR.(ICA.EQ.6)) AD = 30.
          WARM = 12. * AD
C****** WEIGHT INCREASE DUE TO ENGINE SEPERATION*******************
          XEB = 0.
          IF(IEA.EQ.1) XEB = 0.
          IF(IEA.EQ.2) XEB = 4.
          IF(IEP.EQ.2) XEB = 6.
          XA = ED/2. * 12.
          XT = TW * ( BLTOGW - FR ) * .5
          XH = 1.23 * XA
          XN = 11.
          WENG = 2000.
C- #1 ------------------------------------------------------------------
      WES =(1.264 + .034 * XA * XT * XH)*(WENG * XN * XA * XEB *1.0E-10)
C****** WEIGHT INCREASE DUE TO RAM **********************************
          XTT = .1
          XS = 0.
          IF(IRCS.EQ.1) XS = 10.
          IF((IRCS.EQ.2).OR.(IRCS.EQ.3)) XS = 20.
          IF(IRCS.EQ.4) XS = 60.
          IF(IRCS.EQ.5) XS = 60. + BLTOGW/WS *.69
          IF(IRCS.EQ.6) XS = 75. + BLTOGW/WS *.69
          WRAM = XTT * XS * 23.8
C****** WEIGHT INCREASE DUE TO REDUNDANT CONTROLS *******************
          BACKUP = 0.
          IF((ICS.EQ.3).OR.(ICS.EQ.4)) BACKUP = 1.
          XLGP = W + EC + SPAN + XL / 2.
          WRED = BACKUP * (2.207 * XLGP  - 4.79)
```

```
C******* WEIGHT INCREASE DUE TO RWR ***********************************
      WEW = 0.
      IF(IWARN.EQ.1) WEW = 50.
C******* WEIGHT INCREASE DUE TO RADAR JAMMER ***************************
      WJW = 0.
      IF(JAM.EC.1) WJW = 80.
      IF(JAM.EC.2) WJW = 100.
      IF(JAM.EC.3) WJW = 200.
      IF(JAM.EC.4) WJW = 500.
      IF(JAM.EC.5) WJW = 1000.
C******* WEIGHT INCREASE DUE TO CHAFF DISPENSER ************************
      WCD = 0.
      IF(ICHAFF.EQ.1) WCD = 86.
C******* WEIGHT INCREASE DUE TO IR FLARE DISPENSER *********************
      WFD = 0.
      IF(IRFLAR.EQ.1) WFD = 86.
C******* WEIGHT INCREASE DUE TO SUBMERGED STORE ************************
      WSOR = 0.
      IF((IRCS.EQ.5).OR.(IRCS.EQ.6)) WSOR = 1.13 * WT/100.
C******* WEIGHT INCREASE DUE TO COOLED IR PLUG **********************
      WPLG = 0.
      IF(IRSUP.EQ.2) WPLG = .01012 * EC**2
C******* WEIGHT INCREASE DUE TO AEROSOL INJECTER ********************
      WAI = 0.
      IF(IRSUP.EQ.1) WAI = 200.
C******* WEIGHT INCREASE DUE TO IR JAMMER ***************************
      WIRJ = 0.
      IF(IRJAM.EQ.1) WIRJ = 200.
C*************************************************************************
C******* TOTAL WEIGHT INCREASE ***************************************
        H =  WSSP+WF+WFE+WBE+WARM+WES+WRAM+WRED+WEW+WJW+WCD+WFD
     @      +WSOR+WPLG+WAI+WIRJ
C*************************************************************************
C******* TOTAL TOGW OF ENHANCED A/C***********************************
C*************************************************************************
      TOGW= .223614E+05 - .324752E+01*H -.949382E+05*J -.25362*A*C
     @+.241287E+05*A*D +.214144E+03*A*E +.36411E+01*A*H +.51498E+05*A*I
     @+.130783E-01*B*C-.46815E+03*B*D -.237024E+05*B*G +.691265E-05*C*C
     @-.118548E+01*C*D -.483582E-02*C*E -.296972E+02*C*G+.147131E+05*D*D
     @+.108228E+02*D*F +.612094E+07*D*G +.366191E+01*D*H-.55J071E+05*D*I
     @+.148915E+06*D*J -.238375E-01*E*F+.152377E+05*E*G +.907909E-02*E*H
     @-.378503E+03*E*I +.359190E+03*E*J-.917125E-03*F*F -.205186E+04*F*G
     @+.165260E+08*G*G +.111890E+03*G*H-.265987E+07*G*I +.592438E+07*G*J
     @-.637399E-04*H*H +.620790E+01*H*J
        RETURN
        END
```

```
C**********************************************************************
C**                                                                  **
C**      ESCPLT < ESCORT PLT >                                       **
C**      PROGRAM TO GRAPH P(K)'S VS. THREATS AGAINST                 **
C**      FIGHTER ESCORT AIRCRAFT                                     **
C**                                                                  **
C**********************************************************************
      DIMENSION YC(3),Y1(3),Y2(3),Y3(3),XO(3),IPKRAY(400)
     *          ,LABEL(20)
      DATA LABEL/' ',' ',' ',' ',' ',' ','A/A ','GUNS',' ',' ',
     *           'A/A ','MISS','ILE ',' ',' ',
     *           'SAM ',' ',' ',' ',' ',' ',' ',' ',' ',' '/
      DATA YO/0.,0.,0./
      DATA XO/1.,2.,3./
C
      READ(7,700)(Y1(I),I=1,3),(Y2(I),I=1,3),(Y3(I),I=1,3)
  700 FORMAT(F4.2)
C
      CALL TEK618
      CALL HWROT('MOVIE')
      CALL BLOWUP (1.4)
      CALL PAGE(8.5,11.)
      CALL NCBRDR
      CALL AREA2D(6.,8.5)
      CALL XNAME('THREATS$',100)
      CALL YNAME('P(K)$',100)
      CALL SWISSM
      CALL SHDCHR(90.,1.,.003,1)
      CALL BASALF('STAND')
      CALL MIXALF('L/CSTD')
      CALL HEADIN('FIGHTER ESCORT AIRCRAFT$',100,1.5,2)
      CALL HEADIN('L(OSS) R(ATE) VS. T(HREAT) T(YPE)$',100,1.1,2)
      CALL YREVTK
      CALL YAXANG(0.)
      CALL XTICKS(0)
      CALL XAXEND('NOENDS')
      CALL YAXEND('NOLAST')
      CALL SWISSL
      CALL HEIGHT(.12)
      CALL FRAME
      CALL THKFRM(.10)
      CALL XLABGR(LABEL,4,5.0,.1,1.1)
      CALL BLREC(0.01,8.1,4.29,0.6,0)
      CALL BLREC(4.3,7.7,1.7,1.0,0)
      CALL BLKEY(ID)
      CALL CLUSTR(3,.06)
      CALL HEIGHT(.08)
      CALL BARDOC('SECOND','OUTSIDE',2)
```

```
CALL BLBAR
CALL VBARS('LABEL',Y0,Y1,3)
CALL VBARS('LABEL',Y0,Y2,3)
CALL VBARS('LABEL',Y0,Y3,3)
CALL HEIGHT(.05)
CALL DCT
CALL GRID(0,2)
CALL RESET('DOT')
CALL HEIGHT(.10)
CALL BLOFF(IC)
MAXLIN=LINEST(IPKRAY,400,40)
CALL LINES('B(ASELINE)$',IPKRAY,1)
CALL LINES('1ST D(ESIGN)$',IPKRAY,2)
CALL LINES('2ND D(ESIGN)$',IPKRAY,3)
CALL LEGEND(IPKRAY,3,4.5,7.6)
CALL ENDPL(C)
CALL DONEPL
STOP
END
```

```
C*****************************************************************************
C**                                                                         **
C**      STRIKE                                                             **
C**      PROGRAM TC ASSESS LONG RANGE STRIKE AIRCRAFT SURVIVABILITY         **
C**                                                                         **
C*****************************************************************************
C
C             LONG RANGE STRIKE AIRCRAFT
C
C  THESE LINE NUMBERS ARE FOR EASY REFERENCE
C       MAIN MENU                                    1, 100, 1001
C       AIRCRAFT DESIGN SELECTION                    2, 110, 1110
C          A/C PERFORMANCE INDICATOR S               21, 210, 1210
C          SUSCEPTIBILITY FEATURES                   22, 220, 1220
C          JAMMERS 221   RCS 222   RWR 223   CHAFF 224
C          VULNERABILITY FEATURES                    23, 230, 1230
C        COMBAT SCENARIO SELECTION                    3, 120, 1120
C          MISSION PROFILE                           31, 310, 1310
C          THREAT SELECTION                          32, 320, 1320
C        SUSCEPTIBILITY ASSESMENT                     4, 130, 1130
C          PROBABILITY OF DETECTION                  41, 410, 1410
C          PROBABILITY OF HIT                        42, 420, 1420
C                  VS A/A (RADAR MISSILE)                421
C                  VS HIGH ALT SAM                       423
C         VULNERABILITY ASSESMENT                     5, 140, 1140
C                  VULN AREA VS A/A MISSILE              510
C                  VULN AREA VS SAM                      520
C         SURVIVABILITY ASSESMENT                     6, 150, 1150
C           P(S) 1:1 A/A (RADAR MISSILE)                610, 618
C           P(S) 1:1 HIGH ALT SAM                       630, 638
C           SINGLE SORTIE                               640, 1640
C           CAMPAIGN EVALUATION                         650, 1650
C         HELP                                          997X
C         TRANFER                                       998
C         EXIT                                          999
C             SUBROUTINE NAMES AND LINE NUMBERS
C              SSRPDA        475    1000
C              SSRPDS        496    1007
C              SSRPHR        538    1055
C              SSRPHS        560    1076
C              SRFA    1067/1085    1094
C              SRFC    1064/1082    1127
C              SSRAVA        580    1138
C              SSRAVS        603    1170
C              SORT          689    1237
C              CAMP          775    1297
C       IMPLICIT REAL*4(A-H,O-Z),INTEGER*4(I-N)
C
```

```
      DIMENSION KK(4),K1(6),K2(3),K3(2),K4(2),K5(2),K6(4),
C- #5 ------------------------------------------------------------------
     *          JJ(2),PKAR(3),PKSM(3)
C
      DATA K1/'DE','MS','SA','VA','SV','MM'/
      DATA K2/'AP','SF','VF'/
      DATA K3/'MP','TH'/
      DATA K4/'FD','PH'/
      DATA K5/'KH','KD'/
      DATA K6/'AR','HS','SS','CE'/
      DATA KK/'HP','TN','EX','RT'/
C- #5 ------------------------------------------------------------------
      DATA JJ/'Y','N'/
C
C- #3 ------------------------------------------------------------------
C************ TO SAVE DATA ***************************************
C
      CALL FRTCMS('CLRSCRN ')
      WRITE(4,1010)
1010  FORMAT(' ','DATA MODE SELECTION, ENTER A CODE AS FOLLOWS:'//
     *T6,'IF THIS IS YOUR FIRST TIME THRCUGH STRIKE OR IF YOU WISH'/
     *T6,'TC USE THE CEFAULT VALUES/PARAMETERS ENTER...0 '//
     *T6,'TO USE CATA SAVED FROM YOUR LAST RUN ENTER...1 '///
     *T20,'WARNING'//
     *T6,'--CO NOT ENTER 1 IF THIS IS YOUR FIRST RUN OR IF YOU HAVE'/
     *T6,'ERASED YOUR STRIKE DATA FILE FRCM YOUR DISK--'/)
C
      READ(4,1011)I1
1011  FORMAT(I1)
      IF(I1.EQ.0)GC TO 1021
      IF(I1.EQ.1)GC TO 1022
1022  CONTINUE
      REWIND 2
      READ(2,1012)TW,WS,WT,EC,EL,ES,JAM,IRCS,IWARN,ICHAFF,IFS,
     *       IFV,XMD,XMA,XMM,DSR,SAMH,SAMC,AAH,AAD,
     *       PDAR,PDSM,PHAR,PHSM,AVAA,PKHAA,VASM,PKHSM,PSAR,
     *       PSSM,ACR,X1NPAS,ACR1,NSRT,XNPASS,NS,
     *       ACR2,TOTSR,TOTACK,TOTACL,TOTACR,BLTOGW,TOGW
1012  FORMAT(' ',5G12.4)
      GO TO 1
C*****************************************************************
1021  CONTINUE
      DATA TW/1.0/,WS/105./,WT/4000./,EC/3.5/,EL/9.0/,ES/7.0/
      DATA JAM/0/,IRCS/0/,IWARN/0/,ICHAFF/0/
      DATA IFS/1/,IFV/1/
      DATA XMD/200./,XMA/40000./,XMM/1.8/,DSR/9.31/
      DATA SAMH/.0017/,SAMD/20./,AAH/.01/,AAD/4./
      DATA PDAR/.9900/,PDSM/.9947/
```

```
      DATA PHAR/.9989/,PHSM/.9103/
      DATA AVAA/600./,PKHAA/1./,VASM/600./,PKHSM/1./
      DATA PSAR/.0111/,PSSM/.0995/
C- #3 ------------------------------------------------------------------
      DATA ACR/100./,X1NPAS/1./
      DATA ACR1/100./,NSRT/20/,XNPASS/1./,NS/4/
      DATA ACR2/0.00/,TOTSR/154.57/,TOTACK/91.84/,TOTACL/100.00/
      DATA TCTACR/0.00/,BLTCGW/64071.66/,TOGW/64071.66/
C- #5 ------------------------------------------------------------------
      DATA N/0/
C*********************************************************************
C     MAIN MENU DISPLAY
C*********************************************************************
100       CONTINUE
1         CONTINUE
        CALL FRTCMS('CLRSCRN ')
      WRITE(4,1001)
1001  FORMAT('1','STRIKE MENU (1) SELECT A CODE AS FOLLOWS:'//
     +T6,'FOR AN EXPLANATION           ',T51,'HP'/
     +T6,'AIRCRAFT DESIGN SELECTION    ',T51,'DE'/
     +T6,'COMBAT SCENARIO SELECTION    ',T51,'MS'/
     +T6,'SUSCEPTIBILITY ASSESSMENT    ',T51,'SA'/
     +T6,'VULNERABILITY ASSESSMENT     ',T51,'VA'/
     +T6,'SURVIVABILITY ASSESSMENT     ',T51,'SV'/
     +T6,'TO TRANSFER TO OTHER MENUS   ',T51,'TN'/
     +T6,'TO EXIT OR PRINT RESULTS     ',T51,'EX'/)
      READ(5,2000) K1Q
2000  FORMAT(A4)
      IF(K1Q.EQ.K1(1)) GO TO 110
      IF(K1Q.EQ.K1(2)) GO TO 120
      IF(K1Q.EQ.K1(3)) GO TO 130
      IF(K1Q.EQ.K1(4)) GO TO 140
      IF(K1Q.EQ.K1(5)) GO TO 150
      IF(K1Q.EQ.KK(1)) GO TO 9971
      IF(K1Q.EQ.KK(2)) GO TO 998
C- #3 ------------------------------------------------------------------
      IF(K1Q.EQ.KK(3)) GO TO 1061
      WRITE(4,1200)
1200  FORMAT(' ','INPUT ERROR. REPEAT INPUT')
      GO TO 1
C*********************************************************************
C     MENU 2  DESIGN
C*********************************************************************
110     CALL FRTCMS('CLRSCRN ')
2         CONTINUE
      WRITE (4,1110)
1110  FORMAT('1','MENU (2) DESIGN, ENTER  A CODE AS FOLLOWS:'//
     +T6,'FOR AN EXPLANATION           ',T51,'HP'/
```

```
     +T6,'A/C PERFORMANCE INDICATORS  ',T51,'AP'/
     +T6,'SUSCEPTIBILITY FEATURES     ',T51,'SF'/
     +T6,'VULNERABILITY FEATURES      ',T51,'VF'/
     +T6,'TO RETURN TO MENU (1)       ',T51,'RT'/
     +T6,'TO TRANSFER TO OTHER MENUS  ',T51,'TN'/)
      READ(5,2000) K2Q
      IF(K2Q.EQ.K2(1)) GO TO 210
      IF(K2Q.EQ.K2(2)) GO TO 220
      IF(K2Q.EQ.K2(3)) GO TO 230
      IF(K2Q.EQ.KK(1)) GO TO 9972
      IF(K2Q.EQ.KK(2)) GO TO 998
C- #3 ------------------------------------------------------------------
      IF(K2Q.EQ.KK(4)) GO TO 7
      WRITE(4,1200)
      GO TO 2
C*****************************************************************
C     MENU 3  COMBAT SCENARIO
C*****************************************************************
120     CALL FRTCMS('CLRSCRN ')
3       CONTINUE
      WRITE (4,1120)
1120  FORMAT('1','MENU (3) COMBAT SCENARIO, ENTER A CODE AS FOLLOWS:'//
     +T6,'FOR AN EXPLANATION          ',T51,'HP'/
     +T6,'MISSION PROFILE             ',T51,'MP'/
     +T6,'THREAT SELECTION            ',T51,'TH'/
     +T6,'TO RETURN TO MENU (1)       ',T51,'RT'/
     +T6,'TO TRANSFER TO OTHER MENUS  ',T51,'TN'/)
      READ(5,2000) K3Q
      IF(K3Q.EQ.K3(1)) GO TO 310
      IF(K3Q.EQ.K3(2)) GO TO 320
      IF(K3Q.EQ.KK(1)) GO TO 9973
      IF(K3Q.EQ.KK(2)) GO TO 998
C- #3 ------------------------------------------------------------------
      IF(K3Q.EQ.KK(4)) GO TO 7
      WRITE(4,1200)
      GO TO 3
C*****************************************************************
C     MENU 4  SUCEPTIBILITY ASSESMENT
C*****************************************************************
130     CALL FRTCMS('CLRSCRN ')
4       CONTINUE
      WRITE (4,1130)
1130  FORMAT('1','MENU (4) SUCEPTIBILITY ASSESSMENT,'//
     *T6,'ENTER A CODE AS FOLLOWS:'//
     +T6,'FOR AN EXPLANATION          ',T51,'HP'/
     +T6,'PROBABILITY OF DETECTION    ',T51,'PD'/
     +T6,'PROBABILITY OF HIT          ',T51,'PH'/
     +T6,'TO RETURN TO MENU (1)       ',T51,'RT'/
```

```
     +T6,'TC TRANSFER TO OTHER MENUS  ',T51,'TN'/)
      READ(5,2000) K4Q
      IF(K4Q.EQ.K4(1)) GO TO 410
      IF(K4Q.EQ.K4(2)) GO TO 420
      IF(K4Q.EQ.KK(1)) GO TO 9974
      IF(K4Q.EQ.KK(2)) GO TO 998
C-  #3 ------------------------------------------------------------------
      IF(K4Q.EQ.KK(4)) GO TO 7
      WRITE(4,1200)
      GO TO 4
C*****************************************************************
C     MENU 5  VULNERABILITY ASSESMENT
C*****************************************************************
140      CALL FRTCMS('CLRSCRN ')
5        CONTINUE
      WRITE (4,1140)
1140  FORMAT('1','MENU (5) VULNERABILITY ASSESSMENT,'//
     *T6,'ENTER A CODE AS FOLLOWS:'//
     +T6,'FOR AN EXPLANATION          ',T51,'HP'/
     +T6,'VULN AREA & P(K/H) VS A/A MISSILE  ',T51,'KH'/
     +T6,'VULN AREA & P(K/D) VS SAM   ',T51,'KD'/
     +T6,'TC RETURN TO MENU (1)       ',T51,'RT'/
     +T6,'TO TRANSFER TO OTHER MENUS  ',T51,'TN'/)
      READ(5,2000,ERR=1061) K5Q
      IF(K5Q.EQ.K5(1)) GO TO 510
      IF(K5Q.EQ.K5(2)) GO TO 520
      IF(K5Q.EQ.KK(1)) GO TO 9975
      IF(K5Q.EQ.KK(2)) GO TO 998
C-  #3 ------------------------------------------------------------------
      IF(K5Q.EQ.KK(4)) GO TO 7
      WRITE(4,1200)
      GO TO 5
C*****************************************************************
C     MENU 6  SURVIVABILITY ASSESMENT
C*****************************************************************
150      CALL FRTCMS('CLRSCRN ')
6        CONTINUE
      WRITE (4,1150)
1150  FORMAT('1','MENU (6) SURVIVABILITY ASSESSMENT,'//
     *T6,'ENTER A CODE AS FOLLOWS:'//
     +T6,'FOR AN EXPLANATION          ',T51,'HP'/
     +T6,'P(S) 1:1 A/A (RADAR MISSILE)',T51,'AR'/
     +T6,'P(S) 1:1 HIGH ALT SAM       ',T51,'HS'/
     +T6,'SINGLE SORTIE               ',T51,'SS'/
     +T6,'CAMPAIGN EVALUATION         ',T51,'CE'/
     +T6,'TC RETURN TO MENU (1)       ',T51,'RT'/
     +T6,'TO TRANSFER TO OTHER MENUS  ',T51,'TN'/)
      READ(5,2000,ERR=1061) K6Q
```

```
      IF(K6C.EC.KE(1)) GO TC 610
      IF(K6C.EC.KE(2)) GO TO 630
      IF(K6Q.EQ.KE(3)) GC TC 640
      IF(K6Q.EQ.KE(4)) GC TO 650
      IF(K6Q.EQ.KK(1)) GC TC 9978
      IF(K6C.EQ.KK(2)) GO TC 998
C-  #3 ------------------------------------------------------------------
      IF(K6Q.EQ.KK(4)) GC TC 7
      WRITE(4,1200)
      GO TO 6
C
C-  #3 ------------------------------------------------------------------
C*****************************************************************
C**    MENU 7    REASSESSMENT                                   **
C*****************************************************************
  7   CONTINUE
      CALL SSRPDA(JAM,IRCS,PDAR)
      CALL SSRPDS(JAM,IRCS,DSR,PDSM)
      CALL SSRPHR(WS,XMM,XMA,IWARN,ICHAFF,DSR,PHAR)
      CALL SSRPHS(WS,XMM,XMA,IWARN,ICHAFF,DSR,PHSM)
      CALL SSRAVA(IFS,IFV,AVAA,PKHAA)
      CALL SSRAVS(IFS,IFV,JAM,IRCS,VASM,PKHSM)
C
C
      PSAR = 1. - PDAR * PHAR * PKHAA
      PSSM = 1. - PDSM * PHSM * PKHSM
C
      CALL CAMP(XMD,AAH,AAD,PKHAA,PSAR,0.,0.,0.,1.,1.,XMD,
     *          SAMH,SAMD,PKHSM,PSSM,ACR1,NSRT,XNPASS,NS,
     *          ACR2,TOTSR,TCTACK,TOTACL,TCTACR)
C
      GO TO 1
C-  #5 ------------------------------------------------------------------
C*****************************************************************
C**    MENU (8)     ROUTINE TC GENERATE P(K) VALUES FOR PLOTTING  **
C*****************************************************************
    8 CONTINUE
      IF(N.GE.3) GC TO 999
      CALL FRTCMS('CLRNSCRN ')
      WRITE(4,801)N
  801 FORMAT('1',' MENU(8) GRAPH CHOICES'//
     *       T6,'DC YOU WISH TO SAVE P(K) FOR THIS DESIGN?'/
     *       T6,'NCTE:  YCU HAVE ALREADY CHOSEN ',I1,' OF THE',
     *          ' 3 POSSIBLE DESIGNS'/T6,'FCR THIS PLOT.'//
     *       T6,'ENTER A CODE AS FOLLCWS:'/
     *       T6,'   TO SAVE P(K)',T51,'Y'/
     *       T6,'   DO NOT SAVE',T51,'N'/
     *       T6,'   FOR FURTHER EXPLANATICN',T51,'HP')
```

```
C
      READ(4,2000)K8Q
         IF(K8Q.EC.JJ(1)) GC TO 81
         IF(K8Q.EC.JJ(2)) GC TO 999
         IF(K8Q.EC.KK(I)) GC TO 8888
C
      WRITE(4,120C)
      GO TO 8
   81 CONTINUE
         N = N + 1
         PKAR(N) = 1. - PSAR
         PKSM(N) = 1. - PSSM
C
      IF(N.NE.3) GO TO 999
C
      WRITE(8,802)(PKAR(I),PKSM(I),I=1,3)
  802 FORMAT(F4.2)
      GO TO 999
C
C*****************************************************************************
C     MENU 21   A/C PERFORMANCE INPUTS
C*****************************************************************************
210       CALL FRTCMS('CLRSCRN ')
21        CCNTINUE
      WRITE (4,1210)TW,WS,WT,ES,EC,EL
1210  FORMAT('1',      MENU (21) ENTER  A CODE AS FOLLOWS:'//
     +T6,'          A/C PERFORMANCE INDICATORS  '/
     +T6,'1    THRUST TO WEIGHT              ',T51,F6.4/
     +T6,'2    WING LOADING                  ',T51,F6.2,' PSF'/
     +T6,'3    ORDNANCE WEIGHT               ',T51,F6.0,' LBS'/
     +T6,'     ENGINE SEPERATION             ',T51,F6.2,' FT'/
     +T6,'     ENGINE DIAMETER               ',T51,F6.2,' FT'/
     +T6,'     ENGINE LENGTH                 ',T51,F6.2,' FT'//
     +T6,'VALUES 1,2 & 3 ARE VARIABLE; TO CHANGE THEM ENTER ITS NUMBER I
     +N'/T6,'I1 FORMAT. ENTER 0 FOR NO CHANGE REQUIRED')
      READ(5,1211)I1
1211  FORMAT(I1)
      IF(I1.EQ.0) GO TO 110
      GO TO (211,212,213),I1
1212  WRITE(4,1200)
      GO TO 210
211       CCNTINUE
          WRITE(4,1201)
1201      FORMAT('C','      TW RANGE ALLCWED IS .4 TO 1.2'/
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
          READ(5,1202)V1
1202      FORMAT(F5.4)
          TW=V1
```

```
      GO TO 210
212   CONTINUE
      WRITE(4,1203)
1203  FORMAT('0','      WS RANGE ALLOWED IS 90. TO 120.'/
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
      READ(5,1202)V1
      WS=V1
      GO TO 210
213   CONTINUE
      WRITE(4,1204)
1204  FORMAT('0','      WT RANGE ALLOWED IS 1000. TO 14000.'/
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
      READ(5,1202)V1
      WT=V1
      GO TO 210
C*****************************************************************
C     MENU 22  SUSCEPTIBILITY FEATURES
C*****************************************************************
220     CALL FRTCMS('CLRSCRN ')
22    CONTINUE
      WRITE (4,1220)JAM,IRCS,IWARN,ICHAFF
1220  FORMAT('1','      MENU (22) ENTER  A CODE AS FOLLOWS:'//
     +T6,'  SUSCEPTIBILITY REDUCTION FEATURES     '/
     +T6,'1   JAMMER NUMBER              ',T51,I1/
     +T6,'2   RCS REDUCTION LEVEL        ',T51,I1/
     +T6,'3   RADAR WARNING RECEIVER     ',T51,I1/
     +T6,'4   CHAFF DISPENSER            ',T51,I1//
     +T6,'"0" INDICATES NOT INSTALLED "1" INDICATES INSTALLED'//
     +T6,'TO CHANGE A VALUE ENTER ITS NUMBER IN I1 FORMAT'/
     +T6,'ENTER 0 FOR NO CHANGE REQUIRED')
      READ(5,1211)I1
      IF(I1.EQ.0) GO TO 110
      GO TO (221,222,223,224),I1
1229  WRITE(4,1200)
      GO TO 220
221   CONTINUE
      CALL FRTCMS('CLRSCRN ')
      WRITE(4,1221)
1221  FORMAT('1','          JAMMERS AVAILABLE        '//
     +T6,'0                00  ',/
     +T6,'1                50 WATTS',/
     +T6,'2               100 WATTS',/
     +T6,'3               200 WATTS',/
     +T6,'4               500 WATTS',/
     +T6,'5              1000 WATTS',//
     +T6,'ENTER THE JAMMER NUMBER IN I1 FORMAT')
      READ(5,1211)I1
      JAM=I1
```

```
      GO TO 220
222   CONTINUE
      CALL FRTCMS('CLRSCRN ')
      WRITE(4,1222)
1222  FORMAT('0','      RCS REDUCTION LEVELS                '//
     +T6,'0                 NO REDUCTION  ',/
     +T6,'1                 PROCEDURE 1',/
     +T6,'2                 PROCEDURE 2',/
     +T6,'3                 PROCEDURE 1 & 2',/
     +T6,'4                 PROCEDURE 1 & 3',/
     +T6,'5                 PROCEDURE 1,3 & 5',/
     +T6,'6                 PROCEDURE 1,3,5,& 8',/
     +T6,'7                 PROCEDURE 1,3,5,6,7, & 8',/
     +T6,'8                 PROCEDURE 1,4,5,6,7, & 8',//
     +T6,'ENTER THE DESIRED RCS LEVEL IN I1 FORMAT')
      READ(5,1211)I1
      IRCS=I1
      GO TO 220
223   CONTINUE
      WRITE(4,1223)
1223  FORMAT(' ',','      RADAR WARNING RECEIVER              '//
     +T6,'"0" INDICATES NOT INSTALLED, "1" INDICATES INSTALLED'/
     +T6,'ENTER "0" OR "1" IN I1 FORMAT')
      READ(5,1211)I1
      IWARN=I1
      GO TO 220
224   CONTINUE
      WRITE(4,1224)
1224  FORMAT(' ',','      CHAFF DISPENSER                     '//
     +T6,'"0" INDICATES NOT INSTALLED, "1" INDICATES INSTALLED'/
     +T6,'ENTER "0" OR "1" IN I1 FORMAT')
      READ(5,1211)I1
      ICHAFF=I1
      GO TO 220
C*****************************************************************
C     MENU 23  VULNERABILITY FEATURES
C*****************************************************************
230   CALL FRTCMS('CLRSCRN ')
23    CONTINUE
      WRITE (4,1230)IFS,IFV
1230  FORMAT('1',','      MENU (23) ENTER  A CODE AS FOLLOWS:'//
     +T6,'    VULNERABILITY REDUCTION FEATURES  '//
     +T6,'1    FUEL SYSTEM GENERAL      ',T51,I1/
     +T6,'2    FUEL/VOID INTERFACE      ',T51,I1//
     +T6,'"1" MINIMUM PROTECTION '/
     +T6,'TO CHANGE A VALUE ENTER ITS NUMBER IN I1 FORMAT'//
     +T6,'ENTER 0 FOR NO CHANGE REQUIRED')
      READ(5,1211)I1
```

```
      IF(I1.EQ.0) GO TO 110
      GO TO (231,232),I1
1239  WRITE(4,1200)
      GO TO 230
231       CONTINUE
          CALL FRTCMS('CLRSCRN ')
          WRITE(4,1231)
1231  FORMAT('1','          FUEL SYSTEM, GENERAL      '//
     +T6,'1     SINGLE SUMP TANK, NO SELF-SEALING    ',/
     +T6,'2     DUAL SUMP TANKS,  NO SELF-SEALING    ',/
     +T6,'3     SINGLE SUMP TANK, WITH SELF-SEALING  ',/
     +T6,'4     DUAL SUMP TANKS,  WITH SELF-SEALING  ',//
     +T6,'ENTER THE PROTECTION NUMBER IN I1 FORMAT')
          READ(5,1211)I1
          IFS=I1
          GO TO 230
232       CONTINUE
          CALL FRTCMS('CLRSCRN ')
          WRITE(4,1232)
1232  FORMAT('1','          FUEL/VOID INTERFACE       '//
     +T6,'1     TANKS ADJACENT TO DRY BAYS, HIGH SURFACE TEMP',/
     +T6,'2     INTERNAL FUEL TANK FOAM                      ',/
     +T6,'3     ULLAGE INERTING                              ',/
     +T6,'4     VOID SPACE FOAM                              ',/
     +T6,'5     VOID SPACE FIRE EXTINGUISHING                ',/
     +T6,'6     BOTH INTERNAL AND VOID PROTECTION 2 OR 3 & 4 OR 5',//
     +T6,'ENTER THE DESIRED PROTECTION LEVEL IN I1 FORMAT')
          READ(5,1211)I1
          IFV=I1
          GO TO 230
C*****************************************************************
C     MENU 31  MISSION DESCRIPTION
C*****************************************************************
310       CALL FRTCMS('CLRSCRN ')
31        CONTINUE
      WRITE (4,1310)XMD,XMA,XMM
1310  FORMAT('1',T6,'          MENU (31)                    '//
     +T6,'          MISSION DESCRIPTION          '//
     +T6,'1    MISSION PENETRATION DISTANCE ',T51,F6.0,' MI'/
     +T6,'2    MISSION PENETRATION ALTITUDE ',T51,F6.0,' FT'/
     +T6,'3    MISSION PENETRATION MACH     ',T51,F6.4//
     +T6,'TO CHANGE THEM ENTER ITS NUMBER IN I1 FORMAT.'//
     +T6,' ENTER 0 FOR NO CHANGE REQUIRED')
      READ(5,1211)I1
      IF(I1.EQ.0) GO TO 120
      GO TO (311,312,313),I1
1319  WRITE(4,1200)
      GO TO 310
```

```
311       CONTINUE
          WRITE(4,1311)
1311     FORMAT('0','     PENETRATION DISTANCE RANGE 100. TO 1000. NM'//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
          READ(5,1202)V1
          XMC=V1
          GO TO 310
312       CONTINUE
          WRITE(4,1312)
1312  FORMAT('0','     PENETRATION ALTITUDE RANGE 40000 TO 60000. FT'//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
          READ(5,1202)V1
          XMA=V1
          DSR = XMA/4296.4
          GO TO 310
313       CONTINUE
          WRITE(4,1313)
1313      FORMAT('0','     PENETRATION MACH RANGE 1.4 TO 2.2 MACH'//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
          READ(5,1202)V1
          XMM=V1
          GO TO 310
C*****************************************************************
C     MENU 32  THREAT DEFINITION
C*****************************************************************
320       CALL FRTCMS('CLRSCRN ')
32        CONTINUE
      WRITE (4,1320)AAH,AAD,SAMH,SAMC
1320  FORMAT('1','     MENU (32)                    '//
     +T6,'     THREAT DEFINITION                '//
     +T6,'1    A/A THREAT DENSITY       ',T51,F6.4,' WP/SQ.MI.'/
     +T6,'2    A/A THREAT DIAMETER      ',T51,F6.2,' MI.'//
     +T6,'3    SAM THREAT DENSITY       ',T51,F6.4,' WP/SQ.MI.'/
     +T6,'4    SAM THREAT DIAMETER      ',T51,F6.2,' MI'//
     +T6,'TO CHANGE THEM ENTER ITS NUMBER IN I1 FORMAT.'//
     +T6,' ENTER 0 FOR NO CHANGE REQUIRED')
      READ(5,1211)I1
      IF(I1.EQ.0) GO TO 120
      GO TO (321,322,323,324),I1
1329  WRITE(4,1200)
      GO TO 320
321       CONTINUE
          WRITE(4,1321)
1321      FORMAT('0','     A/A THREAT DENSITY RANGE 0.0 TO .02    '//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
          READ(5,1202)V1
          AAH=V1
          GO TO 32C
```

```
322       CCNTINUE
          WRITE(4,1322)
1322      FCRMAT('C','      A/A THREAT DIAMETER RANGE 0.0 TO 5.  '//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
          READ(5,1202)V1
          AAC=V1
          GC TO 320
323       CCNTINUE
          WRITE(4,1323)
1323      FORMAT('C','      SAM THREAT DENSITY RANGE 0.0 TO .002  '//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
          READ(5,1202)V1
          SAMH=V1
          GO TO 32C
324       CONTINUE
          WRITE(4,1324)
1324      FORMAT('0','      SAM THREAT DIAMETER RANGE 0.0 TO 25.  '//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
          READ(5,1202)V1
          SAMD=V1
          GC TC 320
C*************************************************************************
C     MENU 41  PRCB OF DETECTION
C*************************************************************************
410       CALL FRTCMS('CLRSCRN ')
41        CCNTINUE
      WRITE(4,1410)
1410  FORMAT('1','MENU (41) SELECT A CODE AS FOLLOWS:'//
     +T6,'FOR AN EXPLANATION              ',T51,'HP'/
     +T6,'P(D) VS A/A (RADAR MISSILE)     ',T51,'AR'/
     +T6,'P(C) VS HIGH ALT. SAM           ',T51,'HS'/
     +T6,'TC RETURN TC MENU (4)           ',T51,'RT'/
     +T6,'TC TRANSFER TO OTHER MENUS      ',T51,'TN'/)
      READ(5,20C0) K7Q
      IF(K7Q.EQ.K6(1)) GO TC 411
      IF(K7Q.EQ.K6(2)) GO TC 413
      IF(K7Q.EQ.KK(1)) GO TC 9976
      IF(K7C.EQ.KK(2)) GO TC 998
      IF(K7C.EQ.KK(4)) GC TC 130
      WRITE(4,1200)
      GO TO 41
C*************************************************************************
C     PD A/A RADAR MISSILE
C*************************************************************************
411       CALL FRTCMS('CLRSCRN ')
          CALL SSRPCA(JAM,IRCS,PDAR)
4119  WRITE (4,1411)PDAR
1411  FORMAT('1',T6,'THE COMPUTED PROBABILITY OF DETECTION BY A/A (RADAR
```

```
     +) MISSILE IS ',F6.4//T6,'TO CHANGE THIS VALUE ENTER 1'/
     +T6,' ENTER 0 FOR NO CHANGE REQUIRED')
      READ(5,1211)I1
      IF(I1.EQ.0) GO TO 410
      IF(I1.EQ.1) GO TO 1413
1419  WRITE(4,120C)
      GO TO 411
1413       CONTINUE
           WRITE(4,1417)
1417       FORMAT('C','      PD  RANGE   C.0 TO 1.C    '//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
           READ(5,1202)V1
           PCAR=V1
           GC TO 4119
C*************************************************************************
C     PD VS SAM
C*************************************************************************
413        CONTINUE
      CALL SSRPDS(JAM,IRCS,DSR,PDSM)
           CALL FRTCMS('CLRSCRN ')
1490  WRITE (4,1491)PDSM
1491  FORMAT('1',T6,'THE COMPUTED PRCB OF DETECTION BY THE HIGH ALT SAM
     +IS ',1X,F6.4//T6,'TO CHANGE THIS VALUE ENTER 1'/
     +T6,' ENTER C FCR NC CHANGE REQUIRED')
      READ(5,1211)I1
      IF(I1.EQ.0) GO TO 410
      IF(I1.EQ.1) GO TO 1492
1493  WRITE(4,120C)
      GO TO 1490
1492       CONTINUE
           WRITE(4,1417)
           READ(5,1202)V1
           PCSM=V1
           GC TO 1490
C*************************************************************************
C     MENU 42  PRCB OF HIT
C*************************************************************************
420        CALL FRTCMS('CLRSCRN ')
42         CONTINUE
      WRITE(4,1420)
1420  FORMAT('1','MENU (42) SELECT A CODE AS FOLLOWS:'//
     +T6,'FCR AN EXPLANATION          ',T51,'HP'/
     +T6,'P(H) VS A/A (RADAR MISSILE) ',T51,'AR'/
     +T6,'P(H) VS HIGH ALT. SAM       ',T51,'HS'/
     +T6,'TC RETURN TO MENU (4)       ',T51,'RT'/
     +T6,'TO TRANSFER TO OTHER MENUS  ',T51,'TN'/)
      READ(5,20C0) K8C
      IF(K8C.EQ.K6(1)) GC TC 421
```

```
      IF(K8C.EQ.K6(2)) GC TC 423
      IF(K8Q.EQ.KK(1)) GC TC 9977
      IF(K8C.EQ.KK(2)) GO TO 998
      IF(K8C.EQ.KK(4)) GC TO 130
      WRITE(4,1200)
      GO TO 42
C*****************************************************************
C     PROB OF HIT A/A RADAR MISSILE
C*****************************************************************
421   CONTINUE
      CALL SSRPHR(WS,XMM,XMA,IWARN,ICHAFF,DSR,PHAR)
1421     CALL FRTCMS('CLRSCRN ')
         WRITE (4,14911)PHAR
14911 FORMAT('1',T6,'THE CCMPUTED PROB CF HIT BY A/A MISSILE) IS '
     +,F6.4//T6,'TO CHANGE THIS VALUE ENTER 1'/
     +T6,' ENTER C FCR NO CHANGE REQUIREC')
      READ(5,1211)I1
      IF(I1.EQ.0) GO TO 420
      IF(I1.EQ.1) GO TO 14212
14913 WRITE(4,12CC)
      GO TC 1421
14212    CCNTINUE
         WRITE(4,1497)
1497     FORMAT('0','      FH  RANGE   0.0 TC 1.0    '//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
         READ(5,1202)V1
         PHAR=V1
         GC TO 1421
C*****************************************************************
C     PROB OF HIT HIGH ALT SAM
C*****************************************************************
423   CONTINUE
      CALL SSRPHS(WS,XMM,XMA,IWARN,ICHAFF,DSR,PHSM)
1423     CALL FRTCMS('CLRSCRN ')
         WRITE (4,14923)PHSM
14923 FORMAT('1',T6,'THE CCMPUTED PROB CF HIT BY HIGH ALT SAM IS '
     +,F6.4 //T6,'TO CHANGE THIS VALUE ENTER 1'/
     +T6,' ENTER 0 FOR NO CHANGE REQUIREC')
      READ(5,1211)I1
      IF(I1.EQ.0) GC TO 420
      IF(I1.EQ.1) GO TO 14232
14933 WRITE(4,1200)
      GO TO 1423
14232    CCNTINUE
         WRITE(4,1497)
         READ(5,1202)V1
         PHSM=V1
         GC TO 1423
```

```
C*****************************************************************
C MENU 51  VULN. AREA / P(K/H) VS A/A RACAR MISSILE
C*****************************************************************
510     CONTINUE
          CALL SSRAVA(IFS,IFV,AVAA,PKHAA)
1511      CALL FRTCMS('CLRSCRN ')
          WRITE (4,1512)AVAA,PKHAA
1512    FORMAT('1',T6,' THE COMPUTED VULN AREA VS A/A MISSILE IS '
     +,T51,F6.0,/T6,'THE P(K/H) IS ',T51,F6.4,//
     +T6,'TO CHANGE THESE VALUES ENTER 1'/
     +T6,' ENTER C FOR NC CHANGE REQUIRED')
          READ(5,1211)I1
          IF(I1.EQ.0) GO TO 14C
          IF(I1.EQ.1) GO TO 1513
1514      WRITE(4,120C)
          GO TO 1511
1513        CONTINUE
            WRITE(4,1515)
1515        FORMAT('0','      VULN. AREA   RANGE   00.0 TO 600.0    '//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
            READ(5,1202)V1
            AVAA=V1
            PKHAA = AVAA/600.
            GO TO 1511
C*****************************************************************
C     VULN. AREA / P(K/H) VS HIGH ALT SAM
C*****************************************************************
520         CONTINUE
      CALL SSRAVS(IFS,IFV,JAM,IRCS,VASM,PKHSM)
1521        CALL FRTCMS('CLRSCRN ')
            WRITE (4,1522)VASM,PKHSM
1522    FORMAT('1',T6,' THE COMPUTED VULN AREA VS SAM IS ',T51,F6.0/T6,
     +'THE P(K/H) IS ',T51,F6.4,//T6,'TO CHANGE THESE VALUES ENTER 1'/
     +T6,' ENTER 0 FOR NC CHANGE REQUIRED')
          READ(5,1211)I1
          IF(I1.EQ.0) GO TO 140
          IF(I1.EQ.1) GO TO 1523
1524      WRITE(4,12C0)
          GO TO 1521
1523        CONTINUE
            WRITE(4,1525)
1525        FORMAT('0',      VULN. AREA   RANGE   00.0 TO 600.0    '//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
            READ(5,1202)V1
            VASM=V1
            PKHSM = VASM / 600.
            GO TO 1521
C*****************************************************************
```

```
C MENU 61   P(S) A/A RADAR MISSILE
C*************************************************************************
610       PSAR = 1.- PCAR * PHAR * PKHAA
618       CALL FRTCMS('CLRSCRN ')
       WRITE (4,2220)JAM,IFS,IRCS,IFV,IWARN,ICHAFF
2220   FORMAT('0',' SUSCEPTIBILITY REDUCTION FEATURES ',
      +T40,' * VULNERABILITY  REDUCTION FEATURES  '//
      +,'     JAMMER NUMBER              ',T35,I1,
      +T42,'    FUEL SYSTEM GENERAL      ',T69,I1/
      +,'     RCS REDUCTION LEVEL        ',T35,I1,
      +T42,'    FUEL/VOID INTERFACE      ',T69,I1/
      +,'       RADAR WARNING RECEIVER   ',T35,I1/
      +,'       CHAFF DISPENSER          ',T35,I1/)
          WRITE(4,1610)PSAR,PCAR,PHAR,PKHAA
1610      FORMAT('0',T6,' THE PROB OF SURVIVAL VS AA(RADAR)'//
      +T6,'    PS    =  1   -    PD   *    PH    *    PK/H '/
      +T9,F6.4,7X,F6.4,3X,F6.4,3X,F6.4//
      +T6,'TO CHANGE THIS VALUE ENTER 1 IN I1 FORMAT'/
      +T6,'ENTER 0 FOR NO CHANGE REQUIRED')
          READ(5,1659)I1
          IF(I1.EQ.0) GO TO 150
          GO TO (611,1619),I1
1619      WRITE(4,120C)
          GC TO 618
611       CONTINUE
          WRITE(4,1611)
1611      FORMAT('0',T6,'ENTER P(D),P(H), P(K/H) IN REAL NUMBER FORMAT'/
      +T6,'                    (RANGE 0.0C1 TC 1.00)')
          READ(5,1657)PDAR,PHAR,PKHAA
          PSAR=1. - PCAR * PHAR * PKHAA
          GC TO 618
C*************************************************************************
C      P(S) HIGH ALT SAM
C*************************************************************************
630       PSSM = 1.- POSM * PHSM * PKHSM
638       CALL FRTCMS('CLRSCRN ')
       WRITE (4,2220)JAM,IFS,IRCS,IFV,IWARN,ICHAFF
          WRITE(4,1630)PSSM,PDSM,PHSM,PKHSM
1630      FORMAT('0',T6,' THE PROB OF SURVIVAL VS SAM'//
      +T6,'    PS    =  1   -    PD   *    PH    *    PK/H '/
      +T9,F6.4,7X,F6.4,3X,F6.4,3X,F6.4//
      +T6,'TO CHANGE THIS NUMBER ENTER 1 IN I1 FORMAT.'/
      +T6,'ENTER 0 FOR NO CHANGE REQUIRED')
          READ(5,1659)I1
          IF(I1.EQ.0) GO TO 150
          GO TO (631,1639),I1
1639      WRITE(4,120J)
          GO TO 638
```

```
631         CONTINUE
            WRITE(4,1611)
            READ(5,1657)PDSM,PHSM,PKHSM
            PSSM= 1. - PDSM * PHSM * PKHSM
            GO TO 638
C*****************************************************************
C MENU 62      SORTIE ANALYSIS
C*****************************************************************
640       CONTINUE
649       CALL FRTCMS('CLRSCRN ')
       WRITE (4,164C)ACR,XINPAS,PSAR,PSSM
1640   FORMAT('1',' MENU (62)  SORTIE ANALYSIS'//
      +T6,'1    AIRCRAFT IN SORTIE              ',T46,F6.0/
      +T6,'2    NUMBER OF PASSES PER SORTIE     ',T44,F6.0/
      +T6,'3    P(S) VS A/A RADAR MISSILE       ',T48,F6.4/
      +T6,'4    P(S) VS HIGH ALT SAM            ',T48,F6.4//
      +T6,'TO CHANGE A VALUE ENTER ITS NUMBER IN I1 FORMAT.'/
      +T6,'ENTER 0 FOR NO CHANGE REQUIRED')
       READ(5,1659)I1
       IF(I1.EQ.0) GO TC 689
       GO TO (641,642,618,638),I1
1648   WRITE(4,1200)
            GO TO 64C
641         CONTINUE
            WRITE(4,1651)
            READ(5,1657)V1
            ACR=V1
            GO TO 649
642         CONTINUE
            WRITE(4,1653)
            READ(5,1202)V1
            XINPAS=V1
            GO TO 649
689     CALL   SCRT(
     &XMD,AAH,AAD,PKHAA,PSAR,0.,0.,0.,1.,1.,XMD,SAMH,SAMD,PKHSM,PSSM,
     &ACR,NSRT,XINFAS,NS, ACR2,TOTSR,TOTACK,TOTACL,TOTACR)
       CALL FRTCMS('CLRSCRN ')
       WRITE (4,1689)ACR2,TOTSR,TOTACK,TOTACL,TOTACR
1689   FORMAT('1','      RESULTS FROM SINGLE SCRTIE AGAINST THE THREATS'//
      +T6,'     UNDAMAGED AIRCRAFT          ',T51,F6.2/
      +T6,'     SORTIES FLOWN               ',T51,F6.2/
      +T6,'     TARGETS ATTACKED            ',T51,F6.2/
      +T6,'     AIRCRAFT LOST               ',T51,F6.2/
      +T6,'     AIRCRAFT DAMAGED            ',T51,F6.2//
      +T6,'TC RERUN A SCRTIE ANALYSIS ENTER "1" '/
      +T6,'TC RETURN TO MENU (6) ENTER 0')
       READ(5,1211)I1
        IF(I1.EQ.1) GO TO 64C
```

```
      GO TO 15C
C*****************************************************************************
C MENU 63      CAMPAIGN ANALYSIS
C*****************************************************************************
650       CONTINUE
659        CONTINUE
          CALL FRTCMS('CLRSCRN ')
       WRITE (4,1650)ACR1,NSRT,XNPASS,NS,PSAR,PSSM
1650   FORMAT('1',' MENU (63)  CAMPAIGN ANALYSIS '//
     +T6,'1    AIRCRAFT IN CAMPAIGN                ',T46,F6.0/
     +T6,'2    NUMBER OF RAIDS IN CAMPAIGN',T43,I6/
     +T6,'3    NUMBER OF PASSES PER SORTIE  ',T44,F6.0/
     +T6,'4    NUMBER OF SORTIES FOR REPAIR ',T43,I6//
     +T6,'5    P(S) VS A/A MISSILE          ',T48,F6.4//
     +T6,'6    P(S) VS HIGH ALT SAM         ',T48,F6.4//
     +T6,'TO CHANGE A VALUE ENTER ITS NUMBER IN I1 FORMAT.'/
     +T6,'ENTER 0 FOR NO CHANGE REQUIRED')
      READ(5,1659)I1
1659  FORMAT(I1)
      IF(I1.EQ.0) GO TO 699
      GO TO (651,652,653,656,618,638),I1
1658  WRITE(4,120C)
         GO TO 65C
651      CONTINUE
         WRITE(4,1651)
1651     FORMAT('0',T6,'ENTER NUMBER OF A/C IN REAL NUMBER FORMAT.')
         READ(5,1657)V1
1657     FORMAT(F8.4)
         ACR1=V1
         GO TO 659
652      CONTINUE
         WRITE(4,1652)
1652     FORMAT('0',T6,'ENTER NUMBER OF RAIDS IN I2 FORMAT.')
         READ(5,1697)I2
1697     FORMAT(I2)
         NSRT=I2
         GO TO 659
653      CONTINUE
         WRITE(4,1653)
1653    FORMAT('0',T6,'ENTER PASSES PER SORTIE IN REAL NUMBER FORMAT.')
         READ(5,1202)V1
         XNPASS=V1
         GO TO 659
656      CONTINUE
         WRITE(4,1656)
1656     FORMAT('0',T6,'ENTER MAX NUMBER OF SORTIES FOR REPAIR IN I2 FO
     +RMAT.')
         READ(5,1697)I2
```

```
          NS=12
          GO TO 659
699       CALL FRTCMS('CLRSCRN ')
        CALL  CAMP(
     &XMD,AAH,AAD,PKHAA,PSAR,0.,0.,0.,1.,1.,XMD,SAMH,SAMD,PKHSM,PSSM,
     &ACR1,NSRT,XNPASS,NS, ACR2,TOTSR,TOTACK,TOTACL,TOTACR)
        WRITE (4,1699)ACR2,TOTSR,TOTACK,TOTACL,TOTACR
1699    FORMAT('1',' RESULTS FROM SINGLE SORTIE AGAINST THE THREATS'//
     +T6,'  A/C READY FOR NEXT LAUNCH',T51,F6.0/
     +T6,'  SORTIES FLOWN           ',T51,F8.0/
     +T6,'  TARGETS ATTACKED        ',T51,F8.0/
     +T6,'  AIRCRAFT LOST           ',T51,F6.0/
     +T6,'  AIRCRAFT IN REPAIR      ',T51,F6.0//
     +T6,'TO RERUN A CAMPAIGN ENTER 1 '/
     +T6,'TO RETURN TO MENU (6) ENTER 0')
        READ(5,1211)I1
         IF(I1.EQ.1) GO TO 650
         GO TO 150
C*****************************************************************
C     HELP
C*****************************************************************
9971      CALL FRTCMS('CLRSCRN ')
        WRITE(4,7971)
7971    FORMAT(' ','                          HELP FOR MENU 1                 '/
     +T6,' THE VISAP DESIGN EVALUATOR IS DIVIDED INTO FIVE SECTIONS. '/
     +T6,'     THE AIRCRAFT DESIGN SECTION IS WHERE A DESCRIPTION OF'/
     +T6,' THE AIRCRAFT IS ENTERED. THIS INCLUDES GENERAL PARAMETRIC'/
     +T6,' SIZING VALUES AS WELL AS DESCRIPTIONS OF THE S/V FEATURES'/
     +T6,' CONTAINED IN THE DESIGN. VALUES SHOWN INITIALLY ARE DEFAULT'/
     +T6,' VALUES WHICH MAY BE CHANGED.'/
     +T6,'     THE MISSION SECTION IS WHERE THE MISSION PARAMETERS AND'/
     +T6,' THREAT INTENSITY VALUES ARE ENTERED. NOTE THAT THE TYPE'/
     +T6,' OF THREATS CANNOT BE CHANGED BECAUSE THE SELECTION OF THE'/
     +T6,' AIRCRAFT DETERMINES THE THREATS.                 '/
     +T6,'     THE LAST THREE SECTIONS ARE FOR EVALUATION OF THE'/
     +T6,' DESIGN. IF THE DESIGN AND THREAT SECTIONS ARE NOT ENTERED'/
     +T6,' DEFAULT VALUES (BASELINE) WILL BE USED FOR ALL CALCULATIONS.'
     +,//T6,'          ENTER ANY INTEGER TO RETURN TO MENU 1      ')
        READ(5,*)IJK
        GO TO 100
9972      CALL FRTCMS('CLRSCRN ')
        WRITE(4,7972)
7972    FORMAT(' ',' '                          HELP FOR MENU 2                 '/
     +T6,' THE DESIGN SECTION IS DIVIDED INTO THREE SUBSECTIONS.'/
     +T6,'     THE AIRCRAFT PERFORMANCE INDICATORS AFFECT THE '/
     +T6,' ABILITY OF THE AIRCRAFT TO MANEUVER AND AVOID THE THEAT.'/
     +T6,' SOME OF THE VALUES MAY REMOVE THE AIRCRAFT FROM THE'/
     +T6,' THREAT ENVELOPE COMPLETELY. A FURTHER DISCUSSION OF THE '/
```

```
     +T6,' IMPACT OF THESE VALUES MAY BE FOUND IN THE P(H) SECTION'/
     +T6,' OF SUSCEPTIBILITY EVALUATION.                          '/
     +T6,'     SUSCEPTIBILITY REDUCTION FEATURES OF THE DESIGN ARE'/
     +T6,' ENTERED IN THIS SECTION. THESE INCLUDE JAMMER SIZE, RCS '/
     +T6,' REDUCTION LEVELS, CHAFF DISPENSER AND RADAR WARNING RE- '/
     +T6,' CEIVER. THE DEFAULT VALUES (BASELINE) ARE ZERO, INDICATING'/
     +T6,' NONE OF THESE FEATURES ARE INCLUDED.                    '/
     +T6,'     VULNERABILITY REDUCTION FEATURES VARY WITH THE THREE'/
     +T6,' TYPES OF AIRCRAFT. SELECT THOSE FEATURES THAT BEST'/
     +T6,' DESCRIBE YOUR DESIGN. MINIMUM VALUES OF 1 (BASELINE)'///
     +T6,' INDICATE NO IMPROVEMENTS.                              '/
     +T6,'            ENTER ANY INTEGER TO RETURN TO MENU 2       ')
      READ(5,*)IJK
      GO TO 110
9973    CALL FRTCMS('CLRSCRN ')
      WRITE(4,7973)
7973  FORMAT(' ','                          HELP FOR MENU 3       '/
     +T6,' THE COMBAT SCENERIO SECTION IS DIVIDED INTO TWO SUBSECTIONS.
     +'/,T6,'     IN MISSION PROFILE, VALUES ARE ENTERED TO SPECIFICALLY
     +'/,T6,' DEFINE THE DESIRED MISSION.THE MISSION PARAMETERS ARE DEFI
     +NED'/,T6,' BY THE SELECTION OF AIRCRAFT TYPE. THESE INCLUDE ITEMS'
     +/,T6,' THAT MIGHT BE CONSIDED AS TACTICS.                   '/
     +T6,'     IN THREAT SELECTION, THREAT DENSITIES AND THREAT'/
     +T6,' DIAMETERS ARE ENTERED.  THE THREATS FOR THE LONG RANGE STRIKE
C- #2 ------------------------------------------------------------------
     +'/,T6,' MISSION ARE; AIR-TO-AIR IR MISSILES AND HIGH ALTITUDE SAM'
     +'S'/,T6,'           ENTER ANY INTEGER TO RETURN TO MENU 3     ')
      READ(5,*)IJK
      GO TO 120
9974    CALL FRTCMS('CLRSCRN ')
      WRITE(4,7974)
7974  FORMAT(' ','                          HELP FOR MENU 4       '/
     +T6,' THE SUSCEPTIBILITY ASSESSMENT SECTION HAS TWO SUBSECTIONS.'/
     +T6,'     THE PROBABILITY OF DETECTION IS AFFECTED BY THE'/
     +T6,' RCS OF THE AIRCRAFT, THE POWER OF THE NOISE JAMMER, '/
     +T6,' AND THE SLANT RANGE FROM THE THREAT TO THE A/C AT CPA.'/
     +T6,' NOTE THAT ALL AIRCRAFT ARE CONSIDERED TO PASS OVER A POINT'/
     +T6,' THAT IS THE SAME HORIZONTAL DISTANCE FROM THE THREAT '/
     +T6,' AS THE ALTITUDE OF THE AIRCRAFT. THIS MEANS THAT THE'/
     +T6,' CPA SLANT RANGE IS 1.414 TIMES THE ALTITUDE.'/
     +T6,'     THE PROBABILITY OF HIT IS DEFINED SEPARATELY FOR EACH'/
     +T6,' AIRCRAFT AND THREAT. HOWEVER, THE FORM IS CONSISTENT, WHERE'/
     +T6,' P(H) REFERS TO THE PROBABILITY THAT A NON-MANEUVERING A/C'/
     +T6,' WOULD BE HIT BY THE THREAT, F(M) IS THE MANEUVER FACTOR.'/
     +T6,' AND F(C) IS THE COUNTERMEASURE (CHAFF OR FLARE) FACTOR.'///
     +T6,'                P(H)'' = P(H) * F(M) * F(C)             '///
     +T6,'          ENTER ANY INTEGER TO RETURN TO MENU 4         ')
      READ(5,*)IJK
```

```
      GO TO 130
 9975    CALL FRTCMS('CLRSCRN ')
      WRITE(4,7975)
 7975 FORMAT(' ',/                                  HELP FOR MENU 5          '/
     +T6,'       THE VULNERABILITY ASSESSMENT SECTION CALCULATES  '/
     +T6,' EITHER THE P(K/H) OR THE AVERAGE VULNERABLE AREA FOR THE '/
     +T6,' AIRCRAFT VERSUS A THREAT. FOR THE STRIKE AIRCRAFT;   '//
     +T6,'    VS AAA                                                 '/
     +T6,'       P(K/H) = FROM TABLE BASED UPON VULN. FEATURES   '/
     +T6,'       AP = 600.                                          '/
     +T6,'       AV = AP * P(K/H)                                   '/
     +T6,'    VS SAM                                                '/
     +T6,'       P(K/H) = FROM TABLE BASED UPON CEP                 '/
     +T6,'          ** NOTE ** CEP FUNCTION OF RCS & JAMMER         '/
     +T6,'       AP = ASSUMED 600.                                  '/
     +T6,'       AV  = AP * P(K/H)                                 '//
     +T6,'          ENTER ANY INTEGER TO RETURN TO MENU 5          ')
      READ(5,*)IJK
      GO TO 140
 9976    CALL FRTCMS('CLRSCRN ')
      WRITE(4,7976)
 7976 FORMAT(' ',/                                  HELP FOR MENU 41         '/
     +T6,'       THE FOLLOWING METHODS ARE USED FOR THE STRIKE P(D)'//
     +T6,'    VS AAA                                                 '/
     +T6,'       P(D) = FUNCTION OF SLANT RANGE AT CPA           '/
     +T6,'    VS SAM                                                '/
     +T6,'       P(D) = TWO TIMES THE INTEGRAL OF THE GAUSSIAN      '/
     +T6,'            PROBABILITY FUNCTION FROM INFINITY TO CPA'//
     +T6,'         ENTER ANY INTEGER TO RETURN TO MENU 41           ')
      READ(5,*)IJK
      GO TO 410
 9977    CALL FRTCMS('CLRSCRN ')
      WRITE(4,7977)
 7977 FORMAT(' ',/                                  HELP FOR MENU 42         '/
     +T6,'       THE FOLLOWING METHODS ARE USED FOR THE STRIKE P(H)'/
     +T6,'PH = PROBABILITY THAT A NON-MANEUVERING A/C IS HIT        '/
     +T6,'PA = PROBABILITY THAT THE CREW IS ALLERTED AND TAKE EVASIVE AC
     +TION.'/
     +T6,'FM = MANEUVER FACTOR          FC = CHAFF FACTOR'/
     +T6,'WS = WING LOADING/100.        TW = THRUST TO WEIGH'/
     +T6,'ALT = PENETRATION ALT / 10,000                    H'//
     +T6,'    VS AAA GUNS                                           '/
     +T6,'       PH= 1.0                          PA= 1.'/
     +T6,'       FM= 1+ .961 * WS**2 - .08246 * MACH * ALT'/
     +T6,'       PH'' = PH * FC * (1. -(1.-FM)*PA)                  '/
     +T6,'    VS SAM                                                '/
     +T6,'       PH = .95595        FC = .6                         '/
     +T6,'       FM = 1.-.35393 * MACH**2 + .169654 * WS * ALT      '/
```

```
     +T6,'       PH'' = PH * FC * ( 1. - (1.- FM) * FA)                '//
     +T6,'         ENTER ANY INTEGER TO RETURN TO MENU 42               ')
      READ(5,*)IJK
      GO TO 420
9978    CALL FRTCMS('CLRSCRN ')
      WRITE(4,7978)
7978  FORMAT(' ',' '                          HELP FOR MENU 6          '//
     +T6,'THE P(S) VS INDIVIDUAL WEAPONS                                '/
     +T6,'     P(S) = 1 -  P(D) * P(H) * P(K/H)                        '//
     +T6,'THE P(S) FOR SINGLE SORTIE                                    '/
     +T6,'     W = WEIGHTING FACTOR              XL = PENETRATION DISTANCE'/
     +T6,'     XH = THREAT DENSITY                DL = THREAT DIAMETER    '/
     +T6,'     H = A/C HIT     XK = A/C KILLED     A = A/C DAMAGED        '/
     +T6,'     ACOVER = A/C OVER TARGET          ATAC = TARGETS ATTACKED  '/
     +T6,'     PSM = PROB. OF MISS. SURVIVAL     ACR1 = A/C IN FORMATION'//
     +T6,'     W = XL * XH * D / 100.          PSM = PS ** W              '/
     +T6,'     PH = (1. - PSM)/PKH             H1 = ACR1 * PH             '/
     +T6,'     XK1 = H * PKH                   A1 = H1 - XK1              '/
     +T6,'     ACOVER = ACR1-H1-H2-H3          ATAC = ACOVER * XNPAS      '/
     +T6,'     H4 = ACOVER * PH                XK4 = H4 * PKH             '/
     +T6,'     A3 = H4 - XK4                   ACNHT = ACR1-H1-H4         '/
     +T6,'     ACDAM = A1 + A4                 ACKIL = XK1 + XK4          '//
     +T6,'         ENTER ANY INTEGER TO RETURN TO MENU 6                  ')
      READ(5,*)IJK
C-  #3 ------------------------------------------------------------------
      GO TO 150
C-  #5 ------------------------------------------------------------------
C  ******************** PLOTTING INFORMATION ****************************
 8888 CALL FRTCMS('CLRSCRN ')
      WRITE(4,8889)
 8889 FORMAT(' ',' '          HELP FOR MENU (8)          '//
     *T6,'MENU (8) INCORPORATES A DATA GENERATING ROUTINE TO SAVE'/
     *T6,'THE PROBABILITIES OF A KILL ( P(K) = 1 - P(S) ) FOR'/
     *T6,'LATER PLOTTING.  THIS PLOT MAY BE OBTAINED FROM A'/
     *T6,'TEKTRONIX DUAL SCREEN (TEK618) SYSTEM.  THE P(K)'/
     *T6,'AGAINST THE APPROPRIATE THREAT TYPES ARE PRESENTED.'//
     *T6,'    THREE DESIGNS CAN BE PLOTTED AT A TIME, FOR EXAMPLE'/
     *T6,'YOUR BASELINE DESIGN, YOUR FIRST DESIGN, AND ONE OTHER'/
     *T6,'MODIFICATION.  YOU MUST HAVE DONE AND CHOSEN TO SAVE'/
     *T6,'PLOTTING DATA FROM THREE RUNS.'//
     *T6,'    TO OBTAIN THE PLOT, FOLLOW THE SAME LOGON AND LINK'/
     *T6,'PROCEDURES YOU UTILIZED TO ACCESS VISAP, HOWEVER, ENTER'/
     *T6,'DISVIS INSTEAD OF VISAP. THEN ENTER STRPLT.'//
     *T6,'         ENTER ANY INTEGER TO RETURN TO MENU (8)')
      READ (5,*)IJK
      GO TO 8
C*************************************************************************
C          TRANSFER
```

```
C*************************************************************************
998      CALL FRTCMS('CLRSCRN ')
      WRITE(4,1998)
1998  FORMAT(' ','TRANSFER MENU, SELECT A CODE AS FOLLOWS:'/
     +T6,'MAIN MENU                    ',T51,'MM'/
     +T6,'  AIRCRAFT DESIGN SELECTION  ',T51,'DE'/
     +T6,'    A/C PERFORMANCE INDICATORS ',T51,'AP'/
     +T6,'    SUSCEPTIBIL  Y FEATURES    ',T51,'SF'/
     +T6,'    VULNERABILI   FEATURES     ',T51,'VF'/
     +T6,'  COMBAT SCENARIO SELECTION  ',T51,'MS'/
     +T6,'    MISSION PROFILE           ',T51,'MP'/
     +T6,'    THREAT SELECTION          ',T51,'TH'/
     +T6,'  SUSCEPTIBILITY ASSESSMENT  ',T51,'SA'/
     +T6,'    PROBABILITY OF DETECTION  ',T51,'PD'/
     +T6,'    PROBABILITY OF HIT        ',T51,'PH'/
     +T6,'  VULNERABILITY ASSESSMENT    ',T51,'VA')
      WRITE(4,19981)
19981 FORMAT(' ',T6,'    P(K/H)                          ',T51,'KH'/
     +T6,'    P(K/D)                    ',T51,'KD'/
     +T6,'  SURVIVABILITY ASSESSMENT    ',T51,'SV'/
     +T6,'    P(S) 1:1 AAA (RADAR)      ',T51,'AR'/
     +T6,'    P(S) 1:1 AAA (OPTICAL)    ',T51,'AC'/
     +T6,'    P(S) 1:1 LOW ALT SAM      ',T51,'LS'/
     +T6,'    SINGLE SORTIE             ',T51,'SS'/
     +T6,'    CAMPAIGN EVALUATION       ',T51,'CE'/
     +T6,'TO EXIT OR PRINT RESULTS    ',T51,'EX'/)
      READ(5,2000) K9Q
      IF(K9Q.EQ.K1(1)) GO TO 110
      IF(K9Q.EQ.K1(2)) GO TO 120
      IF(K9Q.EQ.K1(3)) GO TO 130
      IF(K9Q.EQ.K1(4)) GO TO 140
      IF(K9Q.EQ.K1(5)) GO TO 150
      IF(K9Q.EQ.K2(1)) GO TO 210
      IF(K9Q.EQ.K2(2)) GO TO 220
      IF(K9Q.EQ.K2(3)) GO TO 230
      IF(K9Q.EQ.K3(1)) GO TO 310
      IF(K9Q.EQ.K3(2)) GO TO 320
      IF(K9Q.EQ.K4(1)) GO TO 410
      IF(K9Q.EQ.K4(2)) GO TO 420
      IF(K9Q.EQ.K5(1)) GO TO 510
      IF(K9Q.EQ.K5(2)) GO TO 520
      IF(K9Q.EQ.K6(1)) GO TO 610
      IF(K9Q.EQ.K6(2)) GO TO 630
      IF(K9Q.EQ.K6(3)) GO TO 640
      IF(K9Q.EQ.K6(4)) GO TO 650
      IF(K9Q.EQ.KK(3)) GO TO 999
      IF(K9Q.EQ.K1(6)) GO TO 100
      WRITE(4,1200)
```

```
      GO TO 598
C*****************************************************************
C           EXIT
C*****************************************************************
C- #3 ---------------------------------------------------------------
1061       CONTINUE
C***************DETERMINE TCGW ***********************************
           CALL ESRWT(ES,EC,EL,TW,WS,WT,
     @     IFS,IFV,JAM,IRCS,XMA,XMD,XMM,IWARN,ICHAFF,
     @     BLTOGW,TOGW)
C- #3 ---------------------------------------------------------------
C********* TC SAVE DATA ******************************
      REWIND 2
      WRITE(2,1012)TW,WS,WT,EC,EL,ES,JAM,IRCS,IWARN,ICHAFF,IFS,
     *      IFV,XMC,XMA,XMM,DSR,SAMH,SAMD,AAH,AAD,
     *      PCAR,PCSM,PHAR,PHSM,AVAA,PKHAA,VASM,PKHSM,PSAR,
     *      PSSM,ACR,XINPAS,ACR1,NSRT,XNPASS,NS,
     *      ACR2,TCTSR,TCTACK,TOTACL,TOTACR,BLTOGW,TOGW
C*****************************************************************
C- #3 ---------------------------------------------------------------
      CALL FRTCMS('CLRSCRN ')
      WRITE (4,920C)TW,WS,WT,XMD,AAH,XMA,AAD,XMM,SAMH,SAMD
      WRITE (4,222C)JAM,IFS,IRCS,IFV,IWARN,ICHAFF
      WRITE (4,92C1)
      WRITE (4,92C2)PSAR,PCAR,PHAR,PKHAA
      WRITE (4,92C4)PSSM,PCSM,PHSM,PKHSM
      WRITE (4,9220)
      WRITE (4,9220)
      WRITE (4,9205)
      WRITE (4,9206)ACR1,NSRT,XNPASS,NS,ACR2,TOTSR,TOTACK,TOTACL,TOTACR
      WRITE (4,9220)
      WRITE (4,9207)BLTOGW,TOGW
      WRITE (4,8282)
      WRITE (4,8282)
      GO TO 8
C*****************************************************************
999        CONTINUE
        CALL FRTCMS('CLRSCRN ')
      WRITE(4,9999)
9999  FORMAT('0',' TO PRINT YOUR RESULTS AND EXIT ENTER  "0"'/
     +,' TO PRINT YOUR RESULTS AND REENTER PROGRAM ENTER "1"'/
     +,' TO EXIT WITHOUT A PRINT ENTER "2"')
      READ(5,*)IJK
      IF(IJK.EQ.2) GO TO 99999
C- #4 ---------------------------------------------------------------
      WRITE (6,920C)TW,WS,WT,XMD,AAH,XMA,AAD,XMM,SAMH,SAMD
      WRITE (6,222C)JAM,IFS,IRCS,IFV,IWARN,ICHAFF
      WRITE (6,9220)
```

```
      WRITE (6,9201)
      WRITE (6,9202)PSAR,PCAR,PHAR,PKHAA
      WRITE (6,9204)PSSM,PDSM,PHSM,PKHSM
      WRITE (6,9220)
      WRITE (6,9205)
      WRITE (6,9206)ACR1,NSRT,XNPASS,NS,ACR2,TOTSR,TOTACK,TOTACL,TOTACR
      WRITE (6,9220)
      WRITE (6,9207)BLTOGW,TOGW
      IF(IJK.EQ.1) GO TO 1022
C- #3,#4 ------------------------------------------------------------------
9200  FORMAT('1',T25,'** LONG RANGE STRIKE AIRCRAFT **'///
     *       T30,'* PERFORMANCE FEATURES'//
     *      ,'   THRUST TO WEIGHT',T31,F8.2,
     *      T42,'   WING LOADING',T65,F8.2/
     *      ,'   ORDNANCE WEIGHT',T31,F8.2///
     *      ,' * MISSION PARAMETERS',T40,' * THREAT PARAMETERS'//
     *      ,'   PENETRATION DISTANCE',T31,F8.2,
     *      T42,'   A/A DENSITY',T65,F8.2/
     *      ,'   PENETRATION ALTITUDE',T31,F8.2,
     *      T42,'   A/A DIAMETER',T65,F8.2/
     *      ,'   PENETRATION MACH NBR.',T31,F8.2,
     *      T42,'   SAM DENSITY',T65,F8.2/
     *      T42,'   SAM DIAMETER',T65,F8.2///)
C- #3,#4 ------------------------------------------------------------------
9201  FORMAT ('0',' * SURVIVABILITY ASSESSESSMENT:'//
     *       T18,' P(S)     P(O)     P(H)     P(K/H)')
9202  FORMAT (' ',' VS A/A MISSILE  ',4(F4.2,5X))
9204  FORMAT (' ',' VS HIGH ALT SAM ',4(F4.2,5X))
9205  FORMAT ('0',' * CAMPAIGN ANALYSIS:')
9206  FORMAT ('0',' INITIAL A/C    ',F8.0,'     NUMBER OF RAIDS     ',I7,/
     +       ,'  PASSES/SORTIE ',F8.0,'     SORTIES FOR REPAIR ',I5,/
     +       ,'  A/C READY     ',F8.0,'     TOTAL SORTIES      ',F8.0,/
     +       ,'  TOTAL TARGETS ',F8.0,'     TOTAL A/C LOST     ',F8.0,/
     +       ,'  IN REPAIR     ',F8.0,/)
9220  FORMAT (' ')
8282  FORMAT (8(' '))/)
9207  FORMAT ('0',' BASELINE TOGW ',F10.2,T36,'ENHANCED TOGW',F10.2)
99999      STOP
           END
      SUBROUTINE SSRPCA(JAMS,IRCSS,PDCS)
      REAL PDCM(10)
      DATA PDCM/.99,.986,.985,.98,.96,.93,.91,.87,.805,.76/
      PDCS=PDCM(IRCSS+1)
       IF(JAMS.NE.0) PDCS=PDCM(10)
      RETURN
     END
     SUBROUTINE SSRPDS(JAMMER,RCS,DSR,PDF)
     INTEGER A,B,RCS,JAMMER,Q
```

```
      DIMENSION H(2,9,6),F(101),PDT(101),XX(101)
      DATA H/37.,10.,36.,10.,31.,9.,29.,8.,26.,8.,22.5,6.,21.,6.,17.5,5.
     A,13.,4.,
     B23.5,7.,21.5,5.5,17.,5.,15.2,4.2,11.,3.,8.8,2.,7.5,1.9,5.5,1.8,0.,
     C1.,
     D16.8,5.,15.5,4.8,12.,3.7,10.5,3.2,7.9,2.5,6.,1.9,4.8,1.1,3.5,
     C.85,0.,1.,
     D10.8,3.1,8.3,2.4,7.5,2.2,5.6,1.7,4.2,1.3,3.5,1.,0.,1.,0.,1.,0.,1.
     E,6.3,1.4,5.2,1.4,4.7,1.4,0.,1.,0.,1.,0.,1.,0.,1.,0.,1.,0.,1./
     F,4.3,1.3,3.4,1.1,0.,1.,0.,1.,0.,1.,0.,1.,0.,1.,0.,1.,0.,1./
C****************** CANT USE ZERO AS A INCICIES**********************
      I=RCS+1
      J=JAMMER+1
C****************** SELECTS PROPER MEAN AND DEVIATIONS*****************
      X=H(1,I,J)
      S=H(2,I,J)
C********************* CONSTANTS FOR EASE OF WRITING*******************
C- #1 ---------------------------------------------------------------
      CON1=1./(S*SQRT(2.*3.14159))
      CON2=-.5/S**2
C*******************INTEGRATION START AT MEANS + 4 DEVIATIONS********
      XI=X+4*S
C*********************100 STEPS IN ITEGRATION************************
      STEP=-S/12.5
C***************** INITIAL VALUES TO START INTEGRATION****************
      F(1)=0.0
      XX(1)=XI
      PDF=0.
      PD=0.
C*********************INTEGRATION LOOP*************************************
      DO 10 JJ=1,100
            F(JJ+1)= CON1*EXP(CON2*(XI-X)**2)
            XI=XI+STEP
            AREA=-.5*STEP*(F(JJ+1)+F(JJ))
            PDT(JJ+1)=PD
               IF(XI.LT.DSR)GO TO 5
                  PDF=PD
5              CONTINUE
            XX(JJ+1)=XI
            PD=PD+AREA
10    CONTINUE
C#####################SETS UP A MINIMUM PD OF .1
      IF(PDF.GT.0.01) GO TO 20
      PDF=.100
20      CONTINUE
      RETURN
      END
      SUBROUTINE SSRPHR(WS,XMM,XMA,IWARN,ICHAFF,DSR,PDAM)
```

```
C*****************************************************************
C************** A/A RADAR MISSILE P(H) ***************************
C*****************************************************************
                WSS = WS/100.
                XMS = XMA/10000.
               XXMR = DSR
C**************  SAM PH ********************************************
                PH = 1.0
             CALL SRFC (ICHAFF,FC)
C**************  MODIFIED FOR CHAFF ********************************
                PH1 = PH * FC
             CALL SRFA (XXMR,IWARN,FA)
C**************  MODIFIED FOR MANUVERING ***************************
          FM = 1.+.961 * WSS**2 - .08246 * XMS * XMM
          IF(FM.LT.0.01) FM = 0.01
          IF(FM.GT.1.0)  FM = .99
                XMF = 1. - (1.- FM) * FA
            PDAM = PH1 * XMF
            RETURN
        END
        SUBROUTINE SSRPHS(WS,XMM,XMA,IWARN,ICHAFF,DSR,PDAM)
           WSS=WS/100.
           XMS=XMA/10000.
           XXMR = DSR
C**************  SAM PH ********************************************
                PH = .95595
             CALL SRFC (ICHAFF,FC)
C**************  MODIFIED FOR CHAFF ********************************
                PH1 = PH * FC
             CALL SRFA (XXMR,IWARN,FA)
C**************  MODIFIED FOR MANUVERING ***************************
          FM = 1.-.25393 * XMM**2+ .169674 * WSS * XMS
          IF(FM.LT.0.01)FM = 0.01
          IF(FM.GT.1.00)FM = 0.99
                XMF = 1. - (1.- FM) * FA
            PDAM = PH1 * XMF
            RETURN
            END
        SUBROUTINE SRFA(XXMRS,IWARN,FAS)
C*****************************************************************
C******* ALERTION FACTOR *****************************************
        REAL MRM(28),FVM(28),FESM(12),MRSM(12)
           DATA FESM/1.,.99999,.97,.91,.82,.69,.53,.35,.22,.137,.065,0./
           DATA MRSM/0.,36.,40.,50.,60.,70.,80.,90.,100.,110.,120.,140./
        DATA MRM/0.,1.,1.94,2.,2.54,3.,3.08,3.48,3.78,4.,4.05,4.23
       A,4.35,4.45,4.55,4.68,4.8,4.9,5.05,5.35,5.8,6.,6.39,7.,7.36
       B,8.,9.,10./
        DATA FVM/1.,.995,.95,.943,.9,.868,.85,.8,.75,.712,.7,.65,.6
```

```
     A,.55,.5,.45,.4,.357,.35,.3,.25,.216,.2,.165,.15,.13,.114,.101/
      IF(IWARN.EQ.1)GO TO 15
      KEY=1
5     CONTINUE
         KEY=KEY+1
      IF(MRM(KEY).LT.XXMRS) GO TO 5
      DELTAX=MRM(KEY)-MRM(KEY-1)
      DELTAY=FVM(KEY)-FVM(KEY-1)
      FVS=((XXMRS-MRM(KEY-1))/DELTAX)*DELTAY+FVM(KEY-1)
      FAS = FVS
      GO TO 20
15    CONTINUE
         J=1
10       CONTINUE
         J=J+1
         IF(XXMRS.GE.MRSM(J)) GO TO 10
         DX= MRSM(J-1)-MRSM(J)
         DY= FESM(J-1)-FESM(J)
         FES=((XXMRS-MRSM(J-1))/DX)*DY+FESM(J-1)
         FAS = FES
20     CONTINUE
         RETURN
         END
C*************************************************************************
C********* CHAFF FACTOR ***************************************************
C*************************************************************************
         SUBROUTINE SRFC(ICHAFF,FC)
         REAL PBTSM(17)
         DATA PBTSM/.00,.19,.35,.49,.6,.68,.74,.8,.83,.86,.9,.92,.935,
     A                .95,.96,.97,.98/
         PBTS=0.
         IF(ICHAFF.EQ.0) GO TO 10
C**********NUMBER OF BUNDLES DEFAULTED TO FOUR ************************
         NBUNDS = 4
         PBTS=PBTSM(NBUNDS+1)
10       FC = 1. - PBTS
         RETURN
         END
C*************************************************************************
C********* VULNERABLE AREA AND P(K/H) VS A/A RADAR MISSILE ****************
C*************************************************************************
         SUBROUTINE SSRAVA(IFS,IFV,AV,UPKHS)
         F1=0.
         F2=0.
         F3=0.
         F4=0.
         IF (IFS.EQ.2) F1 = 1.
         IF (IFS.EQ.3) F2 = 1.
```

```
      IF (IFS.NE.4) GO TO 5
         F1 = 1.
         F2 = 1.
5     CONTINUE
      IF ((IFV.EQ.2).OR.(IFV.EQ.3)) F3 = 1.
      IF ((IFV.EQ.4).OR.(IFV.EQ.5)) F4 = 1.
      IF (IFV.NE.6) GO TO 10
         F3 = 1.
         F4 = 1.
10    CONTINUE
      TOT = F1+F2+F3+F4
      IF(TOT.GT.3.5) GO TO 4
      IF(TOT.GT.2.5) GO TO 3
      IF(TOT.GT.1.5) GO TO 2
      IF(TOT.GT.0.5) GO TO 1
      UPKHS=1.
      GO TO 20
1     UPKHS=.983*F1+.998*F2+.991*F3+.975*F4
      GO TO 20
2     UPKHS=.983*F1*F2+.973*F1*F3+.911*F1*F4+.989*F2*F3+.971*F2*F4+.963*
     @  F3*F4
      GO TO 20
3     UPKHS=.973*F1*F2*F3+.911*F1*F2*F4+.878*F1*F3*F4+.959*F2*F3*F4
      GO TO 20
4     UPKHS=.877
20    AV = UPKHS * 600.
      RETURN
      END
C*************************************************************************
C********* VULNERABLE AREA AND P(K/H) VS HIGH ALTITUDE SAM ***************
C*************************************************************************
      SUBROUTINE SSRAVS(IFS,IFV,JAM,IRCS,AVS,PKHS)
        REAL CEP(9,6),CEPSM(14),FCEPSM(14)
        DATA CEP/50. ,50. ,50. ,50. ,50. ,50.  ,63.  ,110. ,300.,
     A           50. ,50. ,50. ,50. ,5C. ,63.  ,82.  ,140. ,410.,
     B           50. ,50. ,50. ,50. ,62. ,105. ,140. ,260. ,79C.,
     C           50. ,50. ,59. ,75. ,110.,182. ,265. ,490. ,1000.,
     D           63. ,73. ,105.,135.,2C0.,370. ,540. ,1000.,1000.,
     E           125.,155.,270.,350.,5C0.,1000.,1000.,1000.,1000./
        DATA CEPSM/0.,50.,90.,165.,200.,250.,320.,400.,520.,600.,700.,
     A           800.,1000.,1500./
        DATA FCEPSM/1.,1.,.9,.7,.6,.5,.4,.3,.2,.14,.1,.06,.02,.0/
C********* INITIALLIZING STATMENTS ***************************************
        FCEPS=0.
        CEPS=0.
        F1 = 0.
        F2 = 0.
        F3 = 0.
```

```
            F4 = 0.
C********* ZERO CANNOT BE AN INDEX ************************************
            IY=JAM+1
            IX=IRCS+1
            J=0
15          CONTINUE
            J=J+1
            IF(CEPS.GE.CEPSM(J)) GO TO 15
C********* GRAPH POINT EXTRACTION ************************************
            DX= CEPSM(J-1)-CEPSM(J)
            DY= FCEPSM(J-1)-FCEPSM(J)
            FCEPS=((CEPS-CEPSM(J-1))/DX)*DY+FCEPSM(J-1)
            CEPS = CEP(IX,IY)/FCEPS
C********* MAX VALUE OF CEP IS 1000 FT*******************************
            IF(CEPS.GT.1000.) CEPS=1000.
            IF (IFS.EQ.2) F1 = 1.
            IF (IFS.EQ.3) F2 = 1.
            IF (IFS.NE.4) GO TO 5
                F1 = 1.
                F2 = 1.
5           CONTINUE
            IF ((IFV.EQ.2).OR.(IFV.EQ.3)) F3 = 1.
            IF ((IFV.EQ.4).OR.(IFV.EQ.5)) F4 = 1.
            IF (IFV.NE.6) GO TO 10
                F3 = 1.
                F4 = 1.
10          CONTINUE
            TOT = F1+F2+F3+F4
            IF(TOT.GT.3.5) GO TO 4
            IF(TOT.GT.2.5) GO TO 3
            IF(TOT.GT.1.5) GO TO 2
            IF(TOT.GT.0.5) GO TO 1
            PKHS=1.
            GO TO 20
1           P1=(.99857-.000052960 6*CEPS+.000000341377*CEPS**2)*F1
            P2=(.99951-.000073615*CEPS-.000000042731*CEPS**2)*F2
            P3=(.98418-.000077764 9*CEPS-.000001520 60*CEPS**2)*F3
            P4=(.98867-.000114141*CEPS+.000000115539*CEPS**2)*F4
            PKHS=P1+P2+P3+P4
            GO TO 20
2           P1=(1.0027-.000127961*CEPS+.000000134138*CEPS**2)*F1*F2
            P2=(.98914-.000083624 2*CEPS+.000000365215*CEPS**2)*F1*F3
            P3=(.97357-.000117606*CEPS-.000000149176*CEPS**2)*F1*F4
            P4=(.99001-.000024652 7*CEPS-.000000471454*CEPS**2)*F2*F3
            P5=(.98489-.000238044*CEPS+.000000126457*CEPS**2)*F2*F4
            P6=(.96155-.000072148 3*CEPS-.000000038846 4*CEPS**2)*F3*F4
            PKHS=P1+P2+P3+P4+P5+P6
            GO TO 20
```

```
3       P1=(.99247-.00017642G*CEPS+.000000169423*CEPS**2)*F1*F2*F3
        P2=(.96715-.00031674 1*CEPS+.000000774279*CEPS**2)*F1*F2*F4
        P3=(.94733-.00034973 7*CEPS+.000000451736*CEPS**2)*F1*F3*F4
        P4=(.92959-.00033381 7*CEPS+.000000124132*CEPS**2)*F2*F3*F4
        PKHS=F1+P2+P3+P4
        GO TO 20
4       PKHS=.86150-.00040426 1*CEPS+.000000C113008*CEPS**2
20      CONTINUE
        AVS = PKHS * 600.
        RETURN
        END
         SUBROUTINE SORTI
       &XL1,XH1,D1,PKH1,PS1,   XL2,XH2,D2,PKH2,PS2, XL3,XH3,D3,PKH3,PS3,
       &ACR1,NSRT,XNPAS,NS,          ACR2,TOTSR,TOTACK,TOTACL,TOTACR)
C*************************************************************************
C       XL-PENDIS      H-THREAT DENSITY     D- THREAT DIAMETER
C
C*************************************************************************
C
          W1 = XL1 * XH1 * D1 / 100.
          W2 = XL2 * XH2 * D2 / 100.
          W3 = XL3 * XH3 * D3 / 100.
C
          PSM1 = PS1 ** W1
          PSM2 = PS2 ** W2
          PSM3 = PS3 ** W3
C
          PH1 = (1. - PSM1)/PKH1
          PH2 = (1. - PSM2)/PKH2
          PH3 = (1. - PSM3)/PKH3
C
C***************THREAT 1***************
               H1 = ACR1 * PH1
               XK1 = H1 * PKH1
               A1 = H1 - XK1
C***************THREAT 2***************
                  H2 = (ACR1-H1) * PH2
                  XK2 = H2 * PKH2
                  A2 = H2 - XK2
C***************THREAT 3***************
                     H3 = (ACR1-H1-H2) * PH3
                     XK3 = H3 * PKH3
                     A3 = H3 - XK3
C***************OVER TARGET**************
                ACOVER = ACR1-H1-H2-H3
                ATAC = ACOVER * XNPAS
C***************EGRESS*****************
C***************THREAT 1***************
```

```
                H4 = ACCVER * PH1
                XK4 = H4 * PKH1
                A4 = H4 - XK4
C***************THREAT 2***************
                  H5 = (ACCVER-H4) * PH2
                  XK5 = H5 * PKH2
                  A5 = H5 - XK5
C***************THREAT 3***************
C- #1 ------------------------------------------------------------------
                    H6 = (ACCVER-H4-H5) * PH3
                    XK6 = H6 * PKH3
                    A6 = H6 - XK6
C***************TOTALS FOR SORTIE********
                  ACNHT = ACR1-H1-H2-H3-H4-H5-H6
                  ACDAM = A1 + A2 + A3 + A4 + A5 + A6
                  ACKIL = XK1 + XK2 + XK3 + XK4 + XK5 + XK6
C***************FOR NEXT SORTIE***********
                    ACR2 = ACNHT
                    TOTSR = ACR1
                    TOTACK = ATAC
                    TOTACL = ACKIL
                    TOTACR = ACDAM
          RETURN
            END
          SUBROUTINE CAMP(
       &XL1,XH1,D1,PKH1,PS1,   XL2,XH2,D2,PKH2,PS2,  XL3,XH3,D3,PKH3,PS3,
       &ACR1,NSRT,XNPAS,AS,          ACR2,TOTSR,TOTACK,TOTACL,TOTACR)
C*****************************************************************************
C         XL-PENDIS      H-THREAT DENSITY     D- THREAT DIAMETER
C
C*****************************************************************************
          DIMENSION ACR(200)
            TOTSR   = 0.
            TOTACK  = 0.
            TOTACL  = 0.
            TOTACR  = 0.
C
          W1 = XL1 * XH1 * D1 / 100.
          W2 = XL2 * XH2 * D2 / 100.
          W3 = XL3 * XH3 * D3 / 100.
C
          PSM1 = PS1 ** W1
          PSM2 = PS2 ** W2
          PSM3 = PS3 ** W3
C
          PH1 = (1. - PSM1)/PKH1
          PH2 = (1. - PSM2)/PKH2
          PH3 = (1. - PSM3)/PKH3
```

```
C
      ACR(1)= ACR1
      DO 10 I = 1,NSRT
C*****************INGRESS*****************
         H1 = ACR(I) * PH1
         XK1 = H1 * PKH1
         A1 = H1 - XK1
            H2 = (ACR(I)-H1) * PH2
            XK2 = H2 * PKH2
            A2 = H2 - XK2
               H3 = (ACR(I)-H1-H2) * PH3
               XK3 = H3 * PKH3
               A3 = H3 - XK3
C****************OVER TARGET**************
          ACOVER = ACR(I)-H1-H2-H3
          ATAC = ACOVER * XNPAS
C****************EGRESS*****************
         H4 = ACOVER * PH1
         XK4 = H4 * PKH1
         A4 = H4 - XK4
            H5 = (ACOVER-H4) * PH2
            XK5 = H5 * PKH2
            A5 = H5 - XK5
C- #1 ------------------------------------------------------------------
               H6 = (ACOVER-H4-H5) * PH3
               XK6 = H6 * PKH3
               A6 = H6 - XK6
C***************TOTALS FOR SORTIE********
          ACNHT = ACR(I)-H1-H2-H3-H4-H5-H6
          ACDAM = A1 + A2 + A3 + A4 + A5 + A6
          ACKIL = XK1 + XK2 + XK3 + XK4 + XK5 + XK6
C**************FOR NEXT SORTIE**********
               TOTACR = TOTACR+ACDAM
               ACROUT = TOTACR/FLOAT(NS)
               TOTACR = TOTACR-ACROUT
               ACR(I+1) = ACNHT + ACROUT
               ACR2 = ACR(I+1)
               TOTSR = TOTSR + ACR(I)
               TOTACK = TOTACK + ATAC
               TOTACL = TOTACL + ACKIL
10       CONTINUE
      RETURN
        END
        SUBROUTINE ESRWT(ES,EC,EL,TW,WS,WT,
C*************************************************************************
C********* TOGW DETERMINATION SUBROUTINE *********************************
C*************************************************************************
     @     IFS,IFV,JAM,IRCS,PENALT,PENDIS,PENMAC,IWARN,ICHAFF,
```

```
     a     BLTOGW,TOGW)
           REAL A,B,C,D,E,F,G,H,I,J
           TOGW = C.
           BLTOGW = 0.
           A = TW
           B = WS
           C = PENALT
           D = PENMAC
           E = PENDIS
           F = WT
           G = 0.
           H = 0.
           I = 0.
           J = 0.
C************** BLTOGW ************************************************
C- #1 ---------------------------------------------------------------
        BLTOGW = 95528.1-2.42453*C-163669C.*G+5771.94*A*D+1.00566*A*H
     a    +.C0404312*B*C-1.41229*B*E-13033.3*B*G+.000023164*C*C
     a    -.388375*C*D+.0000132684*C*H+.872068*C*I+138.061*D*E
     a    +1.307C6*D*F+1611310*D*G+.411576*D*H+37635.65*D*J+5560.39*E*G
     a    -22.6367*F*I-4.18043*F*J+13373400.*G*G+41.0552*G*H
     a    -1827710.*G*I+2504410.*G*J
C*********************************************************************
C        A/C TOGW OF DESIGN WITH SURVIVABILITY ENHANCEMENT
C*********************************************************************
C        THE FOLLOWING ASSUMPTION MADE;
C             ALL SELF-SEALING DONE FOR 23 MM
C             TWO WING TANKS, FOUR FUSELAGE TANKS, PLUS SUMP TANK(S)
C             DUAL SUMP TANKS HAVE EQUAL VOLUMN OF SINGLE SUMP TANK
C             EACH TANK HOLDS 1/7 OF TOTAL VOLUMN
C             INTERNAL FOAM VICE ULLAGE INERTING
C             FIRE EXTINGUISHING VICE VOID FOAM
C*********************************************************************
        IF(JAM.EQ.C) GO TO 40
          SREF=BLTOGW/WS
C- #1 ---------------------------------------------------------------
          T1=1./(1.+0.1296**PENMAC**2)**.648
          T2=.8934/PENMAC**2
          T3=1.793-1.036/(PENMAC**2)+.162/(PENMAC**4)
        G = (0.0536*T1+T2+T3*PENMAC**.5)/SREF
40        CONTINUE
C*********************************************************************
C        WEIGHT INCREASE CALCULATIONS
C*********************************************************************
C*******  FR = FUEL RECUIRED FOR MISSION ******************************
C- #1 ---------------------------------------------------------------
       FR=9499.85-.772933*C+24414.*D-464065.*A*G+.414073*A*H
      *    -.C0681604*B*F
```

```
     @ -19611.*B*C+345.404*B*I+.0000173927*C*C-.545816*C*D-.0011389*C*E
     @  +.31419*C*I+69.4257*D*E+.68633*D*F+944143.*D*G+.0876982*D*H
     @  +19218.8*D*J+2979.94*E*G-23.2469*F*I+10929000.*G*G+20.0457*G*H
     @  -1573550.*G*I+151722C.*G*J+.C00011762*H*H
C******* WEIGHT INCREASE DUE TO SELF-SEALING ************************
        XNT = 2.
        IF((IFS.EQ.1).OR.(IFS.EQ.2)) XNT = 0.
        IF(IFS.EC.3) XNT = 1.
      WSSP = 1.49*(2.2*8./7.-1.)*(1./7.)**.75*(FR/6.6)**.64*XNT**.11
C******* WEIGHT INCREASE DUE TO INTERNAL FOAM ***********************
      WF = 0.
        IF((IFV.EQ.2).OR.(IFV.EQ.6)) WF = .C186 * FR/6.6
C******* WEIGHT INCREASE DUE TO FIRE EXTINGUISHING ******************
      WFE = 0.
        XV = 4./3. * ( EC + ES) * EC * EL
        IF((IFV.EQ.5).OR.(IFV.EQ.6)) WFE = 10.5 * XV**.26
C******* WEIGHT INCREASE DUE ULLAGE INERTING ************************
      WIRT = .015 * (FR/6.6)**.92 * XNT
C******* WEIGHT INCREASE DUE EXTERNAL FOAM ***************************
      WEF = 0.
        IF(IFV.EC.4) WEF = 2.65*(BLTOGW-FR)*.001
C******* WEIGHT INCREASE DUE TO RAM **********************************
        XTT = .1
        XS = 0.
        IF(IRCS.EQ.1) XS = 10.
        IF((IRCS.EQ.2).OR.(IRCS.EQ.3)) XS = 50.
        IF(IRCS.EQ.4) XS = 60.
        IF(IRCS.EQ.5) XS = 70.
        IF(IRCS.EQ.6) XS = 80.
        IF((IRCS.EQ.7).OR.(IRCS.EQ.8)) XS = 80. + BLTOGW/WS *.63
        WRAM = XTT * XS * 23.8
C******* WEIGHT INCREASE DUE TO RWR **********************************
        WEW = 0.
        IF(IWARN.EQ.1) WEW = 50.
C******* WEIGHT INCREASE DUE TO RADAR JAMMER *************************
        WJW = 0.
        IF(JAM.EC.1) WJW = 80.
        IF(JAM.EC.2) WJW = 100.
        IF(JAM.EC.3) WJW = 200.
        IF(JAM.EC.4) WJW = 500.
        IF(JAM.EC.5) WJW = 1000.
C******* WEIGHT INCREASE DUE TO CHAFF DISPENSER **********************
        WCD = 0.
        IF(ICHAFF.EQ.1) WCD = 86.
C******* WEIGHT INCREASE DUE TO SUBMERGED STORE **********************
        WSOR = 0.
        IF((IRCS.EQ.7).OR.(IRCS.EQ.8)) WSOR = 1.13 * WT/100.
C*********************************************************************
```

```
C****** TOTAL WEIGHT INCREASE ************************************
      H =  WSSP+WF+WFE+WIRT+WEF+WRAM+WEW+WJW+WCD+WSOR
C*****************************************************************
C****** TOTAL TOGN OF ENHANCED A/C*********************************
C*****************************************************************
C- #1 ------------------------------------------------------------------
      TOGW = 95528.1-2.43453*C-163669C.*G+5771.94*A*D+1.00566*A*H
     @    +.00404312*B*C-1.41229*B*E-13033.3*B*G+.000023164*C*C
     @    -.388375*C*D+.000132684*C*H+.872068*C*I+138.061*D*E
     @    +1.307C6*C*F+1611310.*D*G+.411576*D*H+37639.65*D*J+5560.39*E*G
     @    -22.6367*F*I-4.18043*F*J+1337340C.*G*G+41.0552*G*H
     @    -1827710.*G*I+2504410.*G*J
      RETURN
      END
```

```
C*************************************************************************
C**                                                                     **
C**      STRPLT < STRIKE PLOT >                                         **
C**      PROGRAM TO GRAPH P(K)'S VS. THREATS AGAINST                    **
C**      LONG RANGE STRIKE AIRCRAFT                                     **
C**                                                                     **
C*************************************************************************
      DIMENSION YC(3),Y1(2),Y2(2),Y3(2),XC(2),IPKRAY(400)
     *          ,LABEL(12)
      DATA LABEL/' ',' ',' ',' ','A/A ','MISS','ILE ',
     *           'SAM ',' ',' ',' ',' ',' ',' ',' '/
      DATA YC/0.,.5,1./
      DATA XC/1.5,2.5/
C
      READ(8,800)(Y1(I),I=1,2),(Y2(I),I=1,2),(Y3(I),I=1,2)
  800 FORMAT(F4.2)
C
      CALL TEK618
      CALL HWROT('MOVIE')
      CALL BLOWUP (1.4)
      CALL PAGE(8.5,11.)
      CALL NOBRDR
      CALL AREA2D(6.,8.5)
      CALL XNAME('THREATS$',100)
      CALL YNAME('P(K)$',100)
      CALL SWISSM
      CALL SHDCHR(50.,1.,.003,1)
      CALL BASALF('STAND')
      CALL MIXALF('L/CSTC')
      CALL HEADIN('LONG RANGE STRIKE AIRCRAFT$',100,1.5,2)
      CALL HEADIN('L(OSS) R(ATE) VS. T(HREAT) T(YPE)$',100,1.1,2)
      CALL YREVTK
      CALL YAXANG(0.)
      CALL XTICKS(0)
      CALL XAXEND('NOENDS')
      CALL YAXEND('NOLAST')
      CALL SWISSL
      CALL HEIGHT(.12)
      CALL FRAME
      CALL THKFRM(.10)
      CALL XLABGR(LABEL,3,4,0.,.1,1,1)
      CALL FLREC(0.01,8.1,4.29,0.6,0)
      CALL BLREC(4.3,7.7,1.7,1.0,0)
      CALL BLKEY(IC)
      CALL CLUSTR(3,.08)
      CALL HEIGHT(.08)
      CALL BARDCC('SECOND','OUTSIDE',2)
      CALL BLBAR
```

```
CALL VBARS('LABEL',Y0,Y1,2)
CALL VBARS('LABEL',Y0,Y2,2)
CALL VBARS('LABEL',Y0,Y3,2)
CALL HEIGHT(.05)
CALL DCT
CALL GRID(0,2)
CALL RESET('DOT')
CALL HEIGHT(.10)
CALL BLOFF(IC)
MAXLIN=LINEST(IPKRAY,400,40)
CALL LINES('BASELINE)$',IPKRAY,1)
CALL LINES('1ST DESIGN)$',IPKRAY,2)
CALL LINES('2ND DESIGN)$',IPKRAY,3)
CALL LEGEND(IPKRAY,3,4.5,7.6)
CALL ENDPL(0)
CALL DONEPL
STOP
END
```

```
C*****************************************************************************
C**                                                                         **
C**      SUPPCRT                                                            **
C**      PROGRAM TO ASSESS CLOSE AIR SUPPORT AIRCRAFT SURVIVABILITY         **
C**                                                                         **
C*****************************************************************************
C             CLOSE AIR SUPPORT AIRCRAFT
C
C               THESE LINE NUMBERS ARE FOR EASY REFERENCE
C
C       MAIN MENU                                          1, 100, 1001
C       AIRCRAFT DESIGN SELECTION                          2, 110, 1110
C              A/C PERFORMANCE INDICATORS                 21, 210, 1210
C              SUSCEPTIBILITY FEATURES                    22, 220, 1220
C                     JAMMERS 221   RCS 222   RWR 223   CHAFF 224
C              VULNERABILITY FEATURES                     23, 230, 1230
C        COMBAT SCENARIO SELECTION                         3, 120, 1120
C              MISSION PROFILE                            31, 310, 1310
C              THREAT SELECTION                           32, 320, 1320
C        SUSCEPTIBILITY ASSESMENT                          4, 130, 1130
C              PROBABILITY OF DETECTION                   41, 410, 1410
C              PROBABILITY OF HIT                         42, 420, 1420
C                     AAA RADAR                              421
C                     AAA OPTICAL                            422
C                     LOW ALT SAM                            423
C        VULNERABILITY ASSESMENT                           5, 140, 1140
C                     AAA                                    510
C                     LOW ALY SAM                            520
C        SURVIVABILITY ASSESSMENT                          6, 150, 1150
C              P(S) 1:1 AAA (RADAR)                         610, 618
C              P(S) 1:1 AAA (OPTICAL)                       620, 628
C              P(S) 1:1 LOW ALT SAM                         630, 638
C              SINGLE SORTIE                                640, 1640
C              CAMPAIGN EVALUATION                          650, 1650
C        HELP                                               997
C        TRANFER                                            998
C        EXIT                                               999
C
      IMPLICIT REAL*4(A-H,O-Z),INTEGER*4(I-N)
C
      DIMENSION KK(4),K1(6),K2(3),K3(2),K4(2),K5(2),K6(5),
C- #5 ----------------------------------------------------------------
     *          JJ(2),PKAR(3),PKAO(3),PKSM(3)
C
      DATA K1/'DE','MS','SA','VA','SV','MM'/
      DATA K2/'AP','SF','VF'/
      DATA K3/'MP','TH'/
      DATA K4/'PD','PH'/
```

```
      DATA K5/'KH','KD'/
      DATA K6/'AR','AO','LS','SS','CE'/
      DATA KK/'HP','TN','EX','RT'/
C- #5 ------------------------------------------------------------------
      DATA JJ/'Y','N'/
C
C- #3 ------------------------------------------------------------------
C********* TO SAVE DATA ***************************************************
C
      CALL FRTCMS('CLRSCRN ')
      WRITE(4,1010)
1010  FORMAT(' ',' DATA MODE SELECTION, ENTER A CODE AS FOLLOWS:'//
     *T6,'IF THIS IS YOUR FIRST TIME THRCUGH SUPPORT OR YOU WISH'/
     *T6,'TO USE THE DEFAULT VALUES/PARAMETERS ENTER...0 '//
     *T6,'TO USE DATA SAVED FROM YOUR LAST RUN ENTER...1 '///
     *T20,'WARNING'//
     *T6,'--DO NOT ENTER 1 IF THIS IS YOUR FIRST RUN OR IF YOU HAVE'/
     *T6,'ERASED YOUR SUPPORT DATA FILE FROM YOUR DISK--'/)
C
      READ(4,1011)I1
1011  FORMAT(I1)
      IF(I1.EQ.0)GO TO 1021
      IF(I1.EQ.1)GO TO 1022
1022  CONTINUE
      REWIND 3
      READ(3,1012)TW,WS,WT,B,XL,W,EC,ED,EL,JAM,IRCS,IWARN,ICHAFF,IFS,
     *     IFV,IFE,IEA,IEP,ICS,ICA,XMR,XMA,XMT,AAAH,AAAD,SAMH,SAMD,
     *     PDAO,PDAR,PDSM,PHR,PHO,PHSM,VAAAA,PKHAAA,VASM,PKHSM,PSAR,
     *     PSAO,PSSM,ACR,X1NPAS,ACR1,NSRT,XNPASS,NS,
     *     ACR2,TCTSR,TCTACK,TOTACL,TOTACR,BLTOGW,TOGW
1012  FORMAT(' ',5G12.4)
      GO TO 1
C
1021  CONTINUE
      DATA TW/.55/,WS/90./,WT/8000./,B/40./,XL/40./,W/4./,EC/1.5/,ED/3.5
     &/, EL/12./
      DATA JAM/0/,IRCS/0/,IWARN/0/,ICHAFF/0/
      DATA IFS/1/,IFV/1/,IFE/1/,IEA/1/,IEP/1/,ICS/1/,ICA/1/
      DATA XMR/150./,XMA/10000./,XMT/60./
      DATA AAAH/.01/,AAAD/3./,SAMH/.0017/,SAMD/20./
      DATA PDAO/1./,PDAR/1./,PDSM/.9988/
      DATA PHR/.9007/,PHO/.1416/,PHSM/.1315/
      DATA VAAAA/100./,PKHAAA/.4531/,VASM/100./,PKHSM/1./
      DATA PSAR/.5919/,PSAO/.9358/,PSSM/.382/
C- #3 ------------------------------------------------------------------
      DATA ACR/100./,X1NPAS/1./
      DATA ACR1/100./,NSRT/20/,XNPASS/1./,NS/4/
      DATA ACR2/29.50/,TCTSR/1103.24/,TOTACK/1038.96/,TOTACL/64.51/
```

```
      DATA TCTACR/5.99/,BLTCGW/28945.09/,TOGW/28945.09/
C- #5 ------------------------------------------------------------------
      DATA N/0/
C*****************************************************************
C     MAIN MENU DISPLAY
C*****************************************************************
100       CONTINUE
1         CONTINUE
        CALL FRTCMS('CLRSCRN ')
      WRITE(4,1001)
1001  FORMAT('1','SUPPORT MENU (1) SELECT A CODE AS FOLLOWS:'//
     +T6,'FOR AN EXPLANATION           ',T51,'HP'/
     +T6,'AIRCRAFT DESIGN SELECTION    ',T51,'DE'/
     +T6,'COMBAT SCENARIO SELECTION    ',T51,'MS'/
     +T6,'SUSCEPTIBILITY ASSESSMENT    ',T51,'SA'/
     +T6,'VULNERABILITY ASSESSMENT     ',T51,'VA'/
     +T6,'SURVIVABILITY ASSESSMENT     ',T51,'SV'/
     +T6,'TC TRANSFER TO OTHER MENUS   ',T51,'TN'/
     +T6,'TC EXIT OR PRINT RESULTS     ',T51,'EX'/)
      READ(5,2000) K1C
2000  FORMAT(A4)
      IF(K1C.EQ.K1(1)) GO TO 110
      IF(K1C.EQ.K1(2)) GO TO 120
      IF(K1C.EQ.K1(3)) GO TO 130
      IF(K1C.EQ.K1(4)) GO TO 140
      IF(K1C.EQ.K1(5)) GO TO 150
      IF(K1C.EQ.KK(1)) GO TO 9971
      IF(K1C.EQ.KK(2)) GO TO 998
C- #3 ------------------------------------------------------------------
      IF(K1C.EQ.KK(3)) GO TO 1061
      WRITE(4,1200)
1200  FORMAT(' ','INPUT ERROR. REPEAT INPUT')
      GO TO 1
C*****************************************************************
C     MENU 2  DESIGN
C*****************************************************************
110     CALL FRTCMS('CLRSCRN ')
2         CONTINUE
      WRITE(4,1110)
1110  FORMAT('1','MENU (2) DESIGN,  ENTER  A CODE AS FOLLOWS:'//
     +T6,'FOR AN EXPLANATION           ',T51,'HP'/
     +T6,'A/C PERFORMANCE INDICATORS   ',T51,'AP'/
     +T6,'SUSCEPTIBILITY FEATURES      ',T51,'SF'/
     +T6,'VULNERABILITY FEATURES       ',T51,'VF'/
     +T6,'TC RETURN TO MENU (1)        ',T51,'RT'/
     +T6,'TC TRANSFER TO OTHER MENUS   ',T51,'TN'/)
      READ(5,2000) K2C
      IF(K2C.EQ.K2(1)) GO TO 210
```

```
      IF(K2C.EC.K2(2)) GC TC 220
      IF(K2C.EQ.K2(3)) GO TO 230
      IF(K2C.EC.KK(1)) GC TC 9972
      IF(K2C.EQ.KK(2)) GO TO 998
C- #3 ---------------------------------------------------------------
      IF(K2Q.EQ.KK(4)) GO TO 7
      WRITE(4,120C)
      GO TO 2
C*****************************************************************
C     MENU 3  COMBAT SCENARIC
C*****************************************************************
120      CALL FRTCMS('CLRSCRN ')
3         CCNTINUE
       WRITE(4,112C)
1120  FORMAT('1','MENU (3) COMBAT SCENARIC, ENTER  A CODE AS FOLLOWS:'//
     +T6,'FOR AN EXPLANATICN                ',T51,'HP'/
     +T6,'MISSION PROFILE                   ',T51,'MP'/
     +T6,'THREAT SELECTION                  ',T51,'TH'/
     +T6,'TC RETURN TO MENU (1)             ',T51,'RT'/
     +T6,'TO TRANSFER TO OTHER MENUS        ',T51,'TN'/)
      READ(5,20CO) K3Q
      IF(K3C.EQ.K3(1)) GO TC 310
      IF(K3Q.EQ.K3(2)) GO TC 320
      IF(K3C.EC.KK(1)) GO TC 9973
      IF(K3Q.EQ.KK(2)) GC TC 998
C- #3 ---------------------------------------------------------------
      IF(K3C.EQ.KK(4)) GC TC 7
      WRITE(4,120C)
      GO TO 3
C*****************************************************************
C     MENU 4 SUSCEPTIBILITY ASSESMENT
C*****************************************************************
130      CALL FRTCMS('CLRSCRN ')
4         CCNTINUE
       WRITE(4,1130)
1130  FORMAT('1','MENU (4) SUSCEPTIBILITY ASSESSMENT,'//
     *T6,'ENTER A CODE AS FCLLOWS:'//
     +T6,'FCR AN EXPLANATICN                ',T51,'HP'/
     +T6,'PRCBABILITY CF DETECTION          ',T51,'PD'/
     +T6,'PRCBABILITY OF HIT                ',T51,'PH'/
     +T6,'TC RETURN TO MENU (1)             ',T51,'RT'/
     +T6,'TC TRANSFER TO OTHER MENUS        ',T51,'TN'/)
      READ(5,20CO) K4Q
      IF(K4C.EQ.K4(1)) GO TC 410
      IF(K4Q.EQ.K4(2)) GC TC 420
      IF(K4C.EQ.KK(1)) GO TC 9974
      IF(K4Q.EQ.KK(2)) GC TC 998
C- #3 ---------------------------------------------------------------
```

```
      IF(K4C.EQ.KK(4)) GC TC 7
      WRITE(4,120C)
      GO TO 4
C*****************************************************************
C     MENU 5  VULNERABILITY ASSESMENT
C*****************************************************************
140      CALL FRTCMS('CLRSCRN ')
5         CCNTINUE
       WRITE(4,114C)
1140  FORMAT('1','MENU (5) VULNERABILITY ASSESSMENT,'//
     *T6,'ENTER A CODE AS FOLLOWS:'//
     +T6,'FOR AN EXPLANATICN              ',T51,'HP'/
     +T6,'VULN AREA / P(K/H) VS AAA       ',T51,'KH'/
     +T6,'VULN AREA / P(K/H) VS SAM       ',T51,'KD'/
     +T6,'TC RETURN TO MENU (1)           ',T51,'RT'/
     +T6,'TC TRANSFER TO OTHER MENUS      ',T51,'TN'/)
      READ(5,2000,ERR=1061) K5Q
      IF(K5C.EQ.K5(1)) GO TO 510
      IF(K5C.EQ.K5(2)) GC TC 520
      IF(K5C.EQ.KK(1)) GO TC 9975
      IF(K5Q.EQ.KK(2)) GC TC 998
C- #3 ---------------------------------------------------------------
      IF(K5Q.EQ.KK(4)) GC TC 7
      WRITE(4,120C)
      GO TO 5
C*****************************************************************
C     MENU 6 SURVIVABILITY ASSESMENT
C*****************************************************************
150      CALL FRTCMS('CLRSCRN ')
6         CCNTINUE
       WRITE(4,115C)
115C  FORMAT('1','MENU (6) SURVIVABILITY ASSESSMENT,'//
     *T6,'ENTER A CODE AS FCLLOWS:'//
     +T6,'FOR AN EXPLANATICN              ',T51,'HP'/
     +T6,'P(S) 1:1 AAA (RADAR)            ',T51,'AR'/
     +T6,'P(S) 1:1 AAA (CPTICAL)          ',T51,'AO'/
     +T6,'P(S) 1:1 LOW ALT SAM            ',T51,'LS'/
     +T6,'SINGLE SCRTIE                   ',T51,'SS'/
     +T6,'CAMPAIGN EVALUATICN             ',T51,'CE'/
     +T6,'TC RETURN TO MENU (1)           ',T51,'RT'/
     +T6,'TC TRANSFER TO OTHER MENUS      ',T51,'TN'/)
      READ(5,2000,ERR=1061) K6Q
      IF(K6C.EC.K6(1)) GC TO 610
      IF(K6C.EC.K6(2)) GC TC 620
      IF(K6C.EC.K6(3)) GO TO 630
      IF(K6Q.EQ.K6(4)) GC TC 640
      IF(K6Q.EQ.K6(5)) GC TO 650
      IF(K6Q.EQ.KK(1)) GO TC 9978
```

```
      IF(K6C.EQ.KK(2)) GO TO 998
C- #3 ---------------------------------------------------------------------
      IF(K6C.EQ.KK(4)) GO TO 7
      WRITE(4,120C)
      GO TO 6
C
C- #3 ---------------------------------------------------------------------**
C*****************************************************************************
C**    MENU 7    REASSESSMENT                                               **
C*****************************************************************************
    7 CONTINUE
      CALL SRPDSM(JAM,IRCS,PDSM)
      CALL SRPHR(TW,WS,PHR)
      CALL SRPHC(TW,PHC)
      CALL SRPHSM(IWARN,ICHAFF,TW,WS,PHSM)
      CALL SRVAAA(IFS,IFV,IFE,IEA,IEP,ICS,ICA,TW,WS,XMR,XMA,XMT,WT,
     *            VAAAA,PKHAAA)
     *CALL SRVASM(IFS,IFV,VASM,PKHSM)
C
C
      PSAR = 1. - PDAR * PHR * PKHAAA
      PSAC = 1. - PDAC * PHC * PKHAAA
      PSSM = 1. - PDSM * PHSM * PKHSM
C
      CALL CAMP(XMR,AAAH,ARC,PKHAAA,PSAR,XMR,AAAH,AOD,PKHAAA,PSAC,
     *          XMR,SAMF,SAMD,PKHSM,PSSM,ACR1,NSRT,XNPASS,NS,
     *          ACR2,TOTSR,TCTACK,TOTACL,TCTACR)
C
      GO TO 1
C
C
C- #5 ---------------------------------------------------------------------**
C*****************************************************************************
C**    MENU (8)     ROUTINE TO GENERATE P(K) VALUES FOR PLOTTING            **
C*****************************************************************************
    8 CONTINUE
      IF(N.GE.3) GO TO 999
      CALL FRTCMS('CLRSCRN ')
      WRITE(4,801)N
  801 FORMAT('1',' MENU(8) GRAPH CHOICES'//
     *       T6,'DO YOU WISH TO SAVE P(K) FOR THIS DESIGN?'/
     *       T6,'YOU HAVE ALREADY CHOSEN ',I1,' OF THE',
     *          ' 3 POSSIBLE DESIGNS'/T6,'FOR THIS PLOT.'//
     *       T6,'ENTER A CODE AS FOLLOWS:'/
     *       T6,'   TO SAVE P(K)',T51,'Y'/
     *       T6,'   DO NOT SAVE',T51,'N'/
     *       T6,'   FOR FURTHER EXPLANATION',T51,'HP')
C
```

```
      READ(4,2000)K80
         IF(K80.EC.JJ(1)) GC TO 81
         IF(K80.EC.JJ(2)) GC TO 999
         IF(K80.EC.KK(1)) GC TO 8988
C
      WRITE(4,120C)
      GO TO 8
   81 CONTINUE
         N = N + 1
         PKAR(N) = 1. - PSAR
         PKAC(N) = 1. - PSAC
         PKSM(N) = 1. - PSSM
C
      IF(N.NE.3) GO TO 999
C
      WRITE(9,802)(PKAR(I),PKAC(I),PKSM(I),I=1,3)
  802 FORMAT(F4.2)
      GO TO 999
C*****************************************************************
C     MENU 21 A/C PERFCRMANCE INPUTS
C*****************************************************************
210      CALL FRTCMS('CLRSCRN ')
21        CCNTINUE
       WRITE(4,1210)TW,WS,WT,B,XL,W,EC,ED,EL
1210  FORMAT('1',       MENU (21) ENTER  A CODE AS FOLLOWS:'//
     +T6,'      A/C PERFORMANCE INDICATORS  '/
     +T6,'1    THRUST TC WEIGHT            ',T51,F6.4/
     +T6,'2    WING LOADING                ',T51,F6.2,' PSF'/
     +T6,'3    CRDNANCE WEIGHT             ',T51,F6.0,' LBS'/
     +T6,'     WING SPAN                   ',T51,F6.2,' FT'/
     +T6,'     FUSELAGE LENGTH             ',T51,F6.2,' FT'/
     +T6,'     FUSELAGE WIDTH              ',T51,F6.2,' FT'/
     +T6,'     ENGINE FACE TC QUARTER CORD ',T51,F6.2,' FT'/
     +T6,'     ENGINE DIAMETER             ',T51,F6.2,' FT'/
     +T6,'     ENGINE LENGTH               ',T51,F6.2,' FT'//
     +T6,'VALUES 1,2 & 3 ARE VARIABLE; TC CHANGE THEM ENTER ITS NUMBER I
     +N'/T6,'I1 FCRMAT. ENTER 0 FOR NO CHANGE REQUIRED')
       READ(5,1211)I1
1211  FORMAT(I1)
       IF(I1.EQ.0) GO TO 110
       GO TO (211,212,213),I1
1212  WRITE(4,120C)
       GO TO 210
211        CCNTINUE
           WRITE(4,1201)
1201       FCRMAT('0','      TW RANGE ALLCWED IS .45 TO .65'/
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
           READ(5,1202)V1
```

```
1202      FORMAT(F8.4)
          TW=V1
          GO TO 210
212       CONTINUE
          WRITE(4,1203)
1203      FORMAT('0','      WS RANGE ALLOWED IS 80. TO 100.'/
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
          READ(5,1202)V1
          WS=V1
          GO TO 210
213       CONTINUE
          WRITE(4,1204)
1204      FORMAT('0','      WT RANGE ALLOWED IS 5000. TO 10000.'/
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
          READ(5,1202)V1
          WT=V1
          GO TO 210
C*****************************************************************
C     MENU 22 SUSCEPTIBILITY FEATURES
C*****************************************************************
220       CALL FRTCMS('CLRSCRN ')
22        CONTINUE
          WRITE(4,1220)JAM,IRCS,IWARN,ICHAFF
1220      FORMAT('1','      MENU (22) ENTER  A CODE AS FOLLOWS:'//
     +T6,'      SUSCEPTIBILITY REDUCTION FEATURES      '//
     +T6,'1    JAMMER NUMBER              ',T51,I1/
     +T6,'2    RCS REDUCTION LEVEL        ',T51,I1/
     +T6,'3    RADAR WARNING RECEIVER     ',T51,I1/
     +T6,'4    CHAFF DISPENSER            ',T51,I1//
     +T6,'"0" INDICATES NOT INSTALLED "1" INDICATES INSTALLED'//
     +T6,'TO CHANGE A VALUE ENTER ITS NUMBER IN I1 FORMAT'/
     +T6,'ENTER 0 FOR NO CHANGE REQUIRED')
          READ(5,1211)I1
          IF(I1.EQ.0) GO TO 110
          GO TO (221,222,223,224),I1
1229      WRITE(4,1200)
          GO TO 220
221       CONTINUE
          CALL FRTCMS('CLRSCRN ')
          WRITE(4,1221)
1221      FORMAT('1','            JAMMERS AVAILABLE         '//
     +T6,'0                        00  ',/
     +T6,'1                        50 WATTS',/
     +T6,'2                       100 WATTS',/
     +T6,'3                       200 WATTS',/
     +T6,'4                       500 WATTS',/
     +T6,'5                      1000 WATTS',//
     +T6,'ENTER THE JAMMER NUMBER IN I1 FORMAT')
```

```
            READ(5,1211)I1
            JAM=I1
            GO TO 220
222         CONTINUE
           CALL FRTCMS('CLRSCRN ')
            WRITE(4,1222)
1222        FORMAT('0','      RCS REDUCTION LEVELS                '//
     +T6,'0                    NO REDUCTION  ',/
     +T6,'1                    PROCEDURE 1',/
     +T6,'2                    PROCEDURE 1 & 2',/
     +T6,'3                    PROCEDURE 1,2,3,4,& 5',//
     +T6,'ENTER THE DESIRED RCS LEVEL IN I1 FORMAT')
            READ(5,1211)I1
            IRCS=I1
            GO TO 220
223         CONTINUE
            WRITE(4,1223)
1223        FORMAT(' ',' RADAR WARNING RECEIVER                   '//
     +T6,'"0" INDICATES NOT INSTALLED, "1" INDICATES INSTALLED'/
     +T6,'ENTER "0" OR "1" IN I1 FORMAT')
            READ(5,1211)I1
            IWARN=I1
            GO TO 220
224         CONTINUE
            WRITE(4,1224)
1224        FORMAT(' ',' CHAFF DISPENSER                          '//
     +T6,'"0" INDICATES NOT INSTALLED, "1" INDICATES INSTALLED'/
     +T6,'ENTER "0" OR "1" IN I1 FORMAT')
            READ(5,1211)I1
            ICHAFF=I1
            GO TO 220
C*************************************************************************
C     MENU 23  VULNERABILITY FEATURES
C*************************************************************************
230         CALL FRTCMS('CLRSCRN ')
23          CONTINUE
      WRITE(4,1230)IFS,IFV,IFE,IEA,IEP,ICS,ICA
1230  FORMAT('1',      MENU (23) ENTER  A CODE AS FOLLOWS:'//
     +T6,'       VULNERABILITY  REDUCTION FEATURES  '//
     +T6,'1    FUEL SYSTEM GENERAL      ',T51,I1/
     +T6,'2    FUEL/VOID INTERFACE      ',T51,I1/
     +T6,'3    FUEL/ENGINE INTERFACE    ',T51,I1/
     +T6,'4    ENGINE ARRANGEMENT       ',T51,I1/
     +T6,'5    ENGINE PROTECTION        ',T51,I1/
     +T6,'6    CONTROL SYSTEM           ',T51,I1/
     +T6,'7    CREW ARRANGMENT          ',T51,I1//
     +T6,'"1" MINIMUM PROTECTION '/
     +T6,'TO CHANGE A VALUE ENTER ITS NUMBER IN I1 FORMAT'//
```

```
     +T6,'ENTER 0 FOR NO CHANGE REQUIRED')
      READ(5,1211)I1
      IF(I1.EQ.0) GO TO 110
      GO TO (231,232,233,234,235,236,237),I1
1239  WRITE(4,120C)
      GO TO 230
231       CONTINUE
          CALL FRTCMS('CLRSCRN ')
          WRITE(4,1231)
1231  FORMAT('1',                FUEL SYSTEM, GENERAL       '//
     +T6,'1     SINGLE SUMP TANK, NO SELF-SEALING   ',/
     +T6,'2     SINGLE SUMP TANK, WITH SELF-SEALING',/
     +T6,'3     DUAL SUMP TANKS , NO SELF-SEALING    ,    NO SEPARATION',/
     +T6,'4     DUAL SUMP TANKS , WITH SELF-SEALING  ,    NO SEPARATION',/
     +T6,'5     DUAL SUMP TANKS , EXTRA SELF-SEALING,     NO SEPARATION',/
     +T6,'6     DUAL SUMP TANKS , NO SELF-SEALING    , WITH SEPARATION',/
     +T6,'7     DUAL SUMP TANKS , WITH SELF-SEALING  , WITH SEPARATION',/
     +T6,'8     DUAL SUMP TANKS , EXTRA SELF-SEALING, WITH SEPARATION',//
     +T6,'ENTER THE PROTECTION NUMBER IN I1 FORMAT')
          READ(5,1211)I1
          IFS=I1
          GO TO 230
232       CONTINUE
          CALL FRTCMS('CLRSCRN ')
          WRITE(4,1232)
1232  FORMAT('1',                FUEL/VOID INTERFACE        '//
     +T6,'1     TANKS ADJACENT TO DRY BAYS, HIGH SURFACE TEMP',/
     +T6,'2     TANKS ADJACENT TO DRY BAYS WITH ELECTRICAL EQUIPMENT',/
     +T6,'3     TANKS ADJACENT TO DRY BAYS WITH INERTING EQUIPMENT   ',/
     +T6,'4     INTERNAL FOAM OR INERTING FOR TANK ULLAGES           ',/
     +T6,'5     EXTERNAL FOAM OR FIRE EXTINGUISHING FOR VOIDS        ',/
     +T6,'6     BOTH INTERNAL AND EXTERNAL PROTECTION 2 OR 4 & 3 OR 5',//
     +T6,'ENTER THE DESIRED PROTECTION LEVEL IN I1 FORMAT')
          READ(5,1211)I1
          IFV=I1
          GO TO 230
233       CONTINUE
          CALL FRTCMS('CLRSCRN ')
          WRITE(4,1233)
1233  FORMAT('1',                FUEL/ENGINE INTERFACE      '//
     +T6,'1     FUEL AROUND ENGINE                  ',/
     +T6,'2     FUEL AROUND ENGINE WITH PROTECTION  ',/
     +T6,'3     FUEL AROUND DUCTS                   ',/
     +T6,'4     FUEL AROUND DUCTS WITH PROTECTION   ',/
     +T6,'5     DUCTS AROUND FUEL                   ',/
     +T6,'6     DUCTS AROUND FUEL WITH PROTECTION   ',/
     +T6,'7     FUEL FORWARD OF ENGINE              ',/
     +T6,'8     POSITIVE FUEL/ENGINE SEPARATION     ',//
```

```
     +T6,'ENTER THE PROTECTION NUMBER IN I1 FORMAT')
           READ(5,1211)I1
           IFE=I1
           GO TO 230
234        CONTINUE
          CALL FRTCMS('CLRSCRN ')
           WRITE(4,1234)
1234  FORMAT('1','                ENGINE ARRANGEMENT          '//
     +T6,'1    ONE ENGINE, OR TWO ENGINES SEPARATED BY LESS THAN 2 FT',/
     +T6,'2    TWO ENGINES SEPARATED OVER 2 FT               ',//
     +T6,'ENTER THE DESCRIPTION NUMBER IN I1 FORMAT')
           READ(5,1211)I1
           IEA=I1
           GO TO 230
235        CONTINUE
          CALL FRTCMS('CLRSCRN ')
           WRITE(4,1235)
1235  FORMAT('1','                ENGINE PROTECTION           '//
     +T6,'1    NONE                                          ',/
     +T6,'2    WITH PROTECTION AND/OR OVER 6 FT OF SEPARATION',//
     +T6,'ENTER THE DESCRIPTION NUMBER IN I1 FORMAT')
           READ(5,1211)I1
           IEP=I1
           GO TO 230
236        CONTINUE
          CALL FRTCMS('CLRSCRN ')
           WRITE(4,1236)
1236  FORMAT('1','                CONTROL SYSTEM              '//
     +T6,'1    NO BACKUP - OVER 5 SINGLE POINT FAILURE (SPF) SITES',/
     +T6,'2    NO BACKUP - UNDER 5 SPF SITES',/
     +T6,'3    WITH BACKUP - OVER 5 SPF SITES   ',/
     +T6,'4    WITH BACKUP - UNDER 5 SPF SITES  ',/
     +T6,'5    NO SINGLE POINT FAILURE SITES ',/
     +T6,'ENTER THE DESCRIPTION NUMBER IN I1 FORMAT')
           READ(5,1211)I1
           ICS=I1
           GO TO 230
237        CONTINUE
          CALL FRTCMS('CLRSCRN ')
           WRITE(4,1237)
1237  FORMAT('1','                CREW ARRANGEMENT            '//
     +T6,'1    NO BOTTOM SHIELD FOR PILOT BY ARMOR OR EQUIPMENT',/
     +T6,'2    NO SIDE SHIELD FOR PILOT BY ARMOR OR EQUIPMENT',/
     +T6,'3    PARTIAL ARMOR PROTECTION WITH STANDOFF(FRONT AND/OR BOTTO
     &M)',/
     +T6,'4    PARTIAL ARMOR PROTECTION WITH NO STANDOFF(FRONT AND/OR BO
     &TTOM)',/
     +T6,'5    FULL ARMOR PROTECTION WITH STANDOFF (FRONT,BOTTOM, AND SI
```

```
     &DES)',/
     +T6,'6     FULL ARMOR PROTECTION WITH NO STANDOFF (FRONT,BOTTOM AND
     &SIDES)',//
     +T6,'ENTER THE DESCRIPTION NUMBER IN I1 FORMAT')
           READ(5,1211)I1
           ICA=I1
           GO TO 230
C*************************************************************************
C      MENU 31  MISSION DESCRIPTION
C*************************************************************************
310        CALL FRTCMS('CLRSCRN ')
31         CONTINUE
       WRITE(4,1310)XMR,XMA,XMT
1310   FORMAT('1',' MENU (31)                                          '//
     +T6,'      MISSION DESCRIPTION          '//
     +T6,'1    MISSION RADIUS OF ACTION',T51,F6.0,' MI.'/
     +T6,'2    MISSION LOITER ALTITUDE ',T51,F6.0,' FT'/
     +T6,'3    MISSION TIME ON STATION ',T51,F6.0,' MINUTES'//
     +T6,'TO CHANGE THEM ENTER ITS NUMBER IN I1 FORMAT.'//
     +T6,' ENTER 0 FOR NO CHANGE REQUIRED')
       READ(5,1211)I1
       IF(I1.EQ.0) GO TO 120
       GO TO (311,312,313),I1
1319   WRITE(4,1200)
       GO TO 310
311        CONTINUE
           WRITE(4,1311)
1311       FORMAT('0',' MISSION RADIUS RANGE 200. TO 300. NM'//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
           READ(5,1202)V1
           XMR=V1
           GO TO 310
312        CONTINUE
           WRITE(4,1312)
1312       FORMAT('0',' LOITER ALTITUDE RANGE 1. TO 10000. FT'//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
           READ(5,1202)V1
           XMA=V1
           GO TO 310
313        CONTINUE
           WRITE(4,1313)
1313       FORMAT('0',' TIME ON STATION RANGE 60. TO 120. MIN.'//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
           READ(5,1202)V1
           XMT=V1
           GO TO 310
C*************************************************************************
C      MENU 32  THREAT DEFINITION
```

```
     +T6,'      THE PROBABILITY OF HIT IS DEFINED SEPARATELY FOR EACH'/
     +T6,' AIRCRAFT AND THREAT. HOWEVER, THE FORM IS CONSISTENT, WHERE'/
     +T6,' P(H) REFERS TO THE PROBABILITY THAT A NON-MANEUVERING A/C'/
     +T6,' WOULD BE HIT BY THE THREAT, F(M) IS THE MANEUVER FACTOR.'/
     +T6,' AND F(C) IS THE COUNTERMEASURE (CHAFF OR FLARE) FACTOR.'//
     +T6,'            P(H)'' = P(H) * F(M) * F(C)                  '//
     +T6,'        ENTER ANY INTEGER TO RETURN TO MENU 4             ')
      READ(5,*)IJK
      GO TO 130
 9975   CALL FRTCMS('CLRSCRN ')
      WRITE(4,7975)
 7975 FORMAT(' ',
     +T6,'                              HELP FOR MENU 5          '/
     +T6,'      THE VULNERABILITY ASSESSMENT SECTION CALCULATES  '/
     +T6,' EITHER THE P(K/H) OR THE AVERAGE VULNERABLE AREA FOR THE '/
     +T6,' AIRCRAFT VERSUS A THREAT. FOR THE SUPPORT AIRCRAFT;    '//
     +T6,'   VS AAA                                               '/
     +T6,'      AV  = REGRESSION FORMULA THAT IS A FUNCTION     '/
     +T6,'            OF VULNERABILITY FEATURE INPUTS           '/
     +T6,'      P(K/H) = 1- EXP (-1*AV/125.)'/
     +T6,'   VS SAM                                              '/
     +T6,'      P(K/H) = FROM TABLE BASED UPON VULN. FEATURES    '/
     +T6,'      AV  = 100. * EXP ( PKH - 1.)'/
     +T6,'        ENTER ANY INTEGER TO RETURN TO MENU 5           ')
      READ(5,*)IJK
      GO TO 140
 9976   CALL FRTCMS('CLRSCRN ')
      WRITE(4,7976)
 7976 FORMAT(' ',
     +T6,'                              HELP FOR MENU 41         '/
     +T6,'      THE FOLLOWING METHODS ARE USED FOR THE SUPPORT P(D)'//
     +T6,'   VS A/A GUNS/MISSILE                                  '/
     +T6,'      P(D) = 1.                                       '/
     +T6,'   VS SAM                                              '/
     +T6,'      P(D) = TWO TIMES THE INTEGRAL OF THE GAUSSIAN    '/
     +T6,'           PROBABILITY FUNCTION FROM INFINITY TO CPA'//
     +T6,'        ENTER ANY INTEGER TO RETURN TO MENU 41          ')
      READ(5,*)IJK
      GO TO 410
 9977   CALL FRTCMS('CLRSCRN ')
      WRITE(4,7977)
 7977 FORMAT(' ',
     +T6,'                              HELP FOR MENU 42         '/
     +T6,'      THE FOLLOWING METHODS ARE USED FOR THE SUPPORT P(H)'/
     +T6,'PH = PROBABILITY THAT A NON-MANEUVERING A/C IS HIT      '/
     +T6,'FA = PROBABILITY THAT THE CREW IS ALLERTED AND TAKES EVASIVE
     +ACTION.'/
     +T6,'FM = MANEUVER FACTOR          FC = CHAFF FACTOR'/
     +T6,'WS = WING LOADING/100.        TW = THRUST TO WEIGH'//
     +T6,'   VS AAA (OPTICAL)                                    '/
     +T6,'      PH= .1456                    FA= 1.'/
```

```
      WRITE(4,7972)
7972  FORMAT(' ',T
     +T6,' THE DESIGN SECTION IS DIVIDED INTO THREE SUBSECTIONS.'/
     +T6,'     THE AIRCRAFT PERFORMANCE INDICATORS AFFECT THE '/
     +T6,' ABILITY OF THE AIRCRAFT TO MANEUVER AND AVOID THE THREAT.'/
     +T6,' SOME OF THE VALUES MAY REMOVE THE AIRCRAFT FROM THE'/
     +T6,' THREAT ENVELOPE COMPLETELY. A FURTHER DISCUSSION OF THE '/
     +T6,' IMPACT OF THESE VALUES MAY BE FOUND IN THE P(H) SECTION'/
     +T6,' OF SUSCEPTIBILITY EVALUATION.                    '/
     +T6,'     SUSCEPTIBILITY REDUCTION FEATURES OF THE DESIGN ARE'/
     +T6,' ENTERED IN THIS SECTION. THESE INCLUDE JAMMER SIZE, RCS '/
     +T6,' REDUCTION LEVELS, CHAFF DISPENSER AND RADAR WARNING RE- '/
     +T6,' CEIVER. THE DEFAULT VALUES (BASELINE) ARE ZERO, INDICATING'/
     +T6,' NONE OF THESE FEATURES ARE INCLUDED.              '/
     +T6,'     VULNERABILITY REDUCTION FEATURES VARY WITH THE THREE'/
     +T6,' TYPES OF AIRCRAFT. SELECT THOSE FEATURES THAT BEST'/
     +T6,' DESCRIBE YOUR DESIGN. MINIMUM VALUES OF 1 (BASELINE)'/
     +T6,' INDICATE NO IMPROVEMENTS.                        '//
     +T6,'          ENTER ANY INTEGER TO RETURN TO MENU 2   ')
      READ(5,*)IJK
      GO TO 110
9973     CALL FRTCMS('CLRSCRN ')
      WRITE(4,7973)
7973  FORMAT(' ',T
     +T6,' THE COMBAT SCENERIO SECTION IS DIVIDED INTO TWO SUBSECTIONS.
     +'/,T6,'     IN MISSION PROFILE, VALUES ARE ENTERED TO SPECIFICALLY
     +',T6,' DEFINE THE DESIRED MISSION. THE MISSION PARAMETERS ARE DEFI
     +NED'/,T6,' BY THE SELECTION OF AIRCRAFT TYPE. THESE INCLUDE ITEMS'
     +/,T6,' THAT MIGHT BE CONSIDED TACTICS.                '/
     +T6,'     IN THREAT SELECTION, THREAT DENSITIES AND THREAT'/
     +T6,' DIAMETERS ARE ENTERED.  THE THREATS FOR THE CLOSE AIR'/
C- #2 ------------------------------------------------------------------
     +T6,' SUPPORT MISSION ARE; AAA (OPTICLE), AAA (RADAR), AND'/
     +T6,' LOW ALTITUDE SAM'S.'//
     +T6,'          ENTER ANY INTEGER TO RETURN TO MENU 3   ')
      READ(5,*)IJK
      GO TO 120
9974     CALL FRTCMS('CLRSCRN ')
      WRITE(4,7974)
7974  FORMAT(' ',T
     +T6,' THE SUSCEPTIBILITY ASSESSMENT SECTION HAS TWO SUBSECTIONS.'/
     +T6,'     THE PROBABILITY OF DETECTION IS AFFECTED BY THE'/
     +T6,' RCS OF THE AIRCRAFT, THE POWER OF THE NOISE JAMMER, '/
     +T6,' AND THE SLANT RANGE FROM THE THREAT TO THE A/C AT CPA.'/
     +T6,' NOTE THAT ALL AIRCRAFT ARE CONSIDERED TO PASS OVER A POINT'/
     +T6,' THAT IS THE SAME HORIZONTAL DISTANCE FROM THE THREAT '/
     +T6,' AS THE ALTITUDE OF THE AIRCRAFT. THIS MEANS THAT THE'/
     +T6,' CPA SLANT RANGE IS 1.414 TIMES THE ALTITUDE.'/
```

```
      WRITE(4,1656)
1656  FORMAT('0',T6,'ENTER MAX NUMBER OF SORTIES FOR REPAIR IN I2 FO
     +RMAT.')
      READ(5,1697)I2
      NS=I2
      GO TO 659
699   CONTINUE
      ARO= AAAD/FLOAT(JAM+1)
      AOD= AAAD-ARO
      CALL CAMP(XMR,AAAH,ARO,PKHAAA,PSAR,
     &XMR,AAAH,AOO,PKHAAA,PSAO,XMR,SAMH,SAMO,PKHSM,PSSM,
     & ACR1,NSRT,XNPASS,NS,ACR2,TOTSR,TOTACK,TOTACL,TOTACR)
      CALL FRTOMS('CLRSCRN ')
      WRITE(4,1699)ACR2,TOTSR,TOTACK,TOTACL,TOTACR
1699  FORMAT('1','     RESULTS OF THE CAMPAIGN AGAINST THE THREATS'//
     +T6,'     UNDAMAGED AIRCRAFT       ',T51,F6.0/
     +T6,'     SORTIES FLOWN            ',T51,F8.0/
     +T6,'     TARGETS ATTACKED         ',T51,F8.0/
     +T6,'     AIRCRAFT LOST            ',T51,F6.0/
     +T6,'     AIRCRAFT DAMAGED         ',T51,F6.0//
     +T6,'TO RERUN A CAMPAIGN ENTER 1 '/
     +T6,'TO RETURN TO MENU (6) ENTER 0')
      READ(5,1211)I1
      IF(I1.EQ.1) GO TO 650
      GO TO 150
C*****************************************************************
C     HELP
C*****************************************************************
9971      CALL FRTOMS('CLRSCRN ')
      WRITE(4,7971)
7971  FORMAT(' ',' '                          HELP FOR MENU 1                '/
     +T6,' THE VISAP DESIGN EVALUATOR IS DIVIDED INTO FIVE SECTIONS. '/
     +T6,'     THE AIRCRAFT DESIGN SECTION IS WHERE A DESCRIPTION OF'/
     +T6,' THE AIRCRAFT IS ENTERED. THIS INCLUDES GENERAL PARAMETRIC'/
     +T6,' SIZING VALUES AS WELL AS DESCRIPTIONS OF THE S/V FEATURES'/
     +T6,' CONTAINED IN THE DESIGN. VALUES SHOWN INITIALLY ARE DEFAULT'/
     +T6,' VALUES WHICH MAY BE CHANGED.'/
     +T6,'     THE MISSION SECTION IS WHERE THE MISSION PARAMETERS AND'/
     +T6,' THREAT INTENSITY VALUES ARE ENTERED. NOTE THAT THE TYPE'/
     +T6,' OF THREATS CANNOT BE CHANGED BECAUSE THE SELECTION OF THE'/
     +T6,' AIRCRAFT DETERMINES THE THREATS.                          '/
     +T6,'     THE LAST THREE SECTIONS ARE FOR EVALUATION OF THE'/
     +T6,' DESIGN. IF THE DESIGN AND THREAT SECTIONS ARE NOT ENTERED'/
     +T6,' DEFAULT VALUES (BASELINE) WILL BE USED FOR ALL CALCULATIONS.'
     +,//T6,'          ENTER ANY INTEGER TO RETURN TO MENU 1       ')
      READ(5,*)IJK
      GO TO 100
9972      CALL FRTOMS('CLRSCRN ')
```

```
     +T6,'TC RETURN TO MENU (6) ENTER 0')
      READ(5,1211)I1
       IF(I1.EQ.1) GO TO 640
       GO TO 150
C*****************************************************************************
C     MENU 63  CAMPAIGN ANALYSIS
C*****************************************************************************
650       CONTINUE
659        CONTINUE
          CALL FRTCMS('CLRSCRN ')
       WRITE(4,165C)ACR1,NSRT,XNPASS,NS,PSAR,PSAD,PSSM
1650  FORMAT('1',' MENU (63)  CAMPAIGN ANALYSIS '//
     +T6,'1    AIRCRAFT IN CAMPAIGN              ',T46,F6.0/
     +T6,'2    NUMBER OF RAIDS IN CAMPAIGN       ',T43,I6/
     +T6,'3    NUMBER OF PASSES PER SORTIE       ',T44,F6.0/
     +T6,'4    NUMBER OF SORTIES FOR REPAIR      ',T43,I6//
     +T6,'5    P(S) VS AAA(RACAR)                ',T48,F6.4/
     +T6,'6    P(S) VS AAA(CPTICAL)              ',T48,F6.4/
     +T6,'7    P(S) VS LOW ALT SAM               ',T48,F6.4//
     +T6,'TO CHANGE A VALUE ENTER ITS NUMBER IN I1 FORMAT.'/
     +T6,'ENTER 0 FOR NO CHANGE REQUIRED')
      READ(5,1659)I1
1659  FORMAT(I1)
      IF(I1.EQ.0) GO TO 699
      GO TO (651,652,653,656,618,628,638),I1
1658  WRITE(4,1200)
          GO TO 650
651       CONTINUE
          WRITE(4,1651)
1651      FORMAT('0',T6,'ENTER NUMBER OF A/C IN REAL NUMBER FORMAT.')
          READ(5,1657)V1
1657      FORMAT(F8.4)
          ACR1=V1
          GO TO 659
652       CONTINUE
          WRITE(4,1652)
1652      FORMAT('0',T6,'ENTER NUMBER OF RAIDS IN I2 FORMAT.')
          READ(5,1697)I2
1697      FORMAT(I2)
          NSRT=I2
          GO TO 659
653       CONTINUE
          WRITE(4,1653)
1653     FORMAT('0',T6,'ENTER PASSES PER SORTIE IN REAL NUMBER FORMAT.')
          READ(5,1202)V1
          XNPASS=V1
          GO TO 659
656       CONTINUE
```

```
            WRITE(4,1611)
            READ(5,1657)PDSM,PHSM,PKHSM
            PSSM=1.-PDSM * PHSM * PKHSM
            GO TO 638
C*****************************************************************
C     MENU 62  SORTIE ANALYSIS
C*****************************************************************
640         CONTINUE
649         CALL FRTCMS('CLRSCRN ')
          WRITE(4,1640)ACR,X1NPAS,PSAR,PSAO,PSSM
1640    FORMAT('1',' MENU (62)  SORTIE ANALYSIS     '//
       +T6,'1    AIRCRAFT IN SCRTIE                ',T46,F6.0/
       +T6,'2    NUMBER OF PASSES PER SCRTIE       ',T44,F6.0/
       +T6,'3    P(S) VS AAA (RADAR)               ',T48,F6.4/
       +T6,'4    P(S) VS AAA (OPTICAL)             ',T48,F6.4/
       +T6,'5    P(S) VS LOW ALT SAM               ',T48,F6.4//
       +T6,'TO CHANGE A VALUE ENTER ITS NUMBER IN I1 FORMAT.'/
       +T6,'ENTER 0 FOR NO CHANGE REQUIRED')
          READ(5,1659)I1
          IF(I1.EQ.0) GO TO 689
          GO TO (641,642,618,628,638),I1
1648    WRITE(4,120C)
            GO TO 64C
641         CONTINUE
            WRITE(4,1651)
            READ(5,1657)V1
            ACR=V1
            GO TO 649
642         CONTINUE
            WRITE(4,1653)
            READ(5,1202)V1
            X1NPAS=V1
            GO TO 649
689     CONTINUE
          ARD= AAAD/FLOAT(JAM+1)
          AOD= AAAO-ARD
          CALL SCRT(XMR,AAAH,ARD,PKHAAA,PSAR,
       &XMR,AAAH,AOD,PKHAAA,PSAO,XMR,SAMH,SAMD,PKHSM,PSSM,
       & ACR,1,X1NPAS,4,ACR2,TOTSR,TOTACK,TOTACL,TOTACR)
            CALL FRTCMS('CLRSCRN ')
          WRITE(4,1689)ACR2,TOTSR,TOTACK,TOTACL,TOTACR
1689    FORMAT('1',' RESULTS FROM SINGLE SORTIE AGAINST THE THREATS'//
       +T6,'  UNDAMAGED AIRCRAFT          ',T51,F6.2/
       +T6,'  SORTIES FLOWN               ',T51,F6.2/
       +T6,'  TARGETS ATTACKED            ',T51,F6.2/
       +T6,'  AIRCRAFT LOST               ',T51,F6.2/
       +T6,'  AIRCRAFT DAMAGED            ',T51,F6.2//
       +T6,'TO RERUN A SORTIE ANALYSIS ENTER "1"'/
```

```
            GO TO 618
  611       CONTINUE
            WRITE(4,1611)
 1611  FORMAT('0',T6,'ENTER P(D),P(H), P(K/H) IN REAL NUMBER FORTMAT'/
     +T6,'                    (RANGE 0.001 TO 1.00)')
            READ(5,1657)PDAR,PHR,PKHAA
            PSAR=1.- PDAR * PHR * PKHAA
            GO TO 618
C*************************************************************************
C       P(S) AAA OPTICAL
C*************************************************************************
  620       PSAO = 1.- PDAO * PHO * PKHAAA
  628       CALL FRTCMS('CLRSCRN ')
        WRITE(4,2220)JAM,IFS,IRCS,IFV,IWARN,IFE,ICHAFF,IEA,IEP,ICS,ICA
            WRITE(4,1620)PSAO,PDAO,PHO,PKHAAA
 1620       FORMAT('C',T6,' THE PROB OF SURVIVAL VS AAA(OPTICAL)'//
     +T6,'    PS    =   1   -    PD    *    PH    *    PK/H '/
     +T9,F6.4,7X,F6.4,3X,F6.4,3X,F6.4//
     +T6,'TO CHANGE THIS VALUE ENTER 1 IN I1 FORMAT'/
     +T6,'ENTER 0 FOR NO CHANGE REQUIRED')
            READ(5,1659)I1
            IF(I1.EQ.0) GO TO 150
            GO TO (621,1629),I1
 1629       WRITE(4,1200)
            GO TO 628
  621       CONTINUE
            WRITE(4,1611)
            READ(5,1657)PDAO,PHO,PKHAA
            PSAO=1.-PDAO * PHO * PKHAA
            GO TO 628
C*************************************************************************
C       P(S) LOW ALT SAM
C*************************************************************************
  630       PSSM = 1.- PDSM * PHSM * PKHSM
  638       CALL FRTCMS('CLRSCRN ')
        WRITE(4,2220)JAM,IFS,IRCS,IFV,IWARN,IFE,ICHAFF,IEA,IEP,ICS,ICA
            WRITE(4,1630)PSSM,PDSM,PHSM,PKHSM
 1630       FORMAT('C',T6,' THE PROB OF SURVIVAL VS SAM'//
     +T6,'    PS    =   1   -    PD    *    PH    *    PK/H '/
     +T9,F6.4,7X,F6.4,3X,F6.4,3X,F6.4//
     +T6,'TO CHANGE THIS VALUE ENTER 1 IN I1 FORMAT'/
     +T6,'ENTER 0 FOR NO CHANGE REQUIRED')
            READ(5,1659)I1
            IF(I1.EQ.0) GO TO 150
            GO TO (631,1639),I1
 1639       WRITE(4,1200)
            GO TO 638
  631       CONTINUE
```

```
1521      CALL FRTCMS('CLRSCRN ')
          WRITE(4,1522)VASM,PKHSM
1522    FORMAT('1',T6,' THE COMPUTED A(V) VS SAM IS ',T51,F6.0,' SQFT'/
     +T6,'THE P(K/H) IS ',T51,F6.4,//
     +T6,'TO CHANGE THESE VALUES ENTER 1'/
     +T6,' ENTER 0 FOR NO CHANGE REQUIRED')
          READ(5,1211)I1
          IF(I1.EQ.0) GO TO 140
          IF(I1.EQ.1) GO TO 1523
1524      WRITE(4,1200)
          GO TO 1521
1523        CONTINUE
            WRITE(4,1525)
1525        FORMAT('0','       VULN  AREA   RANGE   37.0 TO 100.0    '//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
            READ(5,1202)V1
            VASM=V1
            PKHSM = 1. + ALOG(VASM/100.)
            GO TO 1521
C*************************************************************************
C     MENU 61  P(S) AAA RADAR
C*************************************************************************
610         PSAR = 1.- PDAR * PHR * PKHAAA
618         CALL FRTCMS('CLRSCRN ')
          WRITE(4,2220)JAM,IFS,IRCS,IFV,IWARN,IFE,ICHAFF,IEA,IEP,ICS,ICA
2220    FORMAT('0',' SUSCEPTIBILITY REDUCTION FEATURES ',
     +T40,' * VULNERABILITY  REDUCTION FEATURES  '//
     +,'      JAMMER NUMBER              ',T35,I1,
     +T42,'    FUEL SYSTEM GENERAL        ',T69,I1/
     +,'      RCS REDUCTION LEVEL        ',T35,I1,
     +T42,'    FUEL/VOID INTERFACE        ',T69,I1/
     +,'      RADAR WARNING RECEIVER     ',T35,I1,
     +T42,'    FUEL/ENGINE INTERFACE      ',T69,I1/
     +,'      CHAFF DISPENSER            ',T35,I1,
     +T42,'    ENGINE ARRANGEMENT         ',T69,I1/
     +T42,'    ENGINE PROTECTION          ',T69,I1/
     +T42,'    CONTROL SYSTEM             ',T69,I1/
     +T42,'    CREW ARRANGMENT            ',T69,I1/)
          WRITE(4,1610)PSAR,PDAR,PHR,PKHAAA
1610      FORMAT('0',T6,' THE PROB OF SURVIVAL VS AAA(RADAR)'//
     +T6,'    PS    =  1  -   PD    *    PH    *    PK/H '/
     +T9,F6.4,7X,F6.4,3X,F6.4,3X,F6.4//
     +T6,'TO CHANGE THIS VALUE ENTER 1 IN I1 FORMAT'/
     +T6,'ENTER 0 FOR NO CHANGE REQUIRED')
          READ(5,1659)I1
          IF(I1.EQ.0) GO TO 150
          GO TO (611,1619),I1
1619      WRITE(4,1200)
```

```
423     CONTINUE
          CALL SRPHSM(IWARN,ICHAFF,TW,WS,PHSM)
1423      CALL FRTCMS('CLRSCRN ')
          WRITE(4,14923)PHSM
14923   FORMAT('1',16,'THE PROB. OF HIT BY LOW ALT. SAM  IS '
     +,F6.4//T6,'TO CHANGE THIS VALUE ENTER 1'/
     +T6,' ENTER 0 FOR NO CHANGE REQUIRED')
        READ(5,1211)I1
        IF(I1.EQ.0) GO TO 420
        IF(I1.EQ.1) GO TO 14232
14933   WRITE(4,1200)
        GO TO 1423
14232       CONTINUE
            WRITE(4,1497)
            READ(5,1202)V1
            PHSM=V1
            GO TO 1423
C*****************************************************************
C     MENU 51  VULN. AREA / P(K/H) VS AAA
C*****************************************************************
510     CONTINUE
         CALL SRVAAA(IFS,IFV,IFE,IEA,IEP,ICS,ICA,TW,WS,XMR,XMA,XMT,WT,VAA
     &AA,PKHAAA)
1511        CALL FRTCMS('CLRSCRN ')
            WRITE(4,1512)VAAAA,PKHAAA
1512    FORMAT('1',T6,'THE COMPUTED A(V) VS AAA IS ',T51,F6.0,' SQFT',/
     +T6,'THE P(K/H) IS ',T51,F6.4,//
     +T6,' TO CHANGE THESE VALUES ENTER 1'/
     +T6,' ENTER 0 FOR NO CHANGE REQUIRED')
        READ(5,1211)I1
        IF(I1.EQ.0) GO TO 140
        IF(I1.EQ.1) GO TO 1513
1514    WRITE(4,1200)
        GO TO 1511
1513        CONTINUE
            WRITE(4,1515)
1515        FORMAT('0',' VULN AREA RANGE 20.0 TO 100.0 '//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
            READ(5,1202)V1
            VAAAA=V1
C- #1 ------------------------------------------------------------
            PKHAAA = 1. - EXP(-1.*VAAAA/125.)
            GO TO 1511
C*****************************************************************
C     VULN. AREA / P(K/H) VS LOW ALT SAM
C*****************************************************************
520         CONTINUE
         CALL SRVASM(IFS,IFV,VASM,PKHSM)
```

```
      IF(K8Q.EQ.KK(4)) GC TC 130
      WRITE(4,1200)
      GO TO 42
C*****************************************************************
C     PROB CF HIT AAA RADAR
C*****************************************************************
421   CONTINUE
        CALL SRPHR(TW,WS,PHR)
1421    CALL FRTCMS('CLRSCRN ')
        WRITE(4,14911)PHR
14911 FORMAT('1',T6,'THE CCMPUTED P(H) BY AAA(RADAR) IS '
     +,F6.4//T6,'TC CHANGE THIS VALUE ENTER 1'/
     +T6,' ENTER 0 FCR NC CHANGE REQUIRED')
      READ(5,1211)I1
      IF(I1.EQ.0) GC TC 42C
      IF(I1.EQ.1) GO TO 14212
14913 WRITE(4,12CC)
      GO TO 1421
14212   CONTINUE
        WRITE(4,1497)
1497    FORMAT('C','      PH  RANGE   0.0 TC 1.0    '//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
        READ(5,1202)V1
        PHR=V1
        GC TO 1421
C*****************************************************************
C     PROB CF HIT AAA CPTICAL
C*****************************************************************
422   CONTINUE
        CALL SRPHC(TW,PHO)
1422    CALL FRTCMS('CLRSCRN ')
        WRITE(4,14921)PHC
14921 FORMAT('1',T6,'THE CCMPUTED P(H) BY THE AAA(OPTICAL) IS '
     +,F6.4//T6,'TC CHANGE THIS VALUE ENTER 1'/
     +T6,' ENTER 0 FOR NC CHANGE REQUIRED')
      READ(5,1211)I1
      IF(I1.EQ.0) GO TO 42C
      IF(I1.EQ.1) GO TO 14222
14929 WRITE(4,12CC)
      GO TO 1422
14222   CONTINUE
        WRITE(4,1497)
        READ(5,1202)V1
        PHC=V1
        GC TO 1422
C*****************************************************************
C     PROB CF HIT LOW ALT SAM
C*****************************************************************
```

```
      IF(I1.EQ.0) GO TO 410
      IF(I1.EQ.1) GO TO 1416
1418  WRITE(4,120C)
      GO TO 412
1416      CONTINUE
          WRITE(4,1417)
          READ(5,1202)V1
          PCAO=V1
          GC TO 412
C*****************************************************************
C     PD VS SAM
C*****************************************************************
413       CONTINUE
        CALL SRPDSM (JAM,IRCS,PDSM)
        CALL FRTCMS('CLRSCRN ')
1490   WRITE(4,1451)PDSM
1491  FORMAT('1',T6,'THE COMPUTED P(D) BY LOW ALT. SAM (RADAR) IS '
     +,F6.4//T6,'TC CHANGE THIS VALUE ENTER 1'/
     +T6,' ENTER C FCR NC CHANGE REQUIREC')
      READ(5,1211)I1
      IF(I1.EQ.0) GO TO 410
      IF(I1.EQ.1) GO TO 1492
1493  WRITE(4,120C)
      GO TO 1490
1492      CONTINUE
          WRITE(4,1417)
          READ(5,1202)V1
          PDSM=V1
          GC TO 1490
C*****************************************************************
C     MENU 42  PRCE OF HIT
C*****************************************************************
420       CALL FRTCMS('CLRSCRN ')
42        CONTINUE
      WRITE(4,142C)
1420  FORMAT('1','MENU (42) SELECT A CODE AS FOLLOWS:'//
     +T6,'FOR AN EXPLANATION              ',T51,'HP'/
     +T6,'P(H) VS AAA (RADAR)             ',T51,'AR'/
     +T6,'P(H) VS AAA (OPTICAL)           ',T51,'AO'/
     +T6,'P(H) VS LOW ALT. SAM            ',T51,'LS'/
     +T6,'TC RETURN TO MENU (4)           ',T51,'RT'/
     +T6,'TO TRANSFER TO OTHER MENUS      ',T51,'TN'/)
      READ(5,20C0) K8C
      IF(K8Q.EQ.K6(1)) GC TC 421
      IF(K8C.EC.K6(2)) GO TO 422
      IF(K8Q.EQ.K6(3)) GC TC 423
      IF(K8C.EC.KK(1)) GC TO 9977
      IF(K8C.EC.KK(2)) GC TO 998
```

```
410       CALL FRTCMS('CLRSCRN ')
41         CONTINUE
       WRITE(4,1410)
1410   FORMAT('1','MENU (41) SELECT A CODE AS FOLLOWS:'//
      +T6,'FOR AN EXPLANATION              ',T51,'HP'/
      +T6,'P(C) VS AAA (RADAR)             ',T51,'AR'/
      +T6,'P(D) VS AAA (OPTICAL)           ',T51,'AO'/
      +T6,'P(C) VS LOW ALT. SAM            ',T51,'LS'/
      +T6,'TO RETURN TO MENU (4)           ',T51,'RT'/
      +T6,'TO TRANSFER TO OTHER MENUS      ',T51,'TM'/)
       READ(5,2000) K7Q
       IF(K7Q.EQ.K6(1)) GO TO 411
       IF(K7Q.EQ.K6(2)) GO TO 412
       IF(K7Q.EQ.K6(3)) GO TO 413
       IF(K7Q.EQ.KK(1)) GO TO 9976
       IF(K7Q.EQ.KK(2)) GO TO 998
       IF(K7Q.EQ.KK(4)) GO TO 130
       WRITE(4,1200)
       GO TO 41
C*****************************************************************
C      PD AAA RADAR
C*****************************************************************
411       CALL FRTCMS('CLRSCRN ')
        WRITE(4,1411)PDAR
1411   FORMAT('1',T6,'THE PROBABILITY OF DETECTION BY AAA (RADAR) IS '
      +,F6.4//T6,'TO CHANGE THIS VALUE ENTER 1'/
      +T6,' ENTER 0 FOR NO CHANGE REQUIRED')
       READ(5,1211)I1
       IF(I1.EQ.0) GO TO 410
       IF(I1.EQ.1) GO TO 1413
1419   WRITE(4,1200)
       GO TO 411
1413       CONTINUE
           WRITE(4,1417)
1417       FORMAT('0','      PD  RANGE   0.0 TO 1.0    '//
      +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
           READ(5,1202)V1
           PDAR=V1
           GO TO 411
C*****************************************************************
C      PD AAA OPTICAL
C*****************************************************************
412       CALL FRTCMS('CLRSCRN ')
        WRITE(4,1415)PDAO
1415   FORMAT('1',T6,'THE PROBABILITY OF DETECTION BY AAA (OPTICAL) IS '
      +,F6.4//T6,'TO CHANGE THIS VALUE ENTER 1'/
      +T6,' ENTER 0 FOR NO CHANGE REQUIRED')
       READ(5,1211)I1
```

```
C*****************************************************************
320       CALL FRTCMS('CLRSCRN ')
32         CONTINUE
        WRITE(4,132C)AAAH,AAAC,SAMH,SAMD
1320   FORMAT('1','          MENU (32)                    '//
     +T6,'       THREAT DEFINITION                      '//
     +T6,'1    AAA THREAT DENSITY       ',T51,F6.4,' WP/SQ.MI.'/
     +T6,'2    AAA THREAT DIAMETER      ',T51,F6.2,' MI.'//
     +T6,'3    SAM THREAT DENSITY       ',T51,F6.4,' WP/SQ.MI.'/
     +T6,'4    SAM THREAT DIAMETER      ',T51,F6.2,' MI.'//
     +T6,'TO CHANGE A VALUE ENTER ITS NUMBER IN I1 FORMAT.'//
     +T6,' ENTER 0 FOR NO CHANGE REQUIRED')
      READ(5,1211)I1
      IF(I1.EQ.0) GO TO 120
      GO TO (321,322,323,324),I1
1329   WRITE(4,1200)
       GO TO 320
321        CONTINUE
           WRITE(4,1321)
1321       FORMAT('0','       AAA THREAT DENSITY RANGE 0.0 TO .02    '//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
           READ(5,1202)V1
           AAAH=V1
           GO TO 320
322        CONTINUE
           WRITE(4,1322)
1322       FORMAT('0','       AAA THREAT DIAMETER RANGE 0.0 TO 5.  '//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
           READ(5,1202)V1
           AAAD=V1
           GO TO 320
323        CONTINUE
           WRITE(4,1323)
1323       FORMAT('0','       SAM THREAT DENSITY RANGE 0.0 TO .002  '//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
           READ(5,1202)V1
           SAMH=V1
           GO TO 320
324        CONTINUE
           WRITE(4,1324)
1324       FORMAT('C','       SAM THREAT DIAMETER RANGE 0.0 TO 25.  '//
     +T6,'ENTER THE NEW VALUE IN REAL NUMBER FORMAT.')
           READ(5,1202)V1
           SAMD=V1
           GO TO 320
C*****************************************************************
C      MENU 41  PROB OF DETECTION
C*****************************************************************
```

```
     +T6,'        FM= 1 - .05 * TW                    '/
     +T6,'        PH'' = PH * (1. -(1.-FM)*FA)                    '/'
     +T6,'    VS AAA (RADAR)                                       '/
     +T6,'        PH= 1.                    FA= 1.'/
     +T6,'        FM= ( 1.-.15 * TW)*( 1. - EXP(-1*(WS-50.)/10.))'/
     +T6,'        PH'' = PH * (1. -(1.-FM)*FA)                    '/
     +T6,'    VS SAM                                               '/
     +T6,'        PH = .17512       FC = .6                        '/
     +T6,'        FM = 1.-7.80516*TW + 6.166 * WS**8 + .907024 * WS**-4'/
     +T6,'        PH'' = PH * FC * ( 1. - (1.- FM) * FA)          '//
     +T6,'          ENTER ANY INTEGER TO RETURN TO MENU 42         ')
      READ(5,*)IJK
      GO TO 420
9978    CALL FRTCMS('CLRSCRN ')
      WRITE(4,7978)
7978  FORMAT(' ',
     +T6,'THE P(S) VS INDIVIDUAL WEAPONS                          '/
     +T6,'     P(S) = 1 -  P(D) * P(H) * P(K/H)                   '//
     +T6,'THE P(S) FOR SINGLE SORTIE                              '/
     +T6,'     W = WEIGHTING FACTOR          XL = PENETRATION DISTANCE'/
     +T6,'     XH = THREAT DENSITY            DL = THREAT DIAMETER    '/
     +T6,'     H = A/C HIT    XK = A/C KILLED    A = A/C DAMAGED      '/
     +T6,'     ACOVER = A/C OVER TARGET       ATAC = TARGETS ATTACKED '/
     +T6,'     PSM = PROB. OF MISS. SURVIVAL  ACR1 = A/C IN FORMATION'//
     +T6,'     W = XL * XH * D / 100.       PSM = PS ** W          '/
     +T6,'     PH = (1. - PSM)/PKH           H1 = ACR1 * PH        '/
     +T6,'     XK1 = H * PKH                 A1 = H1 - XK1         '/
     +T6,'     ACOVER = ACR1-H1-H2-H3        ATAC = ACOVER * XNPAS '/
     +T6,'     H4 = ACOVER * PH              XK4 = H4 * PKH        '/
     +T6,'     A3 = H4 - XK4                 ACNHT = ACR1-H1-H4    '/
     +T6,'     ACDAM = A1 + A4               ACKIL = XK1 + XK4     '//
     +T6,'          ENTER ANY INTEGER TO RETURN TO MENU 6          ')
      READ(5,*)IJK
C-  #3 ------------------------------------------------------------
      GO TO 150
C-  #5 ------------------------------------------------------------
C ****************** PLOTTING INFORMATION ***************************
 8988 CALL FRTCMS('CLRSCRN ')
      WRITE(4,8889)
 8889 FORMAT(' ',        HELP FOR MENU (8)      '//
     *T6,'MENU (8) INCORPORATES A DATA GENERATING ROUTINE TO SAVE'/
     *T6,'THE PROBABILITIES OF A KILL ( P(K) = 1 - P(S) ) FOR'/
     *T6,'LATER PLOTTING.  THIS PLOT MAY BE OBTAINED FROM A'/
     *T6,'TEKTRONIX DUAL SCREEN (TEK618) SYSTEM.  THE P(K)'/
     *T6,'AGAINST THE APPROPRIATE THREAT TYPES ARE PRESENTED.'//
     *T6,'     THREE DESIGNS CAN BE PLOTTED AT A TIME, FOR EXAMPLE'/
     *T6,'YOUR BASELINE DESIGN, YOUR FIRST DESIGN, AND ONE OTHER'/
     *T6,'MODIFICATION.  YOU MUST HAVE DONE AND CHOSEN TO SAVE'/
```

```
     *T6,'PLCTTING DATA FRCM THREE RUNS.'//
     *T6,'     TO CBTAIN THE PLOT, FOLLOW THE SAME LOGON AND LINK'/
     *T6,'PRCCEDURES YOU UTILIZED TO ACCESS VISAP, HOWEVER, ENTER'/
     *T6,'DISVIS INSTEAD OF VISAP. THEN ENTER SUPPLT.'//
     *T6,'          ENTER ANY INTEGER TC RETURN TO MENU (8)')
      READ (5,*)IJK
      GO TO 8
C*****************************************************************
C          TRANSFER
C*****************************************************************
998       CALL FRTCMS('CLRSCRN ')
      WRITE(4,1998)
1998  FORMAT(' ','TRANSFER MENU, SELECT A CODE AS FOLLOWS:'/
     +T6,'MAIN MENU                    ',T51,'MM'/
     +T6,'   AIRCRAFT DESIGN SELECTION  ',T51,'DE'/
     +T6,'     A/C PERFCRMANCE INDICATORS  ',T51,'AP'/
     +T6,'     SUSCEPTIBILITY FEATURES     ',T51,'SF'/
     +T6,'     VULNERABILITY FEATURES      ',T51,'VF'/
     +T6,'   COMBAT SCENARIC SELECTION   ',T51,'MS'/
     +T6,'     MISSION PRCFILE             ',T51,'MP'/
     +T6,'     THREAT SELECTION            ',T51,'TH'/
     +T6,'   SUSCEPTIBILITY ASSESSMENT   ',T51,'SA'/
     +T6,'     PROBABILITY CF DETECTICN    ',T51,'PD'/
     +T6,'     PROBABILITY CF HIT          ',T51,'PH'/
     +T6,'   VULNERABILITY ASSESSMENT    ',T51,'VA')
      WRITE(4,19981)
19981 FORMAT(' ',T6,'     P(K/H)                          ',T51,'KH'/
     +T6,'     P(K/D)                      ',T51,'KD'/
     +T6,'   SURVIVABILITY ASSESSMENT    ',T51,'SV'/
     +T6,'     P(S) 1:1 AAA (RADAR)        ',T51,'AR'/
     +T6,'     P(S) 1:1 AAA (CPTICAL)      ',T51,'AC'/
     +T6,'     P(S) 1:1 LOW ALT SAM        ',T51,'LS'/
     +T6,'     SINGLE SCRTIE               ',T51,'SS'/
     +T6,'     CAMPAIGN EVALUATION         ',T51,'CE'/
     +T6,'TC EXIT CR PRINT RESULTS    ',T51,'EX'/)
      READ(5,2000) K9Q
      IF(K9C.EQ.K1(1)) GO TC 110
      IF(K9Q.EQ.K1(2)) GC TC 120
      IF(K9Q.EQ.K1(3)) GO TC 130
      IF(K9Q.EQ.K1(4)) GO TO 140
      IF(K9Q.EQ.K1(5)) GC TC 150
      IF(K9C.FQ.K2(1)) GO TC 210
      IF(K9Q.EQ.K2(2)) GC TC 220
      IF(K9C.EQ.K2(3)) GO TO 230
      IF(K9C.EQ.K3(1)) GC TO 310
      IF(K9C.EQ.K3(2)) GO TC 320
      IF(K9C.EQ.K4(1)) GO TC 410
      IF(K9C.EQ.K4(2)) GC TC 420
```

```
      IF(K9Q.EQ.K5(1)) GO TO 510
      IF(K9C.EQ.K5(2)) GO TO 520
      IF(K9Q.EQ.K6(1)) GO TO 610
      IF(K9Q.EQ.K6(2)) GO TO 620
      IF(K9C.EQ.K6(3)) GO TO 630
      IF(K9Q.EQ.K6(4)) GO TO 640
      IF(K9Q.EQ.K6(5)) GO TO 650
      IF(K9Q.EQ.KK(3)) GO TO 999
      IF(K9C.EC.K1(6)) GO TO 100
      WRITE(4,120C)
      GO TO 998
C*****************************************************************
C           EXIT
C*****************************************************************
C- #3 ---------------------------------------------------------------
1061      CONTINUE
          CALL SSRWT(B,W,EL,EC,ED,EL,TW,WS,WT,XL,ICA,ICS,IEA,
C********* SUPPORT A/C WEIGHT ESTIMATIONS ROUTINE ******************
     @    IEP,IFE,IFS,IFV,JAM,IRCS,XMR,XMA,XMT,IWARN,ICHAFF,
     @    BLTOGW,TOGW)
C- #3 ---------------------------------------------------------------
C******** TO SAVE DATA ************************************************
      REWIND 3
      WRITE(3,1012)TW,WS,WT,B,XL,W,EC,ED,EL,JAM,IRCS,IWARN,ICHAFF,IFS,
     *     IFV,IFE,IEA,IEP,ICS,ICA,XMR,XMA,XMT,AAAH,AAAD,SAMH,SAMD,PDAO,
     *     PDAR,PCSM,PHR,PHC,PHSM,VAAAA,PKHAAA,VASM,PKHSM,PSAR,PSAO,
     *     PSSM,ACR,X1NPAS,ACR1,NSRT,XNPASS,NS,
     *     ACR2,TOTSR,TOTACK,TOTACL,TOTACR,BLTOGW,TOGW
C
C- #3 ---------------------------------------------------------------
      CALL FRTCMS('CLRSCRN ')
       WRITE (4,9200)TW,WS,WT,XMR,AAAH,XMA,AAAD,XMT,SAMH,SAMD
       WRITE(4,222C)JAM,IFS,IRCS,IFV,IWARN,IFE,ICHAFF,IEA,IEP,ICS,ICA
       WRITE(4,9201)
       WRITE(4,92C2)PSAO,PDAC,PHO,PKHAAA
       WRITE(4,9203)PSAR,PCAR,PHR,PKHAAA
       WRITE(4,92C4)PSSM,PDSM,PHSM,PKHSM
       WRITE(4,92C5)
       WRITE(4,92C6)ACR1,NSRT,XNPASS,NS,ACR2,TOTSR,TOTACK,TOTACL,TOTACR
       WRITE(4,922C)
       WRITE(4,92C7)BLTOGW,TOGW
       WRITE(4,922C)
       WRITE(4,922C)
       WRITE(4,8282)
      GO TO 8
C*****************************************************************
999       CONTINUE
          CALL FRTCMS('CLRSCRN ')
```

```
      WRITE(4,9999)
9999  FORMAT('0',' TO PRINT YOUR RESLLTS AND EXIT ENTER  "0"'/
     +,' TO PRINT YOUR RESULTS AND REENTER PROGRAM ENTER "1"'/
     +,' TO EXIT WITHCUT A PRINT ENTER "2"')
      READ(5,*)IJK
      IF(IJK.EC.2) GO TO 99999
C- #4 ------------------------------------------------------------------
      WRITE (6,92C0)TW,WS,WT,XMR,AAAH,XMA,AAAD,XMT,SAMH,SAMD
      WRITE(6,222C)JAM,IFS,IRCS,IFV,IWARN,IFE,ICHAFF,IEA,IEP,ICS,ICA
      WRITE(6,922C)
      WRITE(6,9201)
      WRITE(6,92C2)PSAO,PDAC,PHO,PKHAAA
      WRITE(6,9203)PSAR,PDAR,PHR,PKHAAA
      WRITE(6,9204)PSSM,PDSM,PHSM,PKHSM
      WRITE(6,9220)
      WRITE(6,9205)
      WRITE(6,9206)ACR1,NSRT,XNPASS,NS,ACR2,TOTSR,TOTACK,TOTACL,TOTACR
      WRITE(6,9220)
      WRITE(6,9207)BLTOGW,TOGW
      IF(IJK.EQ.1) GO TO 1022
C- #3,#4 ---------------------------------------------------------------
9200  FORMAT('1',T25,'** CLOSE AIR SUPPORT AIRCRAFT **'///
     *      T30,'* PERFORMANCE FEATURES'//
     *     ,'    THRUST TC WEIGHT',T30,F8.2,
     *      T42,'   WING LCADING',T65,F8.2/
     *     ,'    ORDNANCE WEIGHT',T30,F8.2///
     *     ,' * MISSION PARAMETERS',T40,' * THREAT PARAMETERS'//
     *     ,'    RACIUS CF ACTION',T30,F8.2,
     *      T42,'   AAA DENSITY',T65,F8.2/
     *     ,'    LCITER ALTITUDE',T30,F8.2,
     *      T42,'   AAA DIAMETER',T65,F8.2/
     *     ,'    TIME ON STATION',T30,F8.2,
     *      T42,'   SAM CENSITY',T65,F8.2/
     *      T42,'   SAM DIAMETER',T65,F8.2//)
C- #3,#4 ---------------------------------------------------------------
9201  FORMAT ('0','       * SURVIVABILITY ASSESSMENT:'//
     *      T18,'P(S)     P(D)     P(H)     P(K/H)')
9202  FORMAT (' ',' VS AAA CPTICAL ',4(F4.2,5X))
9203  FORMAT (' ',' VS AAA RADAR   ',4(F4.2,5X))
9204  FORMAT (' ',' VS SAM         ',4(F4.2,5X))
9205  FORMAT ('0',' * CAMPAIGN ANALYSIS:'/)
9206  FORMAT ('0',' INITIAL A/C    ',F8.0,'     NUMBER OF RAIDS    ',I7,/
     +       ' PASSES/SCRTIE ',F8.0,'     SCRTIES FOR REPAIR ',I5,/
     +       ' A/C READY     ',F8.0,'     TOTAL SCRTIES      ',F8.0,/
     +       ' TCTAL TARGETS ',F8.0,'     TCTAL A/C LOST     ',F8.0,/
     +       ' IN REPAIR     ',F8.0)
9207  FORMAT ('0',' BASELINE TOGW ',F10.2,T36,'ENHANCED TOGW ',F10.2)
9220  FORMAT (' ')
```

```
8282  FORMAT(4('0'))
99999      STOP
           END
           SUBROUTINE SRPDSM(JAMS,IRCSS,PDF)
C*************************************************************************
C*************************************************************************
C*******                                        ***************************
C*******    SUBROUTINE PD LOW ALT SAM           ***************************
C*******       TO MENU PROGRAM                  ***************************
C*************************************************************************
C*************************************************************************
      DIMENSION H(2,4,6),F(101),PDT(101),XX(101)
      DATA H/   35.0, 10.3    ,33.8 ,9.8    ,31.8 ,9.5    ,29.1 ,9.1,
     @          19.6, 5.8     ,17.9 ,5.3    ,15.9 ,4.8    ,13.4 ,4.0,
     @          13.4, 4.1     ,12.6 ,2.9    ,11.2 ,3.5    , 9.5 ,3.0,
     @           9.5, 3.0     , 9.0 ,2.9    , 8.5 ,2.7    , 7.5 ,2.5,
     @           5.9, 1.8     , 5.5 ,1.6    , 5.0 ,1.5    , 4.3 ,1.2,
     @           4.3, 1.3     , 3.9 ,1.2    , 3.5 ,1.0    , 2.9 ,0.8/
C****************** FOR ALL ALT .LT. 10,000 FT*************************
      DSR=1.5
C****************** CANT USE ZERO AS A INDICIES************************
      I=IRCSS+1
      J=JAMS+1
C****************** SELECTS PROPER MEAN AND DEVIATIONS*****************
      X=H(1,I,J)
      S=H(2,I,J)
C******************** CONSTANTS FOR EASE OF WRITING*******************
C- #1 ---------------------------------------------------------------------
      CON1=1./(S*SQRT(2.*3.14159))
      CON2=-.5/S**2
C********************INTEGRATION START AT MEANS + 4 DEVIATIONS********
      XI=X+4*S
C********************100 STEPS IN ITEGRATION*************************
      STEP=-S/12.5
C***************** INITIAL VALUES TO START INTEGRATION****************
      F(1)=0.0
      XX(1)=XI
      PDF=0.
      PD=0.
C********************INTEGRATION LOOP*************************************
      DO 10 JJ=1,100
            F(JJ+1)= CON1*EXP(CON2*(XI-X)**2)
            XI=XI+STEP
            AREA=-.5*STEP*(F(JJ+1)+F(JJ))
            PD=PD+AREA
            PDT(JJ+1)=PD
               IF(XI.LT.DSR)GO TO 5
                  PDF=PD
5              CONTINUE
```

```
            XX(JJ+1)=XI
            PD=PD+AREA
10      CONTINUE
C#######################SETS UP A MINIMUM PD OF .1
        IF(PDF.GT.0.01) GO TO 20
        PDF=.100
20        CONTINUE
        RETURN
        END
           SUBROUTINE SRPHO(THS,PDAM)
C*****************************************************************************
C**************  AAA OPTICAL PH ***********************************************
C*****************************************************************************
           PH = .1456
           FA = 1.
           FM= ( 1.-.05 * THS)
           XMF = 1. -(1.-FM)*FA
           PDAM = PH*XMF
           RETURN
           END
           SUBROUTINE SRPHR(THS,WSS,PDAM)
C*****************************************************************************
C**************** AAA RADAR PH ***********************************************
C*****************************************************************************
              PH= 1.
              FA= 1.
C- #1 ---------------------------------------------------------------------------
              FM= ( 1.-.15 * TWS)*( 1. - EXP(-1.*(WSS-50.)/10.))
           XMF = 1. -(1.-FM)*FA
           PDAM = PH*XMF
           RETURN
           END
           SUBROUTINE SRPHSM(IWARN,ICHAFF,THS,WSS,PDAM)
            XXMR = 1.5
C*****************************************************************************
C**************   SAM PH ***************************************************
C*****************************************************************************
              PH = .17512
           CALL SRFC (ICHAFF,FC)
C*****************************************************************************
C**************  MODIFIED FOR CHAFF ******************************************
C*****************************************************************************
              PH1 = PH * FC
           CALL SRFA (XXMR,IWARN,FA)
C*****************************************************************************
C**************  MODIFIED FOR MANUVERING *************************************
C*****************************************************************************
         FM = 1.-7.80516*TWS+6.166*(WSS/100.)**8+.907024*(100./WSS)**4
```

```
      IF(FM.LT.0.01)FM = 0.01
            XMF = 1. - (1.- FM) * FA
        PDAM = PH1 * XMF
        RETURN
        END
      SUBROUTINE SRFA(XXMRS,IWARN,FAS)
C*************************************************************************
C****** ALERTION FACTOR *************************************************
      REAL MRM(28),FVM(28),FESM(12),MRSM(12)
        DATA FESM/1.,.99999,.97,.91,.82,.69,.53,.35,.22,.137,.065,0./
        DATA MRSM/0.,36.,40.,50.,60.,70.,80.,90.,100.,110.,120.,140./
      DATA MRM/0.,.1,.94,2.,2.54,3.,3.08,3.48,3.78,4.,4.05,4.23
     A,4.35,4.45,4.55,4.68,4.8,4.9,5.05,5.35,5.8,6.,6.39,7.,7.36
     B,8.,9.,10./
      DATA FVM/1.,.995,.95,.943,.9,.868,.85,.8,.75,.712,.7,.65,.6
     A,.55,.5,.45,.4,.357,.35,.3,.25,.216,.2,.165,.15,.13,.114,.101/
      IF(IWARN.EQ.1)GO TO 15
      KEY=1
5     CONTINUE
        KEY=KEY+1
      IF(MRM(KEY).LT.XXMRS) GO TO 5
      DELTAX=MRM(KEY)-MRM(KEY-1)
      DELTAY=FVM(KEY)-FVM(KEY-1)
      FVS=((XXMRS-MRM(KEY-1))/DELTAX)*DELTAY+FVM(KEY-1)
      FAS = FVS
      GO TO 20
15    CONTINUE
        J=1
10      CONTINUE
        J=J+1
        IF(XXMRS.GE.MRSM(J)) GO TO 10
        DX= MRSM(J-1)-MRSM(J)
        DY= FESM(J-1)-FESM(J)
        FES=((XXMRS-MRSM(J-1))/DX)*DY+FESM(J-1)
        FAS = FES
20    CONTINUE
        RETURN
        END
        SUBROUTINE SRFC(ICHAFF,FC)
        REAL PBTSM(17)
        DATA PBTSM/.00,.19,.35,.49,.6,.68,.74,.8,.83,.86,.9,.92,.935,
     A          .95,.96,.97,.98/
        PBTS=0.
        IF(ICHAFF.EQ.0) GO TO 10
        NBUNDS = 4
        PBTS=PBTSM(NBUNDS+1)
10      FC = 1. - PBTS
        RETURN
```

```
      END
      SUBROUTINE SRVASM(IFSS,IFVS,VASMS,PKHSMS)
C*****************************************************************
C*************  VULNERABLE AREA VS SAM ***************************
C*****************************************************************
C************* SET UP VALUES *************************************
      DATA F1/0./,F2/0./,F3/0./,F4/0./
      IF(IFSS.GE.3)                                          F1 = 1.
      IF((IFSS.NE.1).AND.(IFSS.NE.3).AND.(IFSS.NE.6))  F2 = 1.
      IF((IFVS.EQ.3).OR.(IFVS.EQ.4).OR.(IFVS.EQ.6))  F3 = 1.
      IF((IFVS.EQ.5).OR.(IFVS.EQ.6))                         F4 = 1.
C************* CALCULATE PK/H VS SAM *****************************
      ITF = INT(F1+F2+F3+F4)
      GO TO (10,20,30,40),ITF
1       PKHSMS = 1.
      GO TO 50
10      PKHSMS = F1*.984 + F2*.995 + F3*.668 + F4*.911
      GO TO 50
20      PKHSMS = F1*F2*.984 + F1*F3*.521 + F1*F4*.898 +
     &         F2*F3*.628 + F2*F4*.904 + F3*F4*.324
      GO TO 50
30      PKHSMS = F1*F2*F3*.484 + F1*F2*F4*.896 +
     &         F1*F3*F4*.223 + F2*F3*F4*.258
      GO TO 50
40      PKHSMS = .182
50    CONTINUE
C************* CALCULATE VULN AREA VS SAM ************************
      VASMS = 100. * EXP(PKHSMS-1.)
      RETURN
      END
      SUBROUTINE SRVAAA(IFSS,IFVS,IFES,IEAS,IEPS,ICSS,ICAS,A,B,C,D,E,F,
     &VAAAAS,PKHAAS)
C*****************************************************************
C*************  VULNERABLE AREA VS AAA ***************************
C*****************************************************************
      DIMENSION XFE(8),XEA(2)
      DATA XFE/2.,3.,4.,6.,8.,12.,16.,32./
      DATA XEA/2.,1./
C************* NEEDED VARIABLES **********************************
      WES = 11333. + 1.34555*A*F -.00247249*B*F + .067473*C*E
      FRS = -11.1186*A*B + 18.6825*A*C +.3591*A*F +.236943*B*E
     &      - .00004441459*D*F + .00256493*E*F
      FT = 6 * FRS
C************* SET UP VALUES *************************************
      FS = FLOAT(IFSS)
      FV = FLOAT(IFVS)
      FE = XFE(IFES) * FT * .001
      EA = XEA(IEAS) * WES * .001
```

```
          EP = FLOAT(IEPS)
          CS = FLOAT(ICSS)
          CA = FLOAT(ICAS)
C************ CALCULATE VULNERABLE AREA ***************************
      VAAAAS = 41.56 - 2.244*ALOG(FE) - 4.373*ALOG(FV) - 4.732*ALOG(FS)
     &           - 5.009*ALOG(CS) + 5.946*ALOG(EA) - 2.491*ALOG(CA)
     &           + 16.44*ALOG(FT*.001) - 47.503 * ALOG(EP)
C************ CALCULATE P(K/H) ************************************
C- #1 ----------------------------------------------------------------
          PKHAAS = 1.- EXP (-1.*VAAAAS/125.)
        RETURN
        END
        SUBROUTINE SORT(
     &XL1,XH1,D1,PKH1,PS1,   XL2,XH2,D2,PKH2,PS2, XL3,XH3,D3,PKH3,PS3,
     &ACR1,NSRT,XNPAS,NS,          ACR2,TOTSR,TOTACK,TOTACL,TOTACR)
C*****************************************************************
C       XL-PENDIS     H-THREAT DENSITY    D- THREAT DIAMETER
C
C*****************************************************************
C
          W1 = XL1 * XH1 * D1 / 100.
          W2 = XL2 * XH2 * D2 / 100.
          W3 = XL3 * XH3 * D3 / 100.
C
          PSM1 = PS1 ** W1
          PSM2 = PS2 ** W2
          PSM3 = PS3 ** W3
C
          PH1 = (1. - PSM1)/PKH1
          PH2 = (1. - PSM2)/PKH2
          PH3 = (1. - PSM3)/PKH3
C
C***************THREAT 1**************
              H1 = ACR1 * PH1
              XK1 = H1 * PKH1
              A1 = H1 - XK1
C***************THREAT 2**************
                H2 = (ACR1-H1) * PH2
                XK2 = H2 * PKH2
                A2 = H2 - XK2
C***************THREAT 3**************
                  H3 = (ACR1-H1-H2) * PH3
                  XK3 = H3 * PKH3
                  A3 = H3 - XK3
C***************OVER TARGET***********
                ACOVER = ACR1-H1-H2-H3
                ATAC = ACOVER * XNPAS
C***************EGRESS****************
```

```
C***************TREAT 1**************
                H4 = ACOVER * PH1
                XK4 = H4 * PKH1
                A4 = H4 - XK4
C***************TREAT 2**************
                  H5 = (ACOVER-H4) * PH2
                  XK5 = H5 * PKH2
                  A5 = H5 - XK5
C***************TREAT 3**************
C- #1 ------------------------------------------------------------------
                    H6 = (ACOVER-H4-H5) * PH3
                    XK6 = H6 * PKH3
                    A6 = H6 - XK6
C***************TOTALS FOR SORTIE********
                ACNHT = ACR1-H1-H2-H3-H4-H5-H6
                ACDAM = A1 + A2 + A3 + A4 + A5 + A6
                ACKIL = XK1 + XK2 + XK3 + XK4 + XK5 + XK6
C***************FOR NEXT SORTIE***********
                    ACR2 = ACNHT
                    TOTSR = ACR1
                    TOTACK = ATAC
                    TOTACL = ACKIL
                    TOTACR = ACDAM
        RETURN
          END
       SUBROUTINE CAMP(
C*************************************************************************
C*****  SUBROUTINE FOR CAMPAIGN ANALYSIS ********************************
C*************************************************************************
     &XL1,XH1,D1,PKH1,PS1,   XL2,XH2,D2,PKH2,PS2, XL3,XH3,D3,PKH3,PS3,
     &ACR1,NSRT,XNPAS,NS,          ACR2,TOTSR,TOTACK,TOTACL,TOTACR)
        DIMENSION ACR(200)
          IF(NS.EQ.0)NS = 1
          TOTSR  = 0.
          TOTACK = 0.
          TOTACL = 0.
          TOTACR = 0.
C
          W1 = XL1 * XH1 * D1 / 100.
          W2 = XL2 * XH2 * D2 / 100.
          W3 = XL3 * XH3 * D3 / 100.
C
          PSM1 = PS1 ** W1
          PSM2 = PS2 ** W2
          PSM3 = PS3 ** W3
C
          PH1 = (1. - PSM1)/PKH1
          PH2 = (1. - PSM2)/PKH2
```

```
          PH3 = (1. - PSM3)/PKH3
C
         ACR(1)= ACR1
         DO 10 I = 1,NSRT
C****************INGRESS*****************
               H1 = ACR(I) * PH1
               XK1 = H1 * PKH1
               A1 = H1 - XK1
                  H2 = (ACR(I)-H1) * PH2
                  XK2 = H2 * PKH2
                  A2 = H2 - XK2
                     H3 = (ACR(I)-H1-H2) * PH3
                     XK3 = H3 * PKH3
                     A3 = H3 - XK3
C****************OVER TARGET**************
                ACOVER = ACR(I)-H1-H2-H3
                ATAC = ACOVER * XNPAS
C****************EGRESS*******************
               H4 = ACCVER * PH1
               XK4 = H4 * PKH1
               A4 = H4 - XK4
                  H5 = (ACCVER-H4) * PH2
                  XK5 = H5 * PKH2
                  A5 = H5 - XK5
C- #1 ---------------------------------------------------------------------
                     H6 = (ACOVER-H4-H5) * PH3
                     XK6 = H6 * PKH3
                     A6 = H6 - XK6
C****************TOTALS FOR SORTIE*********
               ACNHT = ACR(I)-H1-H2-H3-H4-H5-H6
               ACDAM = A1 + A2 + A3 + A4 + A5 + A6
               ACKIL = XK1 + XK2 + XK3 + XK4 + XK5 + XK6
C****************FOR NEXT SORTIE***********
                     TOTACR = TOTACR+ACDAM
                     ACROUT = TOTACR/FLOAT(NS)
                     TOTACR = TOTACR-ACROUT
                     ACR(I+1) = ACNHT + ACROUT
                     ACR2 = ACR(I+1)
                     TOTSR = TOTSR + ACR(I)
                     TOTACK = TOTACK + ATAC
                     TOTACL = TOTACL + ACKIL
10          CONTINUE
          RETURN
            END
            SUBROUTINE SSRWT(SPAN,W,DL,EC,ED,EL,TW,WS,WT,XL,ICA,ICS,IEA,
C*****************************************************************************
C********* SUPPORT A/C WEIGHT ESTIMATIONS ROUTINE ****************
C*****************************************************************************
```

```
     @     IEP,IFE,IFS,IFV,JAM,IRCS,XMR,XMA,XMT,IWARN,ICHAFF,
     @     BLTOGW,TCGW)
           REAL A,B,C,D,E,F,G,I,J
           A = TW
           B = WS
           C = XMR
           D = XMA
           E = XMT
           F = WT
           G = 0.
           H = 0.
           I = 0.
           J = 0.
C*************************************************************************
      BLTOGW    = .129616E+05 + .425125*F +2.16928*H + 2.227*A*F
     @+.16377*C*E - 13.6801*C*I + 0.272868E-02*E*F +21.1006*F*G
     @-.12935E-04*E*H + 1.672*F*J

C*************************************************************************
C         A/C TCGW OF DESIGN WITH SURVIVABILITY ENHANCEMENT
C*************************************************************************
C         THE FOLLOWING ASSUMPTION MADE;
C             ALL SELF-SEALING DONE FOR 23 MM
C             TWO WING TANKS, FOUR FUSELAGE TANKS, PLUS SUMP TANK(S)
C             DUAL SUMP TANKS HAVE EQUAL VOLUMN OF SINGLE SUMP TANK
C             EACH TANK HOLDS 1/7 OF TOTAL VOLUMN
C             INTERNAL FOAM USE VICE ULLAGE INERTING
C             FIRE EXTINGUSHING VICE EXTERNAL FOAM
C*************************************************************************
           IF(JAM.EQ.0) GO TO 40
              G = .8675 * WS / BLTOGW
40         CONTINUE
C*************************************************************************
C         WEIGHT INCREASE CALCULATIONS
C*************************************************************************
C******   FR = FUEL RECUIRED FOR MISSION ********************************
      FR = -11.1186*A*B + 18.6825*A*C + C.3591*A*F + 6853.06*A*J
     @+ 0.236943*B*E + 186.885*C*G -21.0454*C*I - 0.44145E-05*D*F
     @+.0025649?*E*F +655.357*E*G + 7.19584*G*H + 142678.*G*J
     @-0.397397E-05*H*H + 0.415838*H*J
C******* WEIGHT INCREASE DUE TO SELF-SEALING ************************
           XNT = 2.
           IF((IFS.EQ.1).OR.(IFS.EQ.3).OR.(IFS.EQ.6)) XNT = 0.
           IF(IFS.EQ.2) XNT = 1.
      WSSP = 1.45*(2.2*8./7.-1.)*(1./7.)**.75*(FR/6.6)**.64*XNT**.11
C******* WEIGHT INCREASE DUE TO INTERNAL FOAM ************************
      WF = 0.
           IF((IFV.EQ.4).OR.(IFV.EQ.6)) WF = .0186 * FR/6.6
```

```
C******* WEIGHT INCREASE DUE TO FIRE EXTINGUISHING ******************
      WFE = 0.
          XV = 4./3. * ( EC + 1.) * EC * EL
          IF((IFV.EQ.5).OR.(IFV.EQ.6)) WFE = 10.5 * XV**.26
C******* WEIGHT INCREASE DUE TO DUCT PROTECTION *********************
      XND = 1.
      WAB= 0.
      IF(IEP.EQ.2) XND = 2.
      XS = DL * EC * XND * .5
      IF((IFE.EQ.2).OR.(IFE.EQ.4).OR.(IFE.EQ.6)) WAB = 7.6 * XS
C******* WEIGHT INCREASE DUE TO ARMOR *******************************
      AD = 0.
          IF(ICA.EQ.2) AD = 10.
          IF((ICA.EQ.3).OR.(ICA.EQ.4)) AD = 18.
          IF((ICA.EQ.5).OR.(ICA.EQ.6)) AD = 30.
          WARM = 12. * AD
C******* WEIGHT INCREASE DUE TO ENGINE SEPERATION*********************
          XEB = 0.
          IF(IEA.EQ.1) XEB = 0.
          IF(IEA.EQ.2) XEB = 4.
          IF(IEP.EQ.2) XEB = 6.
          XA = ED * 12.
          XN = 11.
          WENG = 2000.
      WES = WENG * XN * .526 * XA * XEB *.000001
C******* WEIGHT INCREASE DUE TO RAM **********************************
          XTT = .1
          XS = 0.
          IF(IRCS.EQ.1) XS = 10.
          IF(IRCS.EQ.2) XS = 16.
          IF(IRCS.EQ.3) XS = 16. + BLTOGW/WS *.69
          WRAM = XTT * XS * 23.8
C******* WEIGHT INCREASE DUE TO REDUNDANT CONTROLS *******************
          BACKUP = 0.
          IF((ICS.EQ.3).OR.(ICS.EQ.4)) BACKUP = 1.
          XLGP = H + EC + SPAN + XL / 2.
          WRED = BACKUP * (2.207 * XLGP  - 4.79)
C******* WEIGHT INCREASE DUE TO RWR **********************************
          WEW = 0.
          IF(IWARN.EQ.1) WEW = 50.
C******* WEIGHT INCREASE DUE TO RADAR JAMMER **************************
          WJW = 0.
          IF(JAM.EQ.1) WJW = 80.
          IF(JAM.EQ.2) WJW = 100.
          IF(JAM.EQ.3) WJW = 200.
          IF(JAM.EQ.4) WJW = 500.
          IF(JAM.EQ.5) WJW = 1000.
C******* WEIGHT INCREASE DUE TO CHAFF DISPENSER ***********************
```

```
      WCD = 0.
      IF(ICHAFF.EQ.1) WCD = 86.
C******* WEIGHT INCREASE DUE TO SUBMERGED STORE ************************
      WSOR = 0.
      IF(IRCS.EQ.3) WSOR = 1.13 * WT/100.
C*************************************************************************
C******* TOTAL WEIGHT INCREASE ******************************************
      H =  WSSP+WF+WFE+WBB+WARM+WES+WRAM+WRED+WFW+WJW+WCD+WSOR
C*************************************************************************
C******* TOTAL TOGW ON ENHANCED A/C**************************************
C*************************************************************************
      TOGW   = .129616E+05 + .425125*F +2.16928*H + 2.227*A*F
     @+.16377*C*E - 13.6801*C*I + 0.272868E-02*E*F +21.1006*F*G
     @-.12925E-04*E*H + 1.672*F*J
       RETURN
       END
```

```
C*************************************************************************
C**                                                                     **
C**      SUPPLT < SUPPORT PLOT >                                        **
C**      PROGRAM TO GRAPH P(K)'S VS. THREATS AGAINST                    **
C**      CLOSE AIR SUPPORT AIRCRAFT                                     **
C**                                                                     **
C*************************************************************************
      DIMENSION Y0(3),Y1(3),Y2(3),Y3(3),XC(3),IPKRAY(400)
     *          ,LABEL(20)
      DATA LABEL/' ',' ',' ',' ',' ','AAA(','()OP','TICA','L())',
     *           'AAA(',',()RA','DAR(',')  ',
     *           'SAM ',' ',' ',' ',' ',' ',' ',' ',' ',' '/
      DATA YC/0.,0.,0./
      DATA XC/1.,2.,3./
C
      READ(5,900)(Y1(I),I=1,3),(Y2(I),I=1,3),(Y3(I),I=1,3)
  900 FORMAT(F4.2)
C
      CALL TEK618
      CALL HWRCT('MOVIE')
      CALL BLOWUP (1.4)
      CALL PAGE(8.5,11.)
      CALL NOBRDR
      CALL AREA2D(6.,8.5)
      CALL XNAME('THREATS$',100)
      CALL YNAME('P(()K())$',100)
      CALL SWISSM
      CALL SHDCHR(90.,1,.003,1)
      CALL BASALF('STAND')
      CALL MIXALF('L/CSTD')
      CALL HEADIN('CLOSE AIR SUPPORT AIRCRAFT$',100,1.5,2)
      CALL HEADIN('L(OSS) R(ATE) VS. T(HREAT) T(YPE)$',100,1.1,2)
      CALL YREVTK
      CALL YAXANG(0.)
      CALL XTICKS(0)
      CALL XAXEND('NOENDS')
      CALL YAXEND('NOLAST')
      CALL SWISSL
      CALL HEIGHT(.12)
      CALL FRAME
      CALL THKFRM(.10)
      CALL XLABGR(LABEL,4,5,0.,.1,1.1)
      CALL BLREC(0.01,8.1,4.29,0.6,0)
      CALL BLREC(4.3,7.7,1.7,1.0,0)
      CALL BLKEY(IC)
      CALL CLUSTR(3,.08)
      CALL HEIGHT(.08)
      CALL BARDCC('SECOND','OUTSIDE',2)
```

```
CALL BLBAR
CALL VBARS('LABEL',Y0,Y1,3)
CALL VBARS('LABEL',Y0,Y2,3)
CALL VBARS('LABEL',Y0,Y3,3)
CALL HEIGHT(.05)
CALL DOT
CALL GRID(0,2)
CALL RESET('DOT')
CALL HEIGHT(.10)
CALL BLOFF(IC)
MAXLIN=LINEST(IPKRAY,400,40)
CALL LINES('B(ASELINE)$',IPKRAY,1)
CALL LINES('1ST D(ESIGN)$',IPKRAY,2)
CALL LINES('2ND D(ESIGN)$',IPKRAY,3)
CALL LEGEND(IPKRAY,3,4.5,7.6)
CALL ENDPL(0)
CALL DONEPL
STOP
END
```

LIST OF REFERENCES

Hesser, N. P., The Development of an Interactive Computer Program for the Survivability Evaluation of Aircraft Conceptual Designs, M.S. Thesis, Naval Postgraduate School, Monterey, California, June 1982.

Ball, R. E., The Fundamentals of Aircraft Survivability Analysis and Design, Department of Aeronautics, Naval Postgraduate School, Monterey, California, April 1982.

INITIAL DISTRIBUTION LIST

		No. Copies
1.	Defense Technical Information Center Cameron Station Alexandria, Virginia 22314	2
2.	Library, Code 0142 Naval Postgraduate School Monterey, California 93940	2
3.	Professor R. E. Ball, Code 67Bp Department of Aeronautical Engineering Naval Postgraduate School Monterey, California 93940	2
4.	LCDR R. M. Hill, USN Naval Plant Representative Office Sikorsky Aircraft Division United Technologies Corporation Stratford, Connecticut 06497	2
5.	Mr. Paul Chan (220-48) Vought Corporation P.O. Box 225907 Dallas, Texas 75265	1
6.	Mr. Jiten Chhabra Lockheed California Company Dept. 7525, Bldg. 67, Plant A1 P.O. Box 551 Burbank, California 91520	1
7.	Mr. Walter Waskowski Northrop Corporation Aircraft Division One Northrop Avenue Hawthorne, California 90250	1
8.	Capt. Steve Hollowell AFWAL/FIMB Wright-Patterson AFB, Ohio 45433	1
9.	Mr. Milfred W. Brown Naval Air Systems Command Washington, DC 20361	1

		No. Copies
10.	Mr. John J. Morrow (Code 338) Naval Weapons Center China Lake, California 93555	2
11.	Mr. D. Bartz Sikorsky Aircraft Co. Survivability/Vulnerability Dept. North Main St. Stratford, Connecticut 06602	1
12.	Mr. W. Darling Rockwell International North American Aircraft Operations P.O. Box 92098 Los Angeles, California 90090	1
13.	Department Chairman, Code 67 Department of Aeronautics Naval Postgraduate School Monterey, California 93940	1
14.	Combat Data Information Center ATWAL/FIES/CDIC Wright Patterson AFB, Ohio 45433	1
15.	Mr. Dale Atkinson (Air-5164) Naval Air Systems Command Washington, DC 20361	1
16.	Mr. Michael Meyers McDonnell Douglas Aircraft Co. P.O. Box 516 St. Louis, Missouri 63166	1

END

DATE
FILMED

6-83

DTIC